Wii Fit™ Rechargeable Battery for the balance board



Package contents

- Built-in 650mAh NiMH batteries
- AC 5V adapter
- Ouick Setup Guide

Note: Charge the battery pack fully before using it the first time. It may take three hours to do this. The charging indicator will indicate when the battery is fully charged. The LED will turn red and green.

Product features

Charging indicator



Battery notes:

- Built-in 650mAh NiMH batteries
- Easily recharge the battery with one AC 5V adapter (included)
- Battery pack can be charged and used simultaneously
- Recharging time: 3 hours
- Battery life: 500 charging cycles
- · When the batteries are fully charged, the charging will automatically stop
- Designed with short-circuit protection
- · Charging status indicator

Using the battery pack

- 1 Insert the battery pack into the battery compartment of the Wii Fit[™] balance board.
- 2 Connect the DC connector of the AC power adapter to the DC 5V input jack on the battery pack, and connect the AC power adapter to a standard AC outlet.



- During charging, the charging indicator LED is RED.
- When the battery pack is fully charged, the charging indicator LED is green.



Note: Disconnect the AC power adapter from the wall outlet before unplugging the DC plug from the battery pack.

Charging method:

- Recharge the battery pack when first using this product or after long periods of non-use.
- Make sure to deplete the battery the first three times you use it, then fully recharge it. This will train the battery to charge to its maximum power.
 - The fully charged battery can lose power if not used for a long period.
 We recommend that you recharge the battery at least once every two months. Otherwise, the battery might not be recharged.

Notes:

- Rechargeable battery packs only attain maximum charging capacity after they have been charged and discharged several times.
- The battery pack has a limited service life, and playing time is reduced after many charging cycles.

Battery warnings

actions:

- Do not handle a damaged or leaking battery pack. Contact with the
 material can result in injury or burns to the eyes or skin. Even if foreign
 substances are not immediately visible, chemical changes in the
 material can result in injuries occurring at a later time. If you come into
 contact with material from a leaking battery pack, take the following
 - If the material gets into your eyes, do not rub. Immediately flush your eyes with clean water and seek medical attention.
 - If the material comes into contact with your skin or clothes, immediately rinse the affected area with clean water. Consult your physician if inflammation or soreness develops.
 - Do not allow the battery pack to come into contact with fire or subject it to extreme temperatures such as in direct sunlight, in a vehicle exposed to the sun, or near a heat source.
- Do not cause the battery pack to short-circuit.
- · Do not disassemble or tamper with the battery pack.

- use.Do not throw or drop the battery pack or subject it to strong physical shock.
- Do not put heavy objects on, or apply pressure to, the battery pack.

 Prevent damage to the battery pack. Do not carry or store the battery pack with metal items such as coins or keys. If damaged, discontinue

- Do not put heavy objects on, or apply pressure to, the battery pack.
 Do not allow the battery pack to come into contact with liquids. If it
- becomes wet, discontinue use until it is completely dry.
- Keep the battery pack out of reach of small children.
- Dispose of batteries in accordance with local and national disposal regulations (if any).
 If the Wii Fit balance board will not be used for an extended period of
- time, remove the battery pack and store it in a cool, dry place.

90-day limited warranty

Visit www.rocketfishproducts.com for details

ICES-003

This Class B digital apparatus complies with Canadian ICES-003.

FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- © 2009 Best Buy Enterprise Services, Inc.
- All rights reserved. ROCKETFISH is a trademark of Best Buy Enterprise Services, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com