

Safety

- **Warning:** Some medical studies have suggested that long periods of repetitive motion may be linked to certain types of physical discomfort or injuries. You should take frequent breaks during game play. If you feel aching, numbness, or tingling in your arms, wrists, or hands, consult a qualified health professional.
- **Warning:** The starter kit contains small pieces that may pose a choking hazard to small children. Keep the kit components away from small children.
- **Warning:** To prevent fire or shock hazard, do not expose the starter kit to rain or moisture.
- **Warning:** Never insert objects into the starter kit components, because they may touch dangerous voltage points or short out parts, which can result in fire or electrical shock.
- **Caution:** Do not disassemble or damage any of the starter kit components. Refer all servicing to qualified personnel.
- **Caution:** Keep the starter kit out of direct sunlight for extended periods of time.
- **Caution:** Use the starter kit only as instructed. Read all instructions before operating.
- **Caution:** The wall adapter (AC) must not be used to power the charger if the plug or cord is damaged. The plug must be easily unplugged from the wall outlet.


Package contents

- Dual charge station (for PS3 controllers only)
- Dual charge station AC power adapter
- Bluetooth headset
- Headset ear clip
- Headset USB charge cable
- Console stand (for PS3 2nd generation "slim" console model only)
- *Quick Setup Guide*
- **Not included:** PS3 controllers


Using the dual charge station

Charging your controllers:

- 1 Plug the AC power adapter into any available AC power outlet.
- 2 Connect the AC power adapter's USB connector to the dual charge station.




- 3 Attach the Sony PS3 controllers to the charge station. The blue charging indicator on the charge dock lights up when the controller is connected.



Indicator status:

- The LED indicators on the front of the controllers flash while charging and turn off when fully charged.
- The blue LED indicator on the charge dock remains on while a controller is attached to the charge station, regardless of the controller's recharging status.

Using the Bluetooth headset



1	Multifunction button	4	Volume up and down
2	Indicator	5	Clip
3	Microphone	6	Charging connector

The Bluetooth headset must be fully charged before using it for the first time.

To charge the headset:

- 1 Connect the charge cable to the charging connector on the headset.
- 2 Connect the charge cable to the PS3 or any standard USB port. The indicator on the headset turns red while charging and turns blue when fully charged.
- 3 Disconnect the charge cable from the headset when the headset is fully charged.


To pair the headset with the Playstation 3:

- 1 Make sure that the Bluetooth headset is turned on.
- 2 On the Playstation 3, open the Main menu, then go to **Settings, Accessory Settings, Manage Bluetooth Device**, then locate the Bluetooth device settings.
- 3 Press and hold the multifunction button on the Bluetooth headset until the headset beeps and the headset's indicator flashes red and blue.
- 4 On the Playstation 3, select **Yes** to confirm, then select **Start Scanning**.
- 5 When you're asked to verify the Bluetooth headset model, select **SX-919i** from the Bluetooth devices list.
- 6 Select **Enter** to confirm, enter the pass key (**0000**), select **Start**, then select **OK** to confirm the connection.
If the pairing is unsuccessful, repeat the previous steps until successful.
- 7 From the Playstation 3's Main menu, select **Settings**, then select **Accessory Settings**.
- 8 Select **Audio Device Setting**, then select **SX-919i** from the Input device list.
- 9 Select **SX-919i** from the Output device list, then select **OK** to confirm the setting.

Using the console stand

- 1 Place the console stand on a smooth, flat surface.
- 2 Insert the Playstation 3 console vertically onto the console stand.

NOTE: This stand is designed to only work with 2nd generation PS3 "slim" consoles



Legal notices

FCC Part 15

This device complies with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada ICES-003 statement

This Class B digital apparatus complies with Canadian ICES-003.

90-day limited warranty

Visit www.rocketfishproducts.com.

Contact Rocketfish:

For customer service please call 1-800-620-2790

www.rocketfishproducts.com

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645

© 2010 BBY Solutions, Inc.

All rights reserved. ROCKETFISH is a trademark of BBY Solutions, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

ENGLISH 09-1170

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>