

## USB Cradle – User Manual (version 7 – Samsung i900 Omnia)

### Specification:

- Charge your device via USB or A/C charger
- Device dock securely in cradle
- Synchronizes your device with PC / notebook computer
- Supports hi-speed USB 2.0 data transfer
- Includes a 110-240v A/C power input with LED indicator for fast charging
- Includes a USB cable that synchronizes and charges your device without an A/C adaptor cable
- 1-year warranty

### Quick Guide:

#### To Sync your device with your computer:

- Put your device into the cradle, connect the cradle to your computer by the USB cable ( to keep charging, please connect the AC charger at the same time )

#### To charge your device:

- Put your device into the cradle, connect the cradle by an AC charger  
*(as different PDA/smartphone model requires different AC power level, please use our AC charger. Otherwise, please consult your supplier before using the AC charger)*

#### To charge your spare battery: (only available for cradle with spare battery charging slot)

- Put your spare battery into the spare battery charging slot, connect the cradle by an AC charger  
*(as different PDA/smartphone model requires different AC power level, please use our AC charger. Otherwise, please consult your supplier before using the AC charger)*

## **LED Indication:**

### **USB sync / charge cradle:**

Blue LED indicator is on when:

1. USB cradle is connected by USB cable to your computer
2. USB cradle is connected by AC charger (only)

### **USB sync / charge cradle with spare battery charging slot (2 LED indicators):**

When cradle is connected by USB (to computer):

1. Both device and 2<sup>nd</sup> battery are not in the cradle:  
"device light indicator": blue color  
"spare battery indicator": no signal
2. With device in the cradle (2<sup>nd</sup> battery not in the spare battery charging slot):  
"device light indicator": blue color  
"spare battery indicator": no signal
3. When 2<sup>nd</sup> battery is in the spare battery charging slot:  
"device light indicator": blue color  
"spare battery indicator": no signal

When cradle is connected by AC charger (only):

- 1 Both device and 2<sup>nd</sup> battery are not in the cradle:  
"device light indicator": blue color  
"spare battery indicator": green and red color interchange flashing
2. With device in the cradle (2<sup>nd</sup> battery not in the spare battery charging slot):  
"device light indicator": blue color  
"spare battery indicator": green and red color interchange flashing
3. When 2<sup>nd</sup> battery is in the spare battery charging slot:  
"device light indicator": blue color  
"spare battery indicator": light indicator change to red (when charging) and when it is full charge, it changes to green

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>