

ECO-i™ Submittal Data



Building Life.

APR-RZP224BAB Heat Recovery: Indoor Units

Job Name: _____
 Location: _____
 Engineer: _____
 Submitted to: _____
 Submitted by: _____
 Reference: _____


Approval: _____
 Date: _____
 Construction: _____
 Unit #: _____
 Drawing #: _____



APR-RZP224BAB

Use: For indoor unit (Capacity after distribution joint is 76.400 BTU/h or less.)

Example: (F below indicates inner diameter. Ⓢ below indicates outer diameter.)



Unit: in.

Size	Part A	Part B	Part C	Part D	Part E	Part F	Part G	Part H	Part I
Inch	1 5/8"	1 3/8"	1 1/8"	1 1/8"	7/8"	3/4"	5/8"	1/2"	3/8"



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>