

The new Sony Ericsson K790 Cyber-shot® phone – seeing is believing

Sony Ericsson has teamed up with Cyber-shot®, one of the most elite names in digital photography. The K790 represents the next generation of camera phones. It has all the intuitive features and easy navigation you've come to expect from a Sony Ericsson phone. But as a camera, it provides a stunning 3.2 megapixels with autofocus, built-in Xenon flash and BestPic™ technology. All these remarkable features mean you only need one digital camera – the one on your phone.

The Sony Ericsson
K790 brings camera
quality to a mobile
phone so you never
miss a shot

Digital camera quality on your phone

Images you shoot with the K790 produce enough quality to print out at 8 x 10 size and then frame, or use as high-quality backgrounds on your PC. The 3.2 megapixels provides high resolution, and the autofocus lets you capture clarity without thinking.

Capture people in their best light

Don't miss out on photo opportunities at night or in poor light. The K790 has a true Xenon flash just like a real camera. Combined with red eye reduction, your photos can come out looking great, even in the dark.

Find your best shot

With BestPic[™] technology, the K790 starts snapping as your finger touches the button, and by the time you fully press, it's already taken four shots. Then it takes another four afterwards giving you a total of nine shots to choose from. Select the ones you like and throw the rest away.

Printing your photos with ease

For printing, you can simply connect the phone directly to a PictBridge[™]-compliant printer via the included USB cable or connect wirelessly using Bluetooth[®] technology.





Download from Www.Somanuals.com. All Manuals Search And Download.



- 3.2 megapixel camera lens with autofocus
 - Camera Active lens cover
 Open the cover, camera functionality starts automatically
- 3 Camera key
 Press and hold to shoot photos
- Photo keys Top Key – selects scenes (Twilight, Landscape, Portrait etc.) Bottom Key – Shoot mode (BestPic[™], Panoramic etc.)
- Xenon flash
- PictBridge™ Transfer images from the phone via USB cable directly to a printer, without a computer or photo editing software
- Navigation key
 Press up, down, left or right to navigate the menus. Press
 the center to select highlighted item
- 8 Adaptive Softkeys
 Softkeys change for each menu

- 9 Back key Press to go back one step in menu. Press and hold to return to the main screen
- Volume keys
 Press up/down to raise or lower the volume, mute the ringer on incoming calls or activate Voice Dial, also in camera mode acts as the zoom function
- Media player
 Press pause/play to control music listening
- 12 * key
 In text mode, press and hold to turn T9 on and off, tap
 to switch upper and lower case text
- # key
 From standby, press and hold for Silent Mode. For text entries, press to add a space
- Memory Stick slot
 Accepts any Memory Stick Micro™ (M2™)
- Power key
 Press and hold to turn phone on/off. In standby, tap to access quick shortcuts & Profiles menu

Selling Tips

Cyber-shot[™] Camera Quality

Have a few pictures shot with K790 made into 8×10 prints. Have the prints on hand in your store to show your customers the resolution capability of K790. To preserve your showroom 8×10 's, you might want to laminate them. After explaining autofocus, put the K790 in your customer's hand and let them try it for themselves.



BestPic™

BestPic[™]

Pick the best, delete the rest.

Ask your customer if they have children or pets. People especially love talking about their children. It's a natural lead-in to talking about the BestPic™ feature.





Xenon Flash

Light your way!

Hold up another camera phone and turn on the camera light. Then hold the K790 up and take a photo using the flash. Though your store may be too brightly lit to show a difference in the picture, your customer will still be able to see the different quality of light coming from the two products.



with Xenon flash in poor light

Image Stabilizer

Stay focused while on the move!

Switch the camera to video mode and zoom in on a far away object through the store window. Show customers the phone screen and demonstrate how stable the image is compared to a typical camera phone. Also be sure to mention that image stabilization feature works in the regular camera mode, and might be good for taking photos while moving, or in a car.



PictBridge[™]

Pictures worth saving are pictures worth printing.

Ask your customer how they usually print photos. Chances are that their current method, whether done from PC, photo lab, or online service, is more complicated than PictBridge™ with K790. Perhaps your store will want to invest in an inexpensive PictBridge™-capable photo printer. After all, a picture is worth a thousand words.

How to use Autofocus

Frame your subject and press and hold the camera key half-way down. You will see the white framing square appear in the center of the screen. When the square changes color to green, press the camera key all the way down and take the shot.

You can set autofocus for different focus ranges. In camera mode, select Settings>Autofocus>select Auto, Macro, or Infinite.

How to activate BestPic[®]

In camera mode select Settings>Shoot Mode>BestPic[™] or press the shoot mode key.

How to use the Xenon Flash In camera mode select Settings>Flash and select >Auto or Red Eye reduction.

How to use PictBridge[™]

Connect K790 with USB cable to the printer. USB Connection appears on K790 screen, select the Print option. You will see a message indicating that PictBridge™ is ready for you to select the picture you want to print.

K790 Menu Map

The K790's menu system is controlled by the NAVIGATION KEY, BACK KEY and SOFTKEYS. The main menus are shown as icons on a desktop. To navigate to the icon desktop, press the NAVIGATION KEY to enter the main menu. Pressing the Navigation Key allows you to move down, left, and right through the icons, tabbed menus, and submenus. Press down on the NAVIGATION KEY to select highlighted items.

Tap the BACK KEY to go back one level in the menus. Press and hold the BACK KEY from any level of the menu to return to the standby screen.

The SOFTKEY functions vary by menu and are displayed as text labels on the bottom of the display. To use the SOFTKEY functions, press the left or right key that is under the text label on the screen. The NAVIGATION KEY can also function as SELECT.



File Manager

Items such as pictures, videos, sounds, themes, and games are saved as files in folders similar to those found on computers. All files that the phone cannot recognize are saved in the "Other" folder.

Pictures

Sounds

Videos

Themes

Games Applications

Others



Media Player

The Media Player converts the phone into a portable audio and video player.



Messages

Write New

Inbox

Email

RSS Reader

Drafts

Outbox

Sent Messages

Saved Messages

Settings



Connect

Bluetooth

IR

USB

Synchronization

Device Management

Mobile Networks

Data Comm

Internet Settings

Streaming Settings

Accessories



Sounds & Alerts

Ring Volume Ringtone

Silent Mode

Increasing Ring

Vibrating Ring

Message Alert

Key Sound



Display

Wallpaper

Themes

Startup Screen

Screen Saver

Clock Size

Brightness

Sleep Mode Clock



Settings General

Profiles

Time & Date

Language

Voice Control

Phone Status

Shortcuts

Master Reset

Update Service

New Events

Flight Mode

Security

Setup Wizard



Calls

Forward Calls Manage Calls

Time & Cost

Show or Hide Number

Handsfree



Organizer

Calendar

Tasks

Notes

Alarms

Timer

Stopwatch

Calculator

Code Memo

Applications

Synchronization



Contacts

Options

Speed Dial

My Business Card

Groups

SIM Numbers

Special Numbers

Advanced

New Contact



Entertainment

Games

MusicDJ

Record Sound

VideoDJ

PhotoDJ

Remote Control

Demo Tour



Internet Services

Contains Internet shortcuts and bookmarks. Also shows direct links to the Internet services predetermined by your vservice provider.

vaei vide providei.

Accessories

Get the most out of your K790 with these Sony Ericsson accessories.



Memory Stick Micro[™] (M2[™])

This tiny, upgradeable memory stick is just a fraction of the size of most other memory sticks available. It comes in three different capacities to easily store all your favorite pictures, music and video clips on your phone. Choose between 256MB, 512MB or even 1GB.



Bluetooth® Stereo Headset HBH-DS970

Turn your mobile phone into a true music player by wirelessly playing tunes through your cordless Bluetooth® Stereo Headset HBH-DS970. Not only will your music be streamed in superb quality sound to your headphones, but when a call comes in, after a quick glance at the display hanging around your neck, the music mutes and you can use the buttons on the earpiece to take or reject the call.



Bluetooth® Car Handsfree HCB-100

With a Bluetooth® Car Speakerphone HCB-100 you can keep your eyes on the road ahead and still take, make and reject calls. Extremely safe and straightforward to use at the wheel, the HCB-100 will last the distance for the most arduous journeys. Up to 20 hours talk time with a standby time of up to 25 days is high performance defined.



Bluetooth® Car Handsfree HCB-700

The HCB-700 makes handling calls truly handsfree! Just turn the ignition key and you're instantly connected to your phone, completely hands-free. The HCB-700 features voice-digit dialing and a display mounted at eye-level revealing your incoming calls. Staying handsfree while driving has never been easier.

Technical Specifications

System	Triple band GSM/GPRS 850/1800/1900 and EDGE
Memory	Internal: Up to 64MB, External: Removable Memory Stick Micro™ (M2™)
Length	4.1 inches (105 mm)
Width	1.8 inches (47 mm)
Thickness	0.9 inches (22 mm)
Weight	4.1 oz
Screen	240 x 320 pixels, 2 inches
Color	Velvet Black
Talk Time	Up to 7 hours
Standby Time	Up to 350 hours
Supported Media File Formats	MP3, MPEG4, M4A, 3GP, WAV
*Kit Contents	Stereo Portable Handsfree, USB Cable, PC tools and software
	and Adobe Photoshop Album SE 3.0

^{*}Kit contents may vary by service provider



Product Support:

Sony Ericsson Retail Support Website: www.sonyericsson.com/retail/us Sony Ericsson Toll-Free Retail Support: 1-866-866-SEMC (7362)

Sony Ericsson Toll-free Consumer Support: 1-866-SONYERICSSON (766-9374)

www.sonyericsson.com



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com