

# URC6131 TiVo Keymap

VCR/2011-2013: Sony TiVo

Unique Codes 1-3

VCR/2020-2028: Philips

Unique Codes 0-8

Buttons on this sheet that are grayed out are NOT	
Button	Function (@=Key Move)
0	num 0
1	num 1
2	num 2
3	num 3
4	num 4
5	num 5
6	num 6
7	num 7
8	num 8
9	num 9
<i>vol up</i>	
<i>vol down</i>	
<i>mute</i>	
channel up	Channel/Page Up
channel down	Channel/Page Down
power	standby
enter	enter
tv/vid	VCR Bypass
prev	Enter/Jump
menu	menu
guide	Guide
up arrow	up arrow
down arrow	down arrow
left arrow	left arrow
right arrow	right arrow
select	select
angle/sleep	Live TV/Guide
<i>@ pip</i>	
info	display
<i>@ swap</i>	
<i>@ move</i>	
play	play
pause	pause
rewind	rewind
fast fwd	fast fwd
stop	Slow Motion
record	record
exit	clear
<i>surround</i>	
audio/CC	Aux Bypass
<i>+ 100</i>	
<i>fav/scan</i>	
<i>device button</i>	
advance	Advance
replay	instant replay
next track	Window
prev track	Exit
PVR menu	Tivo-HDVR2
subtitle	List
slow	Slow Motion
thumbs up	Thumbs Up
thumbs down	Thumbs Down

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>