



MODEL# SVMR, SVMB

Stinger voltmeter, 3-digit display w/ turn-on circuit

Wiring Schematic

- Red (power)** - wire to +12V constant source at location of desired reading
- Black (ground)** - wire to chassis ground
- Blue (trigger)** - wire to a +12V switched source (ignition) or to radio remote turn-on

Cover Removal

depress both tabs located on either side to remove cover

Mounting Options



- Option 1** - can be secured by (2) mounting holes located under cover with supplied screws
- Option 2** - can be fastened by a piece of double sided tape
- Option 3** - can be custom mounted by two thin strips of double side tape on front cover then back mounted for a more custom look

Voltage Adjustment

test voltage at red and black wires on **SVMR /SVMB** with a small phillips or slotted screwdriver adjust meter to match reading from previous test.

counterclockwise - voltage increase

clockwise - voltage decreased



Stinger® 13160 56th Court Clearwater, FL 33760
Technical Support 800.477.2267 ext. 230
stingerelectronics.com

Download from www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>