







PARTS – LCD TVs			
SVA Model #	Part Name	Image	Part #s
VR-20	Main Board		P-MB VR-20
VR-20	Power Cord		P-CP VR-20
VR-20	Adapter (12V 84W)		P-AD VR-20
VR-30	Adapter (12V 48W) (24V 120W)		P-AD VR-30
VR2600W VR3200W	Power Board		P-PB VR2600W
VR-2600W VR-3200W	Power Cord		P-CP VR-2600W P-CP VR-3200W

** Subject to change without notice. All rights reserved.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>