



SUBARU

SUBARU IMPREZA

**INSTALLATION
INSTRUCTIONS AND USER
MANUAL**


PART NUMBER: H001SFG310

DESCRIPTION: "Speed Dial" Update CD



IMPORTANT: Please store these installation instructions and user manual with the vehicle's owner manual. If the vehicle's battery is replaced or the battery cables are disconnected, this update must be re-run to restore Speed Dial functionality.

**HANDS FREE UPDATE
CONTENTS:**



1X

**TOOLS REQUIRED:
NONE:**

**PART NUMBER:
H001SFG310**

Issue: 01

Date: 12/20/07

SUBARU OF AMERICA


PAGE 1/3

1




Turn ignition switch to accessory power position. On map screen, press "Agree"

2



Press "Tilt" button on bottom right of head unit. On screen, press MAP button. When prompted, push yes.

3



Remove MAP disk. Place Update CD in MAP slot. **DO NOT** install the Update CD into the DVD/CD Slot.

4




The Data reading will begin automatically and will take 60-90 sec.

5




When the update is completed, the screen will display "Disc is not a MAP DVD".

6



Press "Tilt" button on bottom right of head unit. On screen, press MAP button. When prompted, push yes.

7



Remove Update CD. Place Map Disk in MAP slot. **DO NOT** install the Update MAP disk into the DVD/CD Slot.

8



The update can be confirmed by going to the navigation menu and pushing the "Version" icon.

9



The Version should be 6300 or higher.

USER MANUAL ADDENDUM: This addendum includes user manual information for the Speed Dial function, which is added to the navigation system with the update CD.

Making a phone call from the Speed Dial

It is possible to select a phone number from the Speed Dial registered with the in-vehicle equipment to make a phone call.

NOTE

To use the Speed Dial, the phone number needs to be registered onto Speed Dial beforehand. (See page 218)

- 1 Press the **MENU** button.
- 2 Select  (Phone).



- 3 Select  (Speed Dial).



- 4 Select the name or phone number of a person to whom you want to make a phone call.

You have a phone call. Speak over the phone.



When the phone call is over, hang up the phone.




Editing the Speed Dial setting

Adding the phone number to the Speed Dial memory

It is possible to add the phone number from the Phone Book to Speed Dial memory.

NOTE

To add the phone number to the Speed Dial memory, the phone number needs to be registered onto Phone Book beforehand. (See page 201)

- 1 Press the **MENU** button.
- 2 Select  (Phone).




- 3 Select  (Speed Dial Settings).



- 4 Select  (Add).



- 5 Select a name on a Phone Book whom you want to add to the Speed Dial memory.



- 6 Select a phone number which you want to add to the Speed Dial memory.



- 7 Select a registering position where you want to add to the Speed Dial memory.



- 8 If you are going to overwrite the Speed Dial memory, select **Yes** (Yes) to finish the adding.



Deleting the phone number from the Speed Dial memory

It is possible to delete the phone number from the Speed Dial memory.

- 1 Press the **MENU** button.
- 2 Select **Phone** (Phone).



- 3 Select **Speed Dial Settings** (Speed Dial Settings).



- 4 Select **Delete** (Delete).



- 5 Select a Speed Dial memory which you want to delete.



6 Select **Yes** (Yes).



8 Select **Yes** (Yes).



7 If you need to delete all memories from Speed Dial, select **Del.All** (Delete all) on step 4.



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>