

A Easy Set Up Components

DVR4-I300 Unit

BNC to RCA Cable

Power Adapter Cable

DVR Power Adapter

Remote Control

Cameras and Accessories Optional

C Connecting the DVR to TV

- 1 Connect the RCA end of the RCA to BNC cable to the back of the TV INPUT socket
- 2 Connect the BNC plug end of the cable to the top VIDEO INPUT socket on the back of the DVR
- 3 Tune your TV to the correct INPUT - this is sometimes labelled A/V, input, source, L1, L2, etc. - consult TV manual for details

Back of TV

Back of DVR

B Camera Connections

- 1 Connect the camera cable's BNC socket & DC socket to the BNC plug & DC plug on the extension cable.
- 2 Connect the other end of the BNC plug of the extension cable to the camera connections on the back of the DVR.
- 3 Connect the DC power sockets on the extension cables to the power splitter's DC plugs.
- 4 Connect the power splitter's DC socket to the DC plug on the power supply.
- 5 Plug in the DVR and camera power adapter to power outlets.

Cameras Optional

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>