

A Package Contents

B Connection of DVR to your TV

1. Connect BNC Video cable to Output on DVR
2. Connect Yellow Video cable to Video 'Input' on TV
3. Tune TV to 'Input' using TV remote

C DVR & Camera Connections

1. Connect camera to extension cable
2. Connect extension cable to back of DVR
3. Connect extension cable to splitter
4. Plug in DVR Power & Camera Power

Cameras 3 & 4 Optional

SPARE

5 Way Splitter

Camera Power Supply

Front of DVR



Setting the Record Schedule

```

1 MAIN MENU
CAMERA SELECT 1234
RECORD SELECT 1234
RECORD MODE EACH
RECORD FRAMERATE 25
VIDEO QUALITY NORMAL
> RECORD SCHEDULE
SUB MENU
HARD DISK SETUP
MOTION SETUP
RESTORE FACTORY DEFAULT

PRESS (UP, DOWN), THEN (SELECT)
PRESS (MENU) TO EXIT
    
```

1. Push the **MENU** button to bring up the menu
2. Move the cursor to 'Record Schedule' using the **DOWN** arrow and press **SEL**

```

2 RECORD SCHEDULE
> AAAATAA---AAATTTTTTTTTTTT<
  | | | | | | | | | | | | | | | |
  0 3 6 9 12 15 18 21 24

T = Normal Record
A = Motion Record
- = No Record
    
```

1. Move the cursor using the **UP & DOWN** arrow
Press the **SEL** button to change the record mode
- Note:** Schedule based on 24 hour clock

Camera & Record Selection

```

MAIN MENU
CAMERA SELECT 1234
RECORD SELECT 1234
RECORD MODE EACH
RECORD FRAMERATE 25
VIDEO QUALITY NORMAL
> RECORD SCHEDULE
SUB MENU
HARD DISK SETUP
MOTION SETUP
RESTORE FACTORY DEFAULT

PRESS (UP, DOWN), THEN (SELECT)
PRESS (MENU) TO EXIT
    
```

Ensure 'Camera Select' and 'Record Select' show 1234 to record all 4 cameras

Setting the Date & Time

```

1 MAIN MENU
CAMERA SELECT 1234
RECORD SELECT 1234
RECORD MODE EACH
RECORD FRAMERATE 25
VIDEO QUALITY NORMAL
> RECORD SCHEDULE
SUB MENU
HARD DISK SETUP
MOTION SETUP
RESTORE FACTORY DEFAULT

PRESS (UP, DOWN), THEN (SELECT)
PRESS (MENU) TO EXIT
    
```

Push the **MENU** and using the arrows move the cursor to 'Sub Menu' and press **SEL**

```

2 SUB MENU
AUTO RECORD OFF
PASSWORD SETUP OFF
PICTURE CHANGE OFF
> TIME SETUP

PRESS (UP, DOWN), THEN (SELECT)
PRESS (MENU) TO EXIT
    
```

Move the cursor to 'Time Setup' and press the **SEL** button

```

3 TIME SETUP
V
2007/08/13 23:56:39

PRESS (UP, DOWN), THEN (SELECT)
PRESS (MENU) TO EXIT
    
```

- A. Use the **UP** and **DOWN** arrows to move the cursor
- B. Press the **SEL** button to increase the chosen value by 1
- C. Push **MENU** to exit the setup

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>