

*Tekkeon*

myPower™

**FM**

Mobile FM Transmitter  
for iPod

MP1100-50  
User Guide







## USER GUIDE

### Contents

---

Overview .....	2
Connecting myPower FM .....	2
Playing iPod Music on an FM Radio/Stereo .....	3
Troubleshooting .....	4
Limited Warranty .....	4
Customer Support .....	5

## Overview

myPower™ FM—the FM transmitter designed specifically for use with myPower for iPod—lets you play your iPod music on any FM radio. Designed for life on the go, myPower FM can be used at home, in your office, or in your car.

myPower FM simply snaps on to myPower for iPod. Once myPower FM is connected, just tune to any of the seven pre-set channels to listen to music from iPod directly on your FM radio or stereo.

myPower FM must be attached to myPower for iPod, which is made for iPod (3rd, 4th, 5th generation), iPod mini, and iPod photo.




## Connecting myPower FM

myPower FM simply snaps on to the bottom of myPower for iPod. As myPower FM draws minimal power from myPower for iPod, there is no need to charge myPower FM. However, the connected myPower for iPod must be charged.

### To connect myPower FM:

1. Move the myPower for iPod power switch to On.
2. Insert the two plugs on the top of myPower FM into the line out and USB ports on the bottom of myPower for iPod.
3. Press the two units together until they are firmly attached.



## To disconnect myPower FM:


1. Gently pull myPower FM from myPower for iPod.
2. Move the myPower for iPod power switch to Off to turn off the power.

## Playing iPod Music on an FM Radio/Stereo

myPower FM will play your iPod music on an FM radio or stereo within 15 feet of the iPod. You must first select the channel on myPower FM, and then select the same channel on your FM radio. The seven pre-set channels available on myPower FM are CH1, CH2, 88.1, 88.3, 88.5, 88.7, and 88.9. CH1 and CH2 are market-dependent channels. The default channels for these two selections are 87.7 (CH1) and 87.9 (CH2). The last channel in the bottom row is not used.

### To play iPod music on your FM radio:

1. When myPower FM is first connected to myPower for iPod, the unit will be set to CH1 (87.7), the default FM channel.
2. Place myPower FM near your FM radio (within 15 feet).
3. Turn on your FM radio and select 87.7 on your dial.
4. Turn on the connected iPod and play your music. *You will hear the music broadcast on your FM radio or stereo.*
5. If the reception on the selected channel is not clear, press the channel selector on the front of myPower FM to select the next channel. *An LED will light to indicate the channel selection. Each time you press the button, the selection will change, moving across the channels on the front of myPower FM from left to right, top to bottom.*
6. Change the FM radio station to the channel set on myPower FM.
7. Repeat steps 5 and 6 until you identify the optimum FM channel in your area.



# Troubleshooting

Issue	Solution
The reception is not clear on the channel.	<ol style="list-style-type: none"><li data-bbox="451 197 948 239">1. Be sure that the FM channel is the same as that selected on myPower FM.</li><li data-bbox="451 249 948 272">2. Select a different FM channel on your radio and myPower FM.</li></ol>

## Limited Warranty

The product enclosed herein is warranted to be free of operational defects for a period of one year from the date of purchase. In the event of a defect in operation during the warranty period Tekkeon, Inc. will replace the defective product when the owner returns all product contents. The limited warranty will be considered void if the unit is tampered with, subject to misuse, negligence or accidental damage, has been improperly serviced, or if the security seal is removed. This warranty is limited to replacement only and shall not cover any other damages. Any product returned to Tekkeon, Inc. with no fault found will be returned to the owner at the owner's expense.

To obtain warranty coverage, please complete and submit the enclosed registration card.

## Disclaimer of Warranties

Any user of this product does so at the user's own risk. To the maximum extent permitted by applicable law, Tekkeon, Inc. and its suppliers provide the hardware and any support services related thereto "as is" and with all faults; and hereby disclaim all warranties and conditions, whether express, implied or statutory, including, but not limited to implied warranties of merchantability, fitness for a particular purpose, non-infringement, lack of negligence or correspondence to description, except for those warranties specifically and expressly provided in the Limited Warranty.

With respect to the use of this product, in no event shall the company be liable for any loss of profit or any other commercial damage, including but not limited to special, incidental, consequential and other damages.

---

## Customer Support

If your product is in need of repair or replacement, please contact the Tekkeon Customer Support Center at:

Tekkeon, Inc.  
c/o myPower FM  
3002 Dow Avenue, #134  
Tustin, CA 92780  
888-787-5888 / 714-832-1266

[www.tekkeon.com](http://www.tekkeon.com)

Tekkeon, Inc. will issue a Return Merchandise Authorization (RMA) number for all repairs or exchanges.



***Tekkeon***

[www.tekkeon.com](http://www.tekkeon.com)

© 2005 Tekkeon, Inc.

All rights reserved. myPower is a trademark of Tekkeon, Inc. iPod is a trademark of Apple Computer, Inc., registered in the U.S. and other countries. Specifications are subject to change without notice.

Revision R2



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>