

# Smart Key<sup>™</sup>



© 2004 VTech Printed in China

91-64000-000 (R) Download from Www.Somanuals.com. All Manuals Search And Download.


nev are	er notice the look on your baby's face when they learn something w through their own discovery? These self-accomplished moments a parent's greatest reward. To help fulfill them, <b>VTech</b> <sup>®</sup> created <b>Infant Learning</b> series of toys.
chi toy and nu <b>Ini</b>	ese unique interactive learning toys directly respond to what ldren do naturally – play! Using innovative technology, these 's react to baby's interactions, making each play experience fun d unique as they learn age-appropriate concepts like first words, mbers, shapes, colors and music. More importantly, <b>VTech®'s</b> <b>Fant Learning</b> toys develop baby's mental and physical abilities inspiring, engaging and teaching.
Th des bes	<b>VTech</b> <sup>®</sup> , we know that a child has the ability to do great things. at's why all of our electronic learning products are uniquely igned to develop a child's mind and allow them to learn to the t of their ability. We thank you for trusting <b>VTech</b> <sup>®</sup> with the portant job of helping your child learn and grow!
Sin	ncerely,
You	ur Friends at <b>VTech®</b>
	learn more about <b>Infant Learning</b> and other <b>VTech®</b> toys, visit vw.vtech.com

# Introduction

# INTRODUCTION

Thank you for purchasing the VTech<sup>®</sup> Smart Key<sup>™</sup> learning toy.

The **VTech<sup>®</sup> Smart Key<sup>™</sup>** is an interactive electronic role-play toy for babies 6 months and up. The big chunky key is filled with learning and fun. The three brightly colored buttons take baby on adventures around the town through songs, phrases, sounds and melodies. Spin the roller ball to see the role-play puppy flip as the ball spins. The three beads reinforce the learning and provide tactile stimulation and exploration.



# **INCLUDED IN THIS PACKAGE**

- One VTech<sup>®</sup> Smart Key<sup>™</sup> learning toy
- One instruction manual
- WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.

## **GETTING STARTED**


### **BATTERY INSTALLATION**

- 1. Make sure the unit is turned OFF.
- 2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
- Install 2 new 'AAA' (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure the battery cover.

### **BATTERY NOTICE**

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not use batteries of different types.

Download from Www.Somanuals.com. All Manuals Search And Download.



- Remove batteries from the equipment when the unit will not be used for an extended period of time.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

# WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

# **PRODUCT FEATURES**

### 1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/OFF/ VOLUME CONTROL SWITCH to the ON (\*) position. To turn the unit OFF, slide the ON/OFF/VOLUME CONTROL SWITCH to the OFF ( $\bullet$ ) position.



### 2. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech<sup>®</sup> Smart Key<sup>m</sup> will automatically power-down after several seconds without input. The unit can be turned on again by pressing any button.

### 3. FABRIC ATTACHMENT STRAPS

The **VTech<sup>®</sup> Smart Key**<sup>™</sup> can be hung to any stroller or car seat. Simply connect the velcro straps together for fun play on-the-go!


# ACTIVITIES

- Slide the on/off/volume control switch to turn the unit on. You will hear a phrase followed by a short song and another phrase. The light will flash with the sounds.
- 2. Press one of the **three vehicle buttons** to hear a song related to the vehicle, the vehicle name, a fun phrase or a melody. The light will flash with the sound.
- 3. Press the **light-up button** to hear random sounds and phrases or random melodies. The light will flash with the sound.


Download from Www.Somanuals.com. All Manuals Search And Download.







 Shake the key ring to hear random melodies and sounds. The light will flash with the sounds.



5. If there is no input to the unit after approximately five seconds, you will hear "Where should we go today?" After another five seconds if there is still no input, you will hear "Let's go!" If there continues to be no input to the unit, it will automatically powerdown.

# **MELODY LIST**

- 1. On Top of Old Smokey
- 2. See-Saw, Margery Daw
- 3. Old MacDonald Had a Farm
- 4. The Wheels on the Bus
- 5. Yankee Doodle

# **CARE & MAINTENANCE**

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit is not in use for an extended period of time.

Download from Www.Somanuals.com. All Manuals Search And Download.

4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit on. The unit should now be ready to play again.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product warranty, please call **VTech**<sup>®</sup> at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

### IMPORTANT NOTE:

Creating and developing Infant Learning<sup>®</sup> products is accompanied by a responsibility that we at **VTech**<sup>®</sup> take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

### FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- · Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA. Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com