Modems

MOT202T

"Born-Again" UDS/Motorola 202T



- ▲ 2-wire half duplex or 4-wire full duplex private line operation
- ▲ 0 to 1200 bps data rate over unconditional lines and 1800 over high quality lines
- ▲ Anti-streaming
- ▲ Phase coherent, frequency shift keyed (FSK) modulation
- ▲ LED indicators
- ▲ Front panel rotary switch function selector
- ▲ Integral test features
- ▲ 12, 24, 48, 125VDC Power (Rack)
- ▲ 115VAC, 60Hz 220/240VAC 50 Hz power (Standalone)

Introducing the latest addition to the Telenetics° family of industrial grade, temperature hardened modems, the MOT202T is a pin-for-pin, form, fit and function replacement for the Motorola/UDS Model RM16M202T.

A must for industrial applications, the MOT202T (Standalone) features built-in diagnostic, antistreaming, multi-power inputs (115 to 240AC, 12 to 125VDC) and -40°C to $+80^{\circ}\text{C}$ operating range capabilities.

The modem operates over leased or dedicated, loaded or unloaded lines equal to or better than the ITU (formerly CCITT) M.1020/1025 or the BELL 3002 leased line services. It operates over point-to-point or multi-point polled systems and operates in full or half-duplex over 4-wire or 2-wire circuits.

The modem employs circuitry to prevent data and carrier detect errors over noisy lines. In multi-drop systems it is very common to have noise spikes and other harmful high frequency components caused by carrier turn-offs from other modems on the same line. The modem uses a combination of soft-carrier generation and soft-carrier detection in conjunction with a signal to noise ratio (SNR) detector to eliminate errors caused by line noise.

The MOT202T's anti-streaming capability prevents a modem from remaining in the transmit mode when the modem is not actively transmitting date. In addition, the MOT202T allows users to verify transmitted and received data via the diagnostic feature.

The MOT202T interchangeable design between the Universal Data Shelf multiple modem enclosure (RM16M series) and the standalone modem enclosure, enables the modem to be directly inserted in the Universal Data Shelf when the optional front panel is attached. Thus, data-communications facility can easily upgrade from front multiple standalone enclosures to a centralized rack without the expense and trouble of purchasing new modems.

Specifications*

FUNCTIONAL DESCRIPTION

General

Data Rate From 0 to 1800 bps (baud) depending

on transmission facility

Modulation Phase-coherent Frequency shift keying

(FSK).

Line Impedance 600 ohms ± 10 %, transformer coupled

and transient protected

Operation The modem operates at full duplex or

half duplex over four-wire lines, or half-duplex only over two-wire lines.

It operates asynchronously.

Receive and Space: Transmit Mark: Frequencies

2200 Hz 1200 Hz

Soft carrier: 900 Hz

Timings All settings and timings are controlled by jumpers on the modem

board.

Anti-streaming

Option to turn transmitter OFF after a selected time, even if Request To Send

is ON

Test Features The modem employs a rotary switch

that selects these test options:

· Data Mode

Self TestAnalog Loop back

Digital Loop backTest Pattern Transmit

Indicators The modem has LED indicators for the

following interface circuits: RTS, CTS, DCD, RD, TD, TM (Test Mode)

and PWR.

Receiver

Receiver Center 1700Hz ± 16 Hz Frequency Tolerance

.

Receiver Performance The modem receiver will operate with the following performance at 3002/C2 or

M1025 lines

1200Bps: B.E.R. equal to 1 x 10⁻⁵ with 12 db

signal to noise ratio

1800Bps: B.E.R. equal to 1 x 10⁻⁵ with 18 db

signal to noise ratio

Carrier Detect The received carrier detect threshold can Threshold be configured by the on-board jumper.

With jumper option:

DCD off \rightarrow on Carrier stronger than -30 dBm

0R

DCD off \rightarrow on Carrier stronger than -45 dBm

Hysteresis: Approximately 2 dB Receiver Dynamic 0 dBm to - 43 dBm

Range

Transmitter

Transmit FrequencySpace frequency: \pm 0.1 % Tolerances Mark frequency: \pm 0.1 %

Soft Carrier frequency: ± 0.1 %

Transmit Levels The modem transmit level is

selectable from 0 dBm to $-\ 14$ dBm in 2 dB steps by the on-board jumper S2-

1 to 8.

POWER REQUIREMENTS Rack & Standalone

AC Power 20 VAC RMS @ 150 mA, centertapped.

10 VAC RMS @ 225 mA. 115VAC & 220/240VAC

DC Power +15 VDC referred to gnd

-15 VDC referred to gnd. +8.5 VDC referred to gnd.

ENVIRONMENTAL SPECIFICATIONS

Operating Temperature -40 to + 85 degrees C Storage Temperature -40 to + 85 degrees C Relative Humidity 95%, non-condensing

INTERFACE SPECIFICATIONS

Analog Line edge An 8-pin edge connector located at connector the backend of the modem board. The

four signals routed to and from this connector are the analog transmit and receive pairs. Each pair are fully

differential signals.

Pin	Signal Name	Function
3	DTR	Receive Line for four wire systems
4	DTX	Transmit/Receive Line for two wire systems
5	DRX	Transmit/Receive Line for two wire systems
6	DRR	Receive Line for four wire systems

The maximum data rate for this modem is:

- ▲ 0 to 1200 bps (baud) over ITU M.1025 or BELL 3002 Basic services.
- ▲ 0 to 1800 bps (baud) over ITU M.1020 or BELL 3002 C2 conditioned lines.

Interface Compatibility

- ▲ The modem's line interface is compatible with the Bell Systems/WE 202 specifications and with the ITU V.23 recommendation.
- ▲ The modem's data interface is compatible with the RS 232C specifications and with the ITU V.24/28 recommendations.

Document #0071 0700

Telenetics is registered trademark of Telenetics Corporation. All other trademarks are the property of their respective holders. @2000

Power edge connector

A 12-pin edge connector located at the left side of the modem board. This connector supplies the modem board with power from the standalone case or the modem rack. Header H1 is located on top of P1.

Pin	Voltage	Function	Header H1 Pin
10	+ 15 VDC	Transformer 20 VAC	2
12	- 15 VDC	Transformer 20 VAC	1
8	Center Tap	Transformer center	tap 3 & 4
4	+ 8.5 VDC	Transformer 10 VAC	6
6	+ 8.5 VDC	Transformer 10 VAC	5
2	GND	Chassis Ground	n.c.

Digital Data edge connector

P2 is a 25-pin edge connector located at the backend of the modem board. The eleven signals routed to and from this connector are the RS 232 data interface signals.

Pin	RS 232 circuit	V.24 circuit	Function
1	AA	101	Protective Ground
2	BA	103	Transmitted Data
3	BB	104	Received Data
4	CA	105	Request To Send
5	CB	106	Clear To Send
6	CC	107	Data Set Ready
7	AB	102	Signal Ground
8	CF	109	Data Carrier Detect
9			+ 12 Volt.Test only
10			- 12 Volt.Test only
25			Analog Loop back

Modem Board Selective Jumper Options

Operational Settings

Ι)ata	a Carrier Detect Level
-	30	dBm
Ŀ	45	dBm

Transmit Level				
0 dBm				
- 2 dBm				
- 4 dBm				
- 6 dBm				
- 8 dBm				
- 10 dBm				
- 12 dBm				
- 14 dBm				

Line Connection	
2- wire	
4- wire	_

Turnaround Squelch
In
Out

Transmit Carrier
RTS Control
Constant Carrier

Local Copy Squelch
No Local Copy
Local Copy

Tes	t Generator Baud rate
1	
18	
37	
75	
150	

Chassis GND Option							
Chassis	GND	and	Signal	GND	not	connec	cted
Chassis	GND	and	Signal	GND	conr	nected	together

Modem Timing

RTS/C	TS Delay	
8 ms		
33 ms		
59 ms		
219 ms		-

Data Carrier	Detect Delay
6 ms	
23 ms	

	Squelch Time
83 ms	
159.6 ms	

Soft Carrier Timing
No Soft Carrier
8.3 ms
26.6 ms

Anti-Streaming Time
4 ms
7.6 ms
14 ms
28 ms
56 ms
Out

 $^{{}^{\}star}\mathsf{Specifications}$ are subject to change without notice

For more information on Telenetics' wireless products and services, call:

949-455-4000 or visit www.telenetics.com

 $\begin{array}{c} \text{Document} \ \ \#0071 \ \ 0700 \\ \text{Telenetics is registered trademark of Telenetics Corporation.} \end{array}$ All other trademarks are the property of their respective holders. \$\circ{0}{2}000 \end{tension}

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com