



Triax C-HD 415 CX
Digital Cable-TV set-top box
P/N: 305041



**Start
Use Now
Day to Day Use**

02-2009-B

Look for a more detailed user guide at www.com.com

Package content



Set-top box



Remote control




User guide



TRIAX - your ultimate connection

Start

Connection





Remote control

Standby	:	Power on/off
0-9	:	Numeric buttons
FAV	:	Favourites list
RECALL	:	Go back
R/Gr/Y/B	:	Coloured multifunctional buttons
CH+	:	Next channel / cursor upwards
CH-	:	Previous channel / cursor downwards
V-	:	Reduces volume / cursor left
V+	:	Increases volume / cursor right
OK	:	OK / Confirm
BACK	:	Quits menu or menu item/ Stops an operating Timer
EPG	:	Electronic Programme Guide
MENU	:	Displays main menu
INFO	:	Channel's reception data
🔇	:	Mute sound setting
TEXT	:	Switches to teletext
TV/R	:	Switches between TV and radio
AUDIO	:	Changes audio mode
SUB	:	Displays subtitles



Use now

1 Switch on TV and the set-top box





Switch on TV and set-top box using your remote control units.

2 Welcome




Follow the instructions displayed on the TV screen.

3 Select the language and country




4 Data for channel searching




In case your CATV operator has provided you with a USB stick, place the stick in the USB socket at the rear of the set-top box. Press the **OK** key to start the channel search. The information that the USB stick contains is used in connection with the channel search.

Note Even if you do not use a USB stick you have to press the **OK** key to start the channel search. Without the USB stick the channel search uses the settings specified below the menu item **Advanced search**.

5 Searching for channels




This process may take several minutes.



The result of the search is displayed. Press the **OK** key to continue.



6 Ready for use




Now the set-top box is ready for using.




Press **OK** to watch TV.

Day to Day Use

Switch the set-top box on or off




OR



Press the **Standby** key on the set-top box or the remote control to switch the set-top box on or off.

Select a channel




Use the **CH+ / CH-** keys or the numeric keys to select a channel.

Pressing the **OK** key displays the channel list. Use the **CH+ / CH-** keys to select a channel, press **OK** to select the channel.

You can use the **RECALL** key to change to the previously selected channel.


Adjust the volume



Use the **V+ / V-** keys to turn the volume up or down.


Use the **Mute** key to turn the sound off or on.

Switch between TV and radio



Use the **TV/R** key to switch between TV and radio. Press **OK** to open the TV list or the radio list

Show the information bar




Use the **INFO** key to show the information bar. The information bar displays info about: channel name, number, current and following event and time.

Pressing the **INFO** key twice displays more detailed information about the event. Press the key again to remove the information.

Note Every time you change channel the information bar is displayed automatically.

Display subtitles



Use the **SUB** key to display the subtitles if the programme offers the possibility. Using the **SUB** key you can browse the subtitle languages that the channel offers.

Note You can only select language if a channel offers subtitles in more languages.


View teletext

1 Switch to teletext



Use the **TEXT** key to display teletext.

2 Select the page



Use the numeric keys or the **CH+ / CH-** keys to select a page.

3 Return to TV



Use the **TEXT** key to switch off teletext.

Using Electronic Programme Guide (EPG)

1 View EPG



Using the **EPG** key you get an on-screen listing of events currently broadcast and the future broadcasts over the next seven days, depending on the broadcasters. Not all broadcasters provide this listing.

2 Sorting the information



Each of the coloured keys has a specific function in the guide:


Red: Sort the channels according to channel number.

Green: Sort according to the time of events.

Yellow: Sort according to the names of events.

Blue: Transfer an event directly to the timer.


3 Scrolling the listing of events



Use the **V-/V+** keys to scroll through the next seven days.

If you have sorted the list according to channels you scroll to a new channel every time you press the **V-/V+** keys.

4 Select an event



Use the **CH+/CH-** keys to select an event in the list.

Note If you press **OK** to the event you have selected you automatically start watching the event.

5 To view details of the event



Using the **INFO** key you can view the details of the event you selected in the list.

6 Return to TV



Use the **EPG** key to return to the event you were watching on TV.


Favourite channel lists



Using the **FAV** key you get easy access to your lists of favourite channels. Pressing the **FAV** key once displays which of the lists you used last time. Pressing the **FAV** key you can browse your lists of favourite channels.




Press the **OK** key to open the list of favourite channels.



Use the **CH+/CH-** keys to select one of your favourite channels. Press **OK** to confirm your selection and return to TV.

Note If you use the **CH+/CH-** keys, having selected a list of favourite channels and next a channel, note that you can only switch between the channels in the list of favourites. Press the **TV/R** key to get the total list of TV or radio channels.

Audio



Using the **AUDIO** key you get another audio language, depending on the broadcasters. Press the **AUDIO** key to scroll through the languages offered. Not all broadcasters provide this option.



TRIAx - your ultimate connection

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>