




COOKTOP PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)

30" GAS FREESTANDING
SELF CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1	W10110368	Literature Parts Use & Care Guide Tech Sheet
	W10116296	English
	W10116297	French
	9762997	Installation Instructions Anti-Tip Template
	9757142	English/Spanish
	9757143	English/French
	9762761	Safer Cooking Tips English
	9759133	French
2	3191905	Cap, Burner LF & RF Grey
	3191904	Black LR
	3191903	Grey RR
	3191901	Black RR
	3191899	Grey
	3191898	Black


Illus. No.	Part No.	DESCRIPTION
4	4455981	Burner LF & RF (12K)
	4455980	LR - RF(9K)
	4455979	RR(6K)
5	8272251	Cooktop White
	8272253	Black
6	8523854	Panel, Manifold White
	8523855	Black
7	8273104	Knob, Control (2) White
	8273103	Black

Illus. No.	Part No.	DESCRIPTION
8	8273108	Knob, AccuSimmer White
	8273107	Black
9	8273112	Knob, Powerburner (2) White
	8273111	Black
11	8522850	Grate, Burner (4) Grey
	8522851	Black
12	8522847	Grate, Center Gray
	8522846	Black
14	3400701	Screw
15	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1		Endcap, Left Hand
	W10009040	White
	W10009080	Black
		Endcap, Right Hand
2	W10009050	White
	W10009090	Black
2	8053505	Heat Shield, Lower


Illus. No.	Part No.	DESCRIPTION
3		Panel, Control
	9762091	White
	9762093	Black
	9762094	Stainless Model
4	9762078	Bracket, EOC Mount
5	9758080	Module, Spark
8	9756301	Cover, Upper
9	8053910	Shield, Heat
10	8273132	Cover, Lower
11	8523412	Bracket, Support

Illus. No.	Part No.	DESCRIPTION
12		Control, Range
	W10108180	White
	W10108190	Black
13	3196178	Screw
14	9757609	Nameplate
15	9762726	Brkt-Mntg, DSI
16	9762095	Brkt-Mntg, Console
19	8273564	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS


For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve	9	8273060	Nut (4)	20		Orifice, Burner
2		Burner Base	10	8273062	Screw (4)		8273064	Left Front
	8273700	Large (3)	11	3400228	Bolt		8273064	Right Front
	8273701	Small (1)	12	8054078	Burner, Broiler		8273065	Left Rear
3		Tubing, Burner	13	8053970	Spreader, Flame (Oven)		8273067	Right Rear
		W/Orifice	14	9758078	Burner, Bake	21	8053262	Spreader, Flame (Broiler)
	8273693	Left Front	15	9761959	Valve/Regulator	23	3196265	Screw
	8273694	Left Rear	16		Igniter	24	3196176	Screw
	8273696	Right Front		8054129	Broil	25	3196385	Screw
	8523506	Right Rear		9758079	Bake	26	3400016	Screw
4	8523402	Tubing (Manifold to Regulator)	17	8272222	Tubing (Broiler Fitting To Valve)	Following Parts Not Illustrated		
5	8523406	Harness, Igniter (W/Switches)	18	3186489	Fitting, Broiler		8523420	Spuds, LP Gas (Kit of 4)
6	8523793	Electrode (4)	19	8272403	Cover, Igniter			
7	8523407	Pipe, Manifold						
8		Valve						
	9757218	LF – RF – LR						
	8273004	Right Rear						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10012240	Flue Box	19	9758701	Spacer, Door	37	3196178	Screw
2	8272747	Shield, Flue	20	9757098	Back, Main	38	3196152	Screw
3	8273036	Burner Box	21	8522416	Seal, Oven	39		Screw
4		Panel, Side (2)	22	8053971	Brace, Main Back		3196166	White
	8053830	White-Textured	23		Retainer, Insul.		3196168	Black
	8053832	Black		9761449	Left Hand	40	3196176	Screw
5	9761490	Insulation		9761448	Right Hand	42	3196179	Screw
6	8523249	Brkt, Manifold Mtg	24	3196576	Clip, Panel (6)	44	3196177	Screw
7	9761512	Clip, Mounting	25	9757891	Cord, Power	45	3196168	Screw
8		Frame, Front (Not Serviced)	26	9757239	Rod - Dr Switch	46	3196560	Screw
9	3196037	Foot, Front (2)	27	9757262	Switch, Door	47	3196160	Screw
10	W10058460	Foot, Rear (2)	28	3196701	Light Socket Assy	INSULATION		
11	3195097	Bottom, Oven	29	311255	Bulb, Oven Light		8524099	Insulation, Wrap
12	8273902	Sensor, Oven	30	9761013	Latch, Door		8272613	Insulation, Vent
13	8053967	Baffle, Burner	31	W10078370	Rod, Latch		8272614	Insulation, Back
14	8053969	Shield, Heat	32	W10107820	Latch-Mtr			
15	8053968	Shield, Lower	33	9759785	Glide, Drawer			
16	9760314	Rail, Base (2)	34	W10031780	Screw			
17	9760407	Brkt - Mounting	35	3196169	Screw			
18	W10008830	Seal, Oven Flange						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1

(Designer White) (Black) (Stainless Steel)(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	3196817	Bracket, Drawer(2)
4	W10031790	Screw, For Stainless Steel And Universal Silver Models


Illus. No.	Part No.	DESCRIPTION
5	9757219	Handle Stainless Steel Model
	9762251	Universal Silver Model
6	9781235	Clip
7	W10022090	White Panel, Drawer Frnt
	W10022100	Black

Illus. No.	Part No.	DESCRIPTION
8	9755797	Panel, Drawer Frnt For Stainless Steel And Universal Silver Models
9	3196168	Screw
10	3196814	Rivet, Push (2) White
	3196813	Black
11	8053334	Spacer, Glide

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1
(Designer White) (Black) (Stainless Steel)(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	9761975	Trim, Top
	9762391	White
	9762394	Black
	9762394	Stainless Steel
	W10067560	Model
	W10067560	Universal Silver Model
2	3196164	Screw
3		Handle, Door
	9761982	White
	9761983	Black
	9761985	Stainless Steel
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	W10113759	Strap, Door
9	8272618	Insulation, Door

Illus. No.	Part No.	DESCRIPTION
10	9761493	Hinge, Door
	9761496	Stainless Steel
		And Universal
		Silver Models
11	9761357	Retainer, Insul.
12		Trim, Door Side
		Left Hand
	8523172	White
	8523171	Black
	W10113926	Gray
		Right Hand
	8523166	White
	8523165	Black
	W10113925	Gray

Illus. No.	Part No.	DESCRIPTION
13		Glass, Outer Door
	W10075980	White
	W10075990	Black
	9756435	Stainless Steel
		And Universal
		Silver Models
14	3196160	Screw
15	3196025	Clip, Door Glass
18	W10031780	Screw
19		Trim, Bottom
	8523175	White
	8523177	Black
	8523180	Stainless Steel
		Model
	W10067550	Universal Silver
		Model
21	3196794	Bracket, Window
22	3196165	Screw
23	9761517	Clip, Door Mntg(2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: SF367LXSQ1, SF367LXSB1, SF367LXSS1, SF367LXSY1

(Designer White) (Black) (Stainless Steel)(Universal Silver)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black 12 Ga. 150° c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242827	Wire, Yellow 14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
<u>INSULATION</u>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
	241430	Foil, Aluminum Oven (18" x 25')
	4396923	Pan - Broiler

ANTI-TIP KIT

W10017440	Anti-Tip Kit
-----------	--------------

WIRING HARNESS PARTS

W10082160	Harness, Main
8524207	Harness, Bake & Broil Ignitor
8523599	Harness, Wire (Cooktop Spark)
W10045060	Harness, Grnd DSI
3196174	Screw, Ground
3400964	Clip, Wire
3196896	Clip, Wire
313438	Clip, Harness
3196173	Screw
3195927	Wire, Tie
3196696	Clip, Harness

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>