




CONTROL PANEL PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White) (Black) (Biscuit)

MICROWAVE
HOOD
COMBINATION




Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8204919	Use & Care Guide
	8183731	Installation Instructions
	8204908	Tech Sheet
	8204929	Guide, Cooking (Label)
3		Panel, Control
	8205330	White
	8205331	Black
	8205332	Biscuit
4	8183821	Bracket, Control
5	4393744	Plate, Hinge
6	8183726	Microcomputer
8	4393346	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
2	8169545	Frame, Inner
3	4393913	Latch, Door
4	8185107	White
	8185109	Black
	8185108	Biscuit

Illus. No.	Part No.	DESCRIPTION
7	4393777	White
	4393782	Black
	8169642	Biscuit
8	4393833	Screw

Illus. No.	Part No.	DESCRIPTION
9	8205327	White
	8205328	Black
	8205329	Biscuit
10	8205324	White
	8205325	Black
	8205326	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


INTERIOR AND VENTILATION PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0

(White)

(Black)

(Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White) (Black) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	4393688	Reflector, Lamp
2	4393681	Lamp (2)
3	8169645	Filter, Charcoal
4	8169758	Filter, Grease
5	8185105	Plate, Bottom
6	8185210	Glass, Lamp
7	8184308	Holder, Glass
8	8205045	Guide, Air (Magnetron)
9	8183823	Cover, Fan
10	8204656	Switch, Micro (3)
11	8169438	Spring, Interlock (2)
12	8183824	Plate, Cam (2)
13	4393595	Support, Interlock (2)
14	8183825	Wheel, Fan
15	8184310	Housing, Fan
16	8185211	Motor, Fan
17	8185212	Chassis
18	8184311	Holder, Capacitor
19	8184664	Diode, H.V.
20	8169501	Capacitor, H.V.
21	8204844	Transformer, H.V.
22	8204657	Plate, Side (R)
25	8204658	Plate, Side (L)
26	4393709	Capacitor
27	8184312	Holder, Fuse
28	4393308	Fuse
29	8183703	Thermostat
30	8169474	Screw
31	4393835	Screw
32	4393472	Screw
33	4393833	Screw
34	8169478	Screw
35	8169479	Screw
36	4393839	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0

(White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8184638	Deflector, Air
2	8169557	Reflector, Air
3	8185083	Duct, Air
4	8204653	Bracket, Thermostat
5	8183697	Thermostat
6	8184745	Housing, Lamp
7	4393681	Lamp
8	8204694	Wheel, Fan


Illus. No.	Part No.	DESCRIPTION
9	8204751	Motor, Fan
10	8204754	Shield
11	8184624	Housing, Fan
12		Bracket, Fan (Not Serviced)
13	8169474	Screw
14	8169478	Screw

Illus. No.	Part No.	DESCRIPTION
15	4393830	Screw
16	4393874	Plate, Damper
17	8184129	Spacer, Copper Pipe
18	8169635	Cushion, Mtr
19	8169539	Holder, Lamp
20	8184404	Nut
21	4393808	Sensor, Humidity

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND TURNTABLE PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8205044	Motor, Stirrer
2	8205315	Stirrer Shaft/Blade
5	8184476	Cover, Inlet
6	8204662	Hook, Rack (4)
7	8184549	Nails/Bushings (5 of Each)
8	4393799	Turntable
9	8184102	Ring, Turntable


Illus. No.	Part No.	DESCRIPTION
10	4393861	Wheel, Plastic
11	8183949	Driver, Turntable
12	8183953	Motor, Turntable
13	4393756	Cover, Terminal
14	8184306	Magnetron
15	8183698	Thermostat
16	8169540	Holder, Connector (L)
17	8169705	Holder, Connector (R)
18	4393838	Screw
19	8169474	Screw

Illus. No.	Part No.	DESCRIPTION
20	4393831	Screw
21	4393832	Screw
23	8184485	Shield
24	8184585	Thermostat And Bracket
25	8184109	Spacer
26	8183741	Hinge, Upper
27	8183742	Hinge, Lower
28	8204691	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND INSTALLATION PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White) (Black) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8205317	Plate, Mounting
3	8183858	Door, Damper
4	8184313	Lid, Power Cord
6	8184898	Cord, Power
7		Case, Outer
	8169660	White
	8169661	Black
	8169664	Biscuit
8		Grille, Vent
	8183948	White
	8183851	Black
	8183852	Biscuit

Illus. No.	Part No.	DESCRIPTION
9	4393795	Grille, Holder
10	4393833	Screw
13	8169318	Rod
14	8169319	Latch Pivot
15	8169320	E-Ring
16	8185033	Catch
17	8169374	Spring
18	8169697	Plate, Damper

Illus. No.	Part No.	DESCRIPTION
Miscellaneous		
	8169659	Hardware, Installation
	8169704	Screw, Top Mountng
	8184781	Upper Template
	8183743	Wall Template
	8204725	Rack

ACCESSORY PARTS

8171337	Filler Kit (Black)
8171336	Filler Kit (White)
8171338	Filler Kit(Biscuit)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>