




CONTROL PANEL PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)

MICROWAVE
HOOD
COMBINATION




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------------|
| 1 | | Literature Parts |
| | 8204919 | Use & Care Guide |
| | 8183731 | Installation Instructions |
| | 8205611 | Tech Sheet |
| | 8204929 | Guide, Cooking (Label) |
| | | |
| 3 | | Panel, Control |
| | 8205330 | White |
| | 8205331 | Black |
| | 8205332 | Biscuit |
| 4 | 8183821 | Bracket, Control |
| 5 | 4393744 | Plate, Hinge |
| 6 | 8183726 | Microcomputer |
| 8 | 4393346 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------|
| 2 | 8169545 | Frame, Inner |
| 3 | 4393913 | Latch, Door |
| 4 | | Body, Door |
| | 8185107 | White |
| | 8185109 | Black |
| | 8185108 | Biscuit |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------|
| 7 | | Handle, Door |
| | 4393777 | White |
| | 4393782 | Black |
| | 8169642 | Biscuit |
| 8 | 4393833 | Screw |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|----------------|
| 9 | | Door, Complete |
| | 8205327 | White |
| | 8205328 | Black |
| | 8205329 | Biscuit |
| 10 | | Frame, Outer |
| | 8205324 | White |
| | 8205325 | Black |
| | 8205326 | Biscuit |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR AND VENTILATION PARTS


For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)

| Illus. No. | Part No. | DESCRIPTION |
|-------------------|-----------------|---------------------------|
| 1 | 4393688 | Reflector, Lamp |
| 2 | 4393681 | Lamp (2) |
| 3 | 8169645 | Filter, Charcoal |
| 4 | 8169758 | Filter, Grease |
| 5 | 8185105 | Plate, Bottom |
| 6 | 8185210 | Glass, Lamp |
| 7 | 8184308 | Holder, Glass |
| 8 | 8205045 | Guide, Air (Magnetron) |
| 9 | 8183823 | Cover, Fan |
| 10 | 8204656 | Switch, Micro (3) |
| 11 | 8169438 | Spring, Interlock (2) |
| 12 | 8183824 | Plate, Cam (2) |
| 13 | 4393595 | Support, Interlock (2) |
| 14 | 8183825 | Wheel, Fan |
| 15 | 8184310 | Housing, Fan |
| 16 | 8185211 | Motor, Fan |
| 17 | 8185212 | Chassis |
| 18 | 8184311 | Holder, Capacitor |
| 19 | 8184664 | Diode, H.V. |
| 20 | 8169501 | Capacitor, H.V. |
| 21 | 8204844 | Transformer, H.V. |
| 22 | 8204657 | Plate, Side (R) |
| 25 | 8204658 | Plate, Side (L) |
| 26 | 8205553 | Capacitor |
| 27 | 8184312 | Holder, Fuse |
| 28 | 4393308 | Fuse |
| 29 | 8183703 | Thermostat |
| 30 | 8169474 | Screw |
| 31 | 4393835 | Screw |
| 32 | 4393472 | Screw |
| 33 | 4393833 | Screw |
| 34 | 8169478 | Screw |
| 35 | 8169479 | Screw |
| 36 | 4393839 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------|
| 1 | 8184638 | Deflector, Air |
| 2 | 8169557 | Reflector, Air |
| 3 | 8185083 | Duct, Air |
| 4 | 8204653 | Bracket, Thermostat |
| 5 | 8183697 | Thermostat |
| 6 | 8184745 | Housing, Lamp |
| 7 | 4393681 | Lamp |
| 8 | 8204694 | Wheel, Fan |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------------|
| 9 | 8204751 | Motor, Fan |
| 10 | 8204754 | Shield |
| 11 | 8184624 | Housing, Fan |
| 12 | | Bracket, Fan (Not Serviced) |
| 13 | 8169474 | Screw |
| 14 | 8169478 | Screw |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------|
| 15 | 4393830 | Screw |
| 16 | 4393874 | Plate, Damper |
| 17 | 8184129 | Spacer, Copper Pipe |
| 18 | 8169635 | Cushion, Mtr |
| 19 | 8169539 | Holder, Lamp |
| 20 | 8184404 | Nut |
| 21 | 4393808 | Sensor, Humidity |
| 22 | 8169561 | Filter |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND TURNTABLE PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|----------------------------|
| 1 | 8205044 | Motor, Stirrer |
| 2 | 8205315 | Stirrer Shaft/Blade |
| 5 | 8184476 | Cover, Inlet |
| 6 | 8204662 | Hook, Rack (4) |
| 7 | 8184549 | Nails/Bushings (5 of Each) |
| 8 | 4393799 | Turntable |
| 9 | 8205778 | Ring, Turntable |
| 11 | 8205779 | Driver, Turntable |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------------|
| 12 | 8183953 | Motor, Turntable |
| 13 | 4393756 | Cover, Terminal |
| 14 | 8205791 | Magnetron |
| 15 | 8183698 | Thermostat |
| 16 | 8205792 | Holder, Connector (L) |
| 17 | 8169705 | Holder, Connector (R) |
| 18 | 4393838 | Screw |
| 19 | 8169474 | Screw |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|------------------------|
| 20 | 4393831 | Screw |
| 21 | 4393832 | Screw |
| 23 | 8184485 | Shield |
| 24 | 8184585 | Thermostat And Bracket |
| 25 | 8184109 | Spacer |
| 26 | 8183741 | Hinge, Upper |
| 27 | 8183742 | Hinge, Lower |
| 28 | 8204691 | Washer |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND INSTALLATION PARTS

For Models: GH4155XPQ1, GH4155XPB1, GH4155XPT1
(White) (Black) (Biscuit)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------|
| 1 | 8205317 | Plate, Mounting |
| 3 | 8205558 | Damper Assembly |
| 4 | 8184313 | Lid, Power Cord |
| 6 | 8184898 | Cord, Power |
| 7 | | Case, Outer |
| | 8169660 | White |
| | 8169661 | Black |
| | 8169664 | Biscuit |
| 8 | | Grille, Vent |
| | 8183948 | White |
| | 8183851 | Black |
| | 8183852 | Biscuit |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|----------------|
| 9 | 4393795 | Grille, Holder |
| 10 | 4393833 | Screw |
| 13 | 8169318 | Rod |
| 14 | 8169319 | Latch Pivot |
| 15 | 8169320 | E-Ring |
| 16 | 8185033 | Catch |
| 17 | 8169374 | Spring |
| 18 | 8169697 | Plate, Damper |

ACCESSORY PARTS

| | |
|---------|--------------------|
| 8171337 | Filler Kit-White |
| 8171336 | Filler Kit-Black |
| 8171338 | Filler Kit-Biscuit |

| Illus. No. | Part No. | DESCRIPTION |
|----------------------|----------|-----------------------------|
| Miscellaneous | | |
| | 8169659 | Hardware, Installation |
| | 8169704 | Screw, Top Mountng |
| | 8184781 | Upper Template |
| | 8183743 | Wall Template |
| | 8204725 | Rack |
| | 8205843 | Cavity Light Wire Assembly |
| | 8205844 | Fan Motor Wire Assembly |
| | 8205845 | Stirrer Motor Wire Assembly |
| | 8205846 | Hood Light Wire Assemblby |
| | 8205847 | H.V. Wire Assy |
| | 8205635 | Ground Wire Assy |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>