

LG **RUMOR²**



QWERTY Keyboard



Transferring Music



Playing Music



Bluetooth® Pairing



Checking Email



Sending an Instant Message



Taking a Picture

Quick Start Guide www.LGmobilephones.com/rumor2



LG

Life's Good

Getting to Know Your Phone



1. Volume Up/Down
2. Left Soft Key (Messages)
3. Menu/OK Key
4. Speakerphone Key
5. Talk Key
6. Camera Key
7. Voicemail Key
8. USB/Charging Port

9. microSD™ Port
10. Power/End Key
11. Clear & Back Key
12. Navigation Key
 - ▲ Text Message
 - ▼ My Stuff
 - < Scheduler
 - > My Albums

13. Right Soft Key (Contacts)
14. Headset Jack
15. Status Light
16. Speaker
17. Camera Lens



QWERTY Keyboard



1. Emoticons Key
2. Shift Key
Change Capitalization:
Abc (Sentence Case)
ABC (ALL UPPERCASE)
abc (all lowercase)
3. Function Key
To enter alternate characters (press twice to lock)
4. Space Key
5. Arrow Keys
6. Enter Key
7. Clear & Back Key
8. Right Soft Key
9. Left Soft Key



Transferring Music

Transform your mobile phone into a portable music player! Copy music, pictures, and other media files to a microSD card* and access them anywhere you go!

1. From standby mode and with the slide closed, insert a microSD card into the port on the right side of the phone.
2. Connect your phone to your PC using a USB cable.*
3. Select **Transfer Music (1)**.
4. Press the **MENU OK** Key for **Yes (1)**.
5. Your phone will appear as a removable disk under Windows® Explorer. Choose to open a folder to view the files on the memory card.
6. You can now drag and drop files from your computer onto the phone's microSD card.






*Requires microSD card and USB cable (sold separately).



Playing Music

Listen to your favorite songs with the integrated music player. You can listen to songs, podcasts, and other audio files without carrying around a separate MP3 player.





1. From standby mode and with a microSD card* containing music already inserted in the phone, press the **MENU/OK Key** to enter the main menu.
2. Select **Media Player (O)**.
3. Press the **Left Soft Key** to begin playing the highlighted song.
4. Use the side **Volume Keys**   to adjust the volume.



*microSD card sold separately.



Bluetooth® Pairing

Want to go wireless? Take advantage of *Bluetooth* wireless technology to connect your mobile phone to headsets, computers, and more.

1. Set your *Bluetooth* accessory into pairing mode.*
2. From standby mode and with the slide closed, press the  **Key** and select **Tools (#)**.
3. Select **Bluetooth (3)**, and then press the  **Key** for **Pair with Hands Free (1)**.
4. If *Bluetooth* wireless technology is off, you will be prompted to turn it on by pressing the **Left Soft Key**.
5. Once your device is found, highlight it and press the  **Key**.
6. Enter the PIN code (typically "0000") and press the  **Key** to pair.*
7. You can choose to customize the device's name. Press the **Left Soft Key** for **Save**.
8. Press the **Left Soft Key** to connect to your device.

*Refer to your *Bluetooth* accessory's user guide for information about initiating pairing mode and the passkey if asked (typically "0000"). If the accessory supports the headset/hands-free profile, your phone will automatically pair for you without having to input the passkey.



Note: *Bluetooth* accessories sold separately.



Checking Email

Access your inbox on the go. Send and receive emails without carrying around a bulky laptop.


1. Rotate your phone horizontally and open the slide.
2. Select **Email (3)**.
3. Press the **Right Soft Key** to begin the email wizard. Follow the steps in the wizard to set up your email.
4. Highlight the message you want to read and press the **ENTER Key**. To compose an email, press the **Left Soft Key** for **New**.



Sending an Instant Message



Enjoy fast, discreet communication with instant messaging. Access your favorite provider right from your phone.

1. Rotate your phone horizontally and open the slide.
2. Select **IM (4)**.
3. Press the **Left Soft Key** for **OK** to acknowledge the disclaimer.
4. Highlight your preferred IM client and press the **ENTER** **Key**.
5. Enter your login and password information using the QWERTY keyboard, and then press the **Left Soft Key** for **Sign In**.
6. Highlight a contact that is online, and then press the **ENTER** **Key**.
7. Type your message, and then press the **Left Soft Key** for **Send**.




Taking a Picture

Capture images with the 1.3 megapixel digital camera. Take advantage of customizable settings to create the perfect picture, and then send it to a friend.

1. You can take pictures with the slide open or closed. From standby mode and with the slide closed, press and *hold* the  **Key** to access the camera viewfinder.
2. Press up on the **Navigation Key** to view customizable options.
3. When you're ready, press the  **Key** to take the photo.
4. To send the picture to someone, press the **Left Soft Key** for **Send**.

Camera
Key



Optional Accessories



Stereo Headset



Vehicle Power Charger



Bluetooth Headset
(HBM-520)



Bluetooth Headset
(HBM-310)



Bluetooth Solar Speakerphone
(HFB-500)



Bluetooth Stereo Headset
(HBS-250)

Maximize your phone with these cutting-edge accessories at www.LGmobilephones.com/rumor2.

All materials in this guide including, without limitation, the design, the text, and any marks are the property of LG Electronics, Inc. Copyright © 2009 LG Electronics, Inc. ALL RIGHTS RESERVED. LG is a registered trademark of LG Electronics, Inc. RUMOR2 is a trademark of LG Electronics, Inc. Features and specifications are subject to change without prior notice. The use of non-LG accessories will void the warranty and may result in damage to the phone, the phone exploding, or other dangerous conditions. microSD™ is a trademark of SanDisk. The Bluetooth™ word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics MobileComm, U.S.A., Inc. is under license. Other trademarks and trade names are those of their respective owners. Unless otherwise specified herein, all accessories referenced herein are sold separately.



Mixed Sources

Product group from well-managed forests and other controlled sources and recycled wood content

www.fsc.org Cert no. XXX-XXX-XXX
© 1996 Forest Stewardship Council

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>