

Gigaware

Start Here

26-1429

Quick Start

## 2-Remote Recharge Station for Nintendo® Wii™

### Package contents



Charger




Battery pack (2)



USB cable




User's Guide




Quick Start

### ② Place in dock




Charge with or without the Wii remote.

### ① Replace the original battery pack



### ③ Connect power



Connect to a USB power source.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>