

CD Printing for Macintosh® OS X


Discus™ EP is included on your printer CD-ROM. This software allows you to print directly on ink-jet printable CDs and DVDs in Mac OS X.

Follow the instructions on the *Start Here* sheet to install your printer software, including Discus EP for Mac OS X.


Printing on CDs and DVDs in OS X

Make sure you use ink-jet printable CDs or DVDs, and burn the data, music, or video before printing. You might want to do a test print on an extra CD to check the image and positioning.

1. Follow the instructions in your *Printer Basics* book to load a CD or DVD into your printer. In Mac OS X, you will use Discus EP to create your design instead of EPSON® Print CD.
2. To start Discus EP, double-click the **Discus EP 2.72** file on your Macintosh.
3. Click the **CD/DVD** label, then select your printer.
4. Create your design with Discus EP, then click the **Print** tab. For more information on using Discus EP, select **Online Manual** from the Help menu.
5. Click the **Setup** button. You see the following Page Setup dialog box:



6. Select **Stylus Photo 900** or **Stylus Photo 960** from the Format for drop-down list. Make sure you don't select **Roll Paper** or another special feature.
7. Make sure **US Letter** is selected as the Paper Size, then click **OK**.
8. Click the **Print** button.
9. Select the same printer that you selected in the Page Setup dialog box.
10. Select **Print Settings** from the list.
11. Select **CD/DVD** for the Media Type and make sure the Mode is set to **Automatic**, as shown.
12. Click **Print**.



Handle printed CDs and DVDs carefully. To allow the ink to dry fully, wait at least 24 hours before playing a disc or inserting it in a drive.

Where to Get Help

World Wide Web: <http://support.epson.com>

Automated telephone services: (800) 922-8911 (touch tone phone required). Your EPSON SoundAdviceSM Express Code is 70455 for the EPSON Stylus Photo 900 and 70415 for the EPSON Stylus Photo 960.

To speak to a Technical Support Representative: (562) 276-7282 (U.S.) or (905) 709-2567 (Canada), 6 AM to 6 PM, Pacific Time, Monday through Friday. Toll or long distance charges may apply.

EPSON is a registered trademark of SEIKO EPSON CORPORATION.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

Copyright © 2003 Epson America, Inc.
Printed in USA

4/03
CPD-16273

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>