

ACCUSPLIT® AX705

OPERATING INSTRUCTIONS


Twin Button Feature: The Left and Right buttons on new ACCUSPLIT stopwatches operate interchangeably, so both are labeled “A” for these instructions.

Event Timing (works for Lane and Finish timing)

This watch features *Ultimate Lane Timing*—you can’t make a mistake!

A – Start (beginning of event)

A – Stop (end of event)



*Oops! I accidentally pressed **Stop** before the end of the event. There’s still one lap to go. Now what do I do? You can recover by simply pressing **A** again when the event really ends.*

Note: You can press **C** at any time to Rejoin (see current running time).

Note: You can use this watch to take Splits if you manually record after each split (Press **A** for each split time, then write it down before taking next split.). See ACCUSPLIT models AX625 (splits without memory), AX725 (16 memory), or AX725 (50 memory) for dedicated split timing.

BATTERY CHANGING

If the display becomes dim or goes blank, you can replace the battery using “X3V” case battery changing instructions posted at www.accusplit.com/support. The watch uses a five-year CR2032 Lithium battery.

Master Reset

Remove battery as shown above. Wait 5 seconds and reinstall.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check
<http://support.ACCUSPLIT.com>

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA
800-935-1996 • 925-290-1900 • FAX 925-290-1930
www.ACCUSPLIT.com • support@ACCUSPLIT.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>