


ACCUSPLIT®

ACCUSPLIT. PRO SURVIVOR™ PRO EVENT STOPWATCH

STOPWATCH OPERATIONS



SINGLE EVENTS


A – START
A – STOP
C – RESET

TIME-IN, TIME-OUT

A – START
A – STOP
A – RESTART
A – STOP
C – RESET

BATTERY CHANGING

See Specifications panel and drawing below.



ACCUSPLIT, Inc.

6120 Stoneridge Mall Rd.

Suite 210

Pleasanton, CA 94588 USA

800-965-2008 • 925-226-0888

FAX 925-463-0147

www.ACCUSPLIT.com

support@ACCUSPLIT.com

REGISTER NOW

Please return your Survivor Stopwatch Registration to the Repair Center address in the warranty, & we will let you know about future products.

Email (preferred) _____

User _____

SPECIFICATIONS

Batteries: Batteries should last for 18 months. If display becomes dim, open back and replace with Duracell LR43, Eveready 86, or Ray-O-Vac LR43.

Operating Temperature: 14°F to 130°F (-10°C to 55°C).

Quartz Crystal Accuracy: 0.04 sec/hr (accuracy may vary with shock, temperature or aging of crystal).

NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check

<http://support.ACCUSPLIT.com>

1-800-965-2008 or 1-925-226-0888

FAX: 925-463-0147

support@accusplit.com

www.accusplit.com

ASSEMBLED IN PRChina

© 2005 ACCUSPLIT

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>