


Model: FD **OVERHEAD WARMERS**

INTENDED FOR OTHER THAN HOUSEHOLD USE

INSTALLATION **AND OPERATING** INSTRUCTIONS



APW WYOTT® 54" Food Warmer has been designed for use only on the Metro® route stand. Each MetroR shelf has pre-drill holes to use with APW WYOTT® mounting bracket. Each warmer ships with pre-wired cord and plug. Remote controls are factory pre-wired and only wired cord and plug. Remote controls are factory pre-wired and only have to be field mounted depending on route stand location. Follow the "Installation Instructions" (in this booklet) to mount controls.

RETAIN THIS MANUAL FOR FUTURE REFERENCE UNIT MUST BE KEPT CLEAR OF COMBUSTIBLES AT ALL TIMES



FOR YOUR SAFETY: Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.





WARNING: Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the Installation, Operating and Maintenance Instructions thoroughly before installing or servicing this equipment.



Initial heating of unit may generate smoke or fumes and must be done in a well ventilated area. Overexposure to smoke or fumes may cause nausea or dizziness.

This equipment has been engineered to provide you with year-round dependable service when used according to the instructions in this manual and standard commercial kitchen practices.

Phone: (214) 421-7366 Fax: (214) 565-0976

Toll Free: (800) 527-2100 Website: www.apwwyott.com E-mail: info@apwwyott.com





P/N 70402071 5/06

APW / WYOTT

729 Third Avenue Dallas, TX 75226

IMPORTANT FOR FUTURE REFERENCE

Please complete this information and retain this manual for the life of the equipment. For Warranty Service and/or Parts, this information is required.

| | • | · | | | |
|--------|--------------|---------------|----------------|--|--|
| | Model Number | Serial Number | Date Purchased | | |
| Votes: | | | | | |
| 10les: | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

TABLE OF CONTENTS

| SECTION | ITEM | PAGE |
|---------|--|------|
| 1 | Owner's Information | 3 |
| | General Information | 3 |
| | Installation Instructions | 3 |
| | General Operation Instructions | 6 |
| | Warranty Information | 6 |
| 2 | Important Safety Information | 6 |
| 3 | Specifications | 6 |
| | · Electrical | 6 |
| | Dimensions | 7 |
| 4 | Operation | |
| | Operating Instructions | 8 |
| 5 | Cleaning | 8 |
| | General Cleaning Instructions | |
| | Dominos Specific Cleaning Instructions | |
| 6 | Troubleshooting | 8 |
| 7 | Parts List & Exploded View | |
| 8 | Wiring Diagram | 10 |
| 9 | Warranty | |

1. OWNERS INFORMATION

General Information:


- 1. Always clean equipment thoroughly before first use. (See general cleaning instructions).
- 2. Check rating label for your model designation and electrical rating.
- 3. For best results, use stainless steel countertops.
- 4. All dimensions in parenthesis in centimeters unless noted.
- 5. APW Wyott Overhead Foodwarmers are constructed from high quality stainless steel and available in lengths from 18" to 72". Utilizing a metal sheath-heating element with a specially designed reflector, these units give uniform heat over the entire holding surface.
- 6. In Europe, contact an APW Wyott authorized service agency for replacement light bulbs.

Installation Instructions:


| Hardware Provided for Installation of Food Warmer | | | | | |
|---|-------------|----------|----------------------------------|--|--|
| Quantity | Part Number | | Description | | |
| 4 | 88993 | | Screw, 10-32x3/8 TRS HD Phillips | | |
| 4 | 89071 | 0 | Washer, 10 Flat .5 OD x .218 ID | | |
| 4 | 89062 | 9 | Nut, Hex 10-32 | | |
| 4 | 88904 | | Screw, Rolock 8-32x3/8 | | |
| 4 | 89056 | * | Washer, #8 Internal Lock | | |
| 4 | 88921 | 9 | Nut, 8-32 Acorn Cap | | |

Domino's Specific Installations on Metro® Route Stands:


- A. Remove food warmer and ceiling mounting brackets from packaging. Remove screws from ends of food warmer; attach ceiling mounting bracket at both ends of food warmer (as shown).
- В. Use 88993 (screw), 89071 (washer), and 89062 (nut) to attach food warmer to underside of shelving. Place foodwarmer under shelf, aligning the ceiling mounting bracket holes with that of the shelf. May require two persons to hold food warmer in place. From the top of the shelf, push through the washer and screw. From the underside of the ceiling mounting bracket, screw the nut on. Repeat for other hole and holes at opposite end.




C. Remote kit mounting. There are two ways to mount the remote kit, front mounting and rear mounting. Front mounting is where the remote kit is mounted on the opposite side of the cord and plug. Rear mounting, the remote kit is mounted on the same side as the cord and plug. Whatever position chosen, when the food warmer is not operating (OFF), the knob on the remote box should be oriented where OFF is in the north position. The control is NOT designed to operate upside down. (Mount as shown below)



1. Use 88904 (screw), 89056 (washer), and 88921 (nut) to mount bracket. Place bracket (70402017) around shelving pole on the inner side of the shelving unit. Screw bracket (70402018) to bracket (70402017) around shelving pole on the outer side of the shelving unit. The bracket will allow the remote box inner side to align with the front side of the food warmer



2. Remove screw and washer from remote box. Align the holes of the remote box with those of bracket 70402017. Screw the remote box to bracket 70402017. Once remote box is mounted to bracket, adjust height of the bracket so that the top of the remote box is even with or underneath the bottom of the side shields on the shelving unit (min. distance 4" between the bottom of heat strip and top of remote box) and tighten screws.



- D. Repeat steps A through C for other food warmers and shelving combination.
- Illustration of a complete Food warmer E. And Metro® Route stand unit





NOTE: TO AVOID BURNING OR CHARRING OF MATERIALS IN THE SURFACE BELOW THE FOODWARMER USE ONLY ABOVE AN ALL-METAL STRUCTURE SUCH AS A TABLE OR COUNTERTOP. **MINIMUM** CLEARANCE 13". FOR OTHER MATERIALS, INSTALL NOT CLOSER THAN 16" ABOVE THE SURFACE.



REMOTE SWITCHES ARE RECOMMENDED FOR UNDER SHELF MOUNTING. LONGER SWITCH LIFE WILL RESULT FROM COOLER SWITCH MOUNTING LOCATIONS.

General Operation Instructions:

- 1. All foodservice equipment should be operated by trained personnel.
- Do not allow your customers to come in contact with any surface labeled "CAUTION HOT".
- 3. Where applicable: Never pour cold water into dry heated units.
- 4. Where applicable: Do not cook, warm or hold food directly in liner pans (well pans). Always use steamtable pans/insets, etc.
- 5. Never hold food below 150°F (66°C).

Warranty Information:

Reliability Backed By APW Wyott's Warranty:

All APW Wyott Holding Drawers are backed by a one year parts and labor warranty, including On-Site Service calls within 50 miles of authorized service technicians.

Service Information:

Service Hotline (800) 733-2203

2. SAFETY INFORMATION

APW Wyott Overhead Warmers are designed, built and sold for commercial use and should be operated by trained personnel only. Clearly post all CAUTIONS, WARNINGS and OPERATING INSTRUCTIONS near each unit to insure proper operation and to reduce the chance of personal injury and/or equipment damage.

Always disconnect power before servicing the Overhead Warmer. Surfaces will remain hot after power has been turned off. Allow unit to cool before cleaning or servicing. Never clean the Overhead Warmer by immersing it in water. The Overhead Warmer is not protected against water jets; DO NOT CLEAN OVERHEAD WARMER WITHAWATER JET. Always clean equipment before first use.

3. SPECIFICATIONS

Electrical:

- A. Single-phase operation at 120, 208, 230, and 240 volts.
- B. Field-wired units provided with 7/8" conduit hole, 6" long leads, and porcelain wire nuts. For supply connections, use minimum no. 14 AWG copper wires suitable for at least 90°C.
- C. U.S. cord-connected units provided with following plug configuration:
 - 1. 120 volt up to 1440 watts = NEMA 5-15P; 120 volt up to 1920 watts = NEMA 5-20P
 - 2. 208 volt up to 2496 watts = NEMA 6-15P; 208 volt up to 3328 watts = NEMA 6-20P
 - 3. 240 volt up to 2880 watts = NEMA 6-15P; 240 volt up to 3840 watts = NEMA 6-20P
- D European cord-connected units provided with following plug configuration:
 - 1. Continental Europe230 volt up to 3600 watts = Schuko CEE7/7
 - 2. UK230 volt up to 2930 watts = Bs1363




WARNING: ELECTRICAL SHOCK HAZARD. FAILURE TO FOLLOW INSTRUCTIONS IN THIS MANUAL COULD RESULT IN SERIOUS INJURY OR DEATH.



- Electrical Ground is required on this appliance.
- Do not modify the power supply cord plug. If it does not fit into the outlet, have the proper outlet installed by a qualified electrician
- Do not use an extension cord with this appliance.
- Check with a qualified electrician if you are unsure as to whether the appliance is properly grounded.

Overall Dimensions:



4. Operation

- A. All foodservice equipment should be operated by trained personnel.
- B. Do not allow your customers to come in contact with any surface labeled "CAUTION HOT".
- C. Switch on unit. Place precooked product under heat source. Maximum heat coverage equivalent to unit length.
- D. Never hold food below 150°F.

5. Cleaning

General Cleaning Instructions:

- A. Never clean any electrical unit by immersing it in water. Turn off before surface cleaning.
- B. Never clean any electrical unit using water jets.
- C. Disconnect power before cleaning or servicing units. All service should be performed by an APW authorized service agency.
- D. Clean unit daily. Use warm, soapy water. Mild cleansers and non-abrasive pads may be used to remove baked-on food.


Domino's Specific Cleaning Instructions:


- A. Follow general cleaning instructions in manual 57238 Section V for all units.
- B. For Domino's specific unit, remove mounting bracket 70402017 and 70402018. Clean any build-up on pole and brackets.

6. Troubleshooting

- A. Always ask and check:
 - 1. Is the unit connected to a live power source?
 - 2. Check the circuit breaker.
 - 3. Is the power switch on and pilot light illuminating?
 - 4. Check the rating label. Is the unit operating on proper voltage?
- B. If the above checks out, and problems still exist, call an APW Wyott authorized service agency.
- C. All service should be performed by an APW Wyott authorized service agency.

| 7. FD PARTS LIST w/Exploded View | | | | | | | | |
|----------------------------------|----------|------------------------------------|-----|-------|-----------|----------------------------------|-----|--|
| ITEM# | PART # | DESCRIPTION | QTY | ITEM# | PART# | DESCRIPTION | QTY | |
| 1 | 76841 | HOUSING W/ASSY FD54 RH CTRL | 1 | 21 | 70402017 | BRACKET, FD REMOTE DOMINOS | 1 | |
| 2 | 89059 | WASHER #10 EXTERNAL LOCK | 2 | 22 | 55343 | CONDUIT CONNECTOR, 90° FLEX | 2 | |
| 3 | 88961 | NUT, HEX 10-24, GREEN | 1 | 23 | 70402022 | CONDUIT, 1/2" | 1 | |
| 4 | 57718 | END PLATE FD | 1 | 24 | 89062 | NUT HEX 10-32 | 4 | |
| 5 | 89071 | WASHER, #10 FLAT | 5 | 25 | 55340 | BUSHING, ANTI-SHORT CCD, #1 | 2 | |
| 6 | 76811 | REFLECTOR FD54 | 1 | 26 | 76190 | INSULATION 18-72 | 2 | |
| 7 | 75863 | ELEMENT, 925W - 120V | 1 | 27 | 70402018 | BRACKET, FD REMOTE DOMINOS | 1 | |
| 8 | 76801 | COVER LARGE FD RH CTRL | 1 | 28 | 70402024 | REMOTE KIT, 1 INFINITE 120V | 1 | |
| 9 | 76802 | COVER SMALL FD | 1 | 29 | 88904 | SCREW, 8-32 X 3/8 PAN HD | 6 | |
| 10 | 76106 | ELEMENT GUARD FD | 2 | 30 | 89056 | WASHER#8 INT LOCK, SS | 6 | |
| 11 | 76955 | BRACKET MOUNTING FD | 2 | 31 | 88921 | NUT, ACORN CAP 8-32 SS | 4 | |
| 12 | 58004 | FASTENER SELF RETAINING | 1 | 32 | 55941 | CORDSETASSY, 14GA. | 1 | |
| 13 | 88889 | SCREW #8 X 1/2 AB SMS PHL | 9 | 33 | 76191 | INSULATION 18-72 | 1 | |
| 14 | 88993 | SCREW 10-32X3/8 TRS HD PHL | 12 | 34 | 56530 | LIGHT, PILOT | 1 | |
| 15 | 76189 | INSULATION 1/2 X 6 X 2-1/2 FD18-72 | 2 | 35 | 88904 | SCREW, 8-32 x 3/8 PAN HEAD | 2 | |
| 16 | 70402028 | INSULATION 18-72 | 1 | 36 | 55564-EGO | INFINITE SWITCH-EGO | 1 | |
| 17 | 76803 | END PLATE FD | 1 | 37 | 89087 | SCREW, 8-32 x 3/16 BINDING HEAD | 2 | |
| 18 | 76804 | SUPPORT ELEMENT FD | 2 | 38 | 55825 | KNOB, INFINITE NO LOGO | 1 | |
| 19 | 89129 | STRAIN RELIEF, CONNECTOR | 1 | 39 | 70402026 | REMOTE ENCLOSURE, SINGLE CONTROL | 1 | |
| 20 | 55102 | NUT, LOCK ELEC BUSHING | 1 | | | | | |





BROWN

BLUE

2

PILOT

EGO

Нī

P2

INFINITE

CONTROL

TOP

H2 |

P1

<u>(5)</u>

9. APW WYOTT EQUIPMENT LIMITED WARRANTY

APW Wyott Foodservice Equipment Company warrants it's equipment against defects in materials and workmanship, subject to the following conditions:

This warranty applies to the original owner only and is not assignable.

Should any product fail to function in its intended manner under normal use within the limits defined in this warranty, at the option of APW Wyott such product will be repaired or replaced by APW Wyott or its Authorized Service Agency APW Wyott will only be responsible for charges incurred or service performed by its Authorized Service Agencies. The use of other than APW Wyott Authorized Service Agencies will void this warranty and APW Wyott will not be responsible for such work or any charges associated with same. The closest APW Wyott Authorized Service Agent must be used.

This warranty covers products shipped into the 48 contiguous United States, Hawaii, metropolitan areas of Alaska and Canada. There will be no labor coverage for equipment located on any island not connected by roadway to the mainland.

Warranty coverage on products used outside the 48 contiguous United States, Hawaii, and metropolitan areas of Alaska and Canada may vary. Contact the international APW Wyott distributor, dealer, or service agency for details.

One year for parts and one year for labor, effective from the date of purchase by the original owner. The Authorized Service Agency may, at their option, require proof of purchase. Parts replaced under this warranty are warranted for the un-expired portion of the original product warranty only

Exceptions

- *Gas/Electric Cookline: Models GCB, GCRB, GF, GGM, GGT, CHP-H, EF, EG, EHP. Three (3) Year Warrantv on all component parts, except switches and thermostats. (2 additional years on parts only. No labor on second or third year.)
- *Broiler Briquettes, Rock Grates, Cooking Grates, Burner Shields, Fireboxes: 90 Day Material Only. No Labor
- *Heat Strips: Models FD, FDL, FDD, FDDL Two (2) Year Warranty on element only. No labor second year
- *Glass Windows, Doors, Seals, Rubber Seals, Light Bulbs: 90 Day Material Only. No Labor

In all cases, parts covered by extended warranty will be shipped FOB the factory after the first year.

Portable Carry In Products

Equipment weighing over 70 pounds or permanently installed will be serviced on-site as per the terms of this warranty. Equipment weighing 70 pounds or under, and which is not permanently installed, i.e. with cord and plug, is considered portable and is subject to the following warranty handling limitations. If portable equipment fails to operate in its intended manner on the first day of connection, or use, at APW Wyott's option or its Authorized Service Agency, it will be serviced on site or replaced.

From day two through the conclusion of this warranty period, portable units must be taken to or sent prepaid to the APW Wyott Authorized Service Agency for in-warranty repairs. No mileage or travel charges are allowed on portable units after the first day of use. If the customer wants on-site service, they may receive same by paying the travel and mileage charges. Exceptions to this rule: (1) countertop warmers and cookers, which are covered under the Enhanced Warranty Program, and (2) toasters or rollergrills which have in store service.

Exclusions

The following conditions are not covered by warranty:

- *Equipment failure relating to improper installation, improper utility connection or supply and problems due to ventilation.
- *Equipment that has not been properly maintained, calibration of controls, adjustments, damage from improper cleaning and water damage to controls.
- *Equipment that has not been used in an appropriate manner, or has been subject to misuse or misapplication, neglect, abuse, accident, alteration, negligence, damage during transit, delivery or installation, fire, flood, riot or act of god.
- *Equipment that has the model number or serial number removed or altered.

If the equipment has been changed, altered, modified or repaired by other than an Authorized Service Agency during or after the warranty period, then the manufacturer shall not be liable for any damages to any person or to any property, which may result from the use of the equipment thereafter.

This warranty does not cover services performed at overtime or premium labor rates. Should service be required at times which normally involve overtime or premium labor rates, the owner shall be charged for the difference between normal service rates and such premium rates. APW Wyott does not assume any liability for extended delays in replacing or repairing any items beyond its control.

In all cases, the use of other than APW Wyott Authorized OEM Replacement Parts will void this warranty.

This equipment is intended for commercial use only. Warranty is void if equipment is installed in other than commercial application.

Water Quality Requirements

Water supply intended for a unit that has in excess of 3.0 grains of hardness per gallon (GPG) must be treated or softened before being used. Water containing over 3.0 GPG will decrease the efficiency and reduce the operation life of the unit.

Note: Product failure caused by liming or sediment buildup is not covered under warranty.

"THE FOREGOING WARRANTY IS IN LIEU OF ANY AND ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSES AND CONSTITUTES THE ENTIRE LIABILITY OF APW WYOTT. IN NO EVENT DOES THE LIMITED WARRANTY EXTEND BEYOND THE TERMS STATED HEREIN.



Phone: (214) 421-7366 (214) 565-0976 Toll Free: (800) 527-2100 Website: www.apwwyott.com E-mail: info@apwwyott.com

APW WYOTT 729 Third Avenue Dallas, TX 75226

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com