

Docking Station PMD-DOK1

INSTALLATION/OWNER'S MANUAL

Please read this manual to maximize your enjoyment of the outstanding performance and feature capabilities of the equipment, then retain the manual for future reference.

IMPORTANT

Please record the serial number of your unit in the space provided below and keep it as a permanent record. The serial number plate is located on the bottom of the unit.

SERIAL NUMBER: **INSTALLATION DATE:**

INSTALLATION TECHNICIAN:

PLACE OF PURCHASE:

ALPINE ELECTRONICS MARKETING, INC. 1-1-8 Nishi Gotanda Shinagawa-ku Tokyo 141-0031, Japar Phone 03-5496-8231

ALPINE ELECTRONICS OF AMERICA, INC. 19145 Gramercy Place Torrance, California 90501 U.S.A. Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF CANADA

INC. 777 Supertest Road Toronto, Ontario M3J 2M9 Canada Phone 1-800-ALPINE-1 (1-800-257-4631) ALPINE ELECTRONICS OF AUSTRALIA **PTY, LTD.** 161-165 Princess Highway, Hallam Victoria 3803, Australia Phone 03-8787-1200

ALPINE ELECTRONICS GmbH Frankfurter Ring 117, 80807 München, Germany Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K., LTD. ALPINE House Instead Highway, Coventry CCV4 9TW, U.K. Phone 0870-33 33 763

ALPINE ELECTRONICS (BENELUX) GmbH Leuvensesteenweg 510-B6 1930 Zaventem, Belgium

Points to Observe for Safe Usage

- Read this manual carefully before starting operation and use this system safely. We cannot be responsible for problems resulting from failure to observe the instructions in this manual.
- This manual uses various pictorial displays to show how to use this product safely and to avoid harm to yourself and others and damage to your property. Here is what these pictorial displays mean. Understanding them is important for reading this manual.

Meaning of displays

incuning of a	nopiayo
⊥ Warning	This label is intended to alert the user to the presence of important operating instructions. Failure to heed the instructions will result in severe injury or death.
	This label is intended to alert the

ALPINE ITALIA S.p.A. Viale C. Colombo 8, 20090 Trezzano Sul Naviglio (MI), Italy Phone 02-484781 ALPINE ELECTRONICS DE ESPAÑA, S.A. Portal de Gamarra 36, Pabellón, 32 01013 Vitoria (Alava)-APDO 133, Spain Phone 945-283588

ALPINE ELECTRONICS FRANCE S.A.R.L. (RCS PONTOISE B 338 101 280)

98. Rue de la Belle Etoile, Z.I. paris Nord II

B.P. 50016, 95945 Roissy Charles de Gaulle Cedex, France Phone 01-48638989

Tel.: 02-725 1315

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

Caution

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loos

LIMITED WARRANTY

ALPINE ELECTRONICS OF AMERICA, INC. AND ALPINE OF CANADA INC. ("Alpine"), are dedicated to quality craftsmanship and are please to offer this Warranty. We suggest that you read it thoroughly. Should you have any questions, please contact your Dealer or Alpine at one of the telephone numbers listed below.

PRODUCTS COVERED:

This Warranty covers Car Audio/Visual Products and Related Accessories ("the product"). Products purchased in the Canada are covered only in Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

•LENGTH OF WARRANTY:

This Warranty is in effect for one year from the date of the first consumer purchase.

•WHO IS COVERED:

This Warranty only covers the original purchaser of the product, who must reside in the United States, Puerto Rico or Canada.

•WHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor) in the product.

•WHAT IS NOT COVERED:

- This Warranty does not cover the following:
- ① Damage occurring during shipment of the product to Alpine for repair (claims must be presented to the carrier).
- 2 Damage caused by accident, abuse, negligence, misuse, improper connections, improper operation or failure to follow instructions contained in the Owner's Manual.
- ③ Damage caused by act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature.
- ④ Any cost or expense related to the removal or reinstallation of the product.
- (5) Service performed by an unauthorized person, company or association.
- 6 Any product which has the serial number defaced, altered or removed.
- ⑦ Any product which has been adjusted, altered or modified without Alpine's consent.
- ⑧ Any product not distributed by Alpine within the United States, Puerto Rico or Canada.
- (9) Any product not purchased from an Authorized Alpine Dealer.
- 1 Any product that has been determined to contain an excessive amount of dust or dirt and any product that contains other contaminants including liquid or foreign objects.

OHOW TO OBTAIN WARRANTY SERVICE:

① You are responsible for delivery of the product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option,

- ③ You must supply proof of your purchase of the product.
- ④ You must package the product securely to avoid damage during shipment.

•HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON IS AUTHOORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

•HOW WE EXCLUDE CERTAIN DAMAGES:

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. THE TERM "INCIDENTAL DAMAGES" REFERS TO, BUT IS NOT LIMITED TO, EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHERS COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT. THE TERM "CONSEQUENTIAL DAMGES" REFERS TO, BUT IS NOT LIMITED TO, THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. THE **REMEDIES PROVIDED UNDER THIS** WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

•HOW STATE/PROVINCIAL LAW **RELATES TO THE WARRANTY:**

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

•IN CANADA ONLY:

This Warranty is not valid unless your Alpine car audio product has been installed in your vehicle by an Authorized Installation Center, and this warranty stamped upon installation by the installation center.

•HOW TO CONTACT CUSTOMER

	This laber is intended to dient the
	user to the presence of important
Acution	operating instructions.
≜ Caution	Failure to heed the instructions
	can result in injury or material
	damage.

✓! _ Warning

DO NOT DISASSEMBLE OR ALTER.

Doing so may result in an accident, fire or electric shock.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.

Doing so may obstruct forward vision or hamper movement etc. and result in serious accident.

resulting in hazards or product failure.

DO NOT INSTALL IN LOCATIONS WITH HIGH **MOISTURE OR DUST.**

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

repair or replace the product with a new or reconditioned product without charge. If the repairs are covered by the warranty, and if the product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges.

② You should provide a detailed description of the problem(s) for which service is required.

SERVICE:

Should the product require service, please call the following number for your nearest Authorized Alpine Service Center.

U.S.A. 1-888-NAV-HELP (1-888-628-4357) CANADA 1-888-NAV-HELP (1-888-628-4357)

Alpine Electronics of America, Inc.,

19145 Gramercy Place, Torrance, California 90501, U.S.A.


Alpine Electronics of Canada, Inc.,

777 Supertest Road, Toronto, Ontario, M3J 2M9, Canada


FCC STATEMENT

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS : (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE. (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.


Installation



Connections







- Select a location where the PMD-DOK1 Docking Station will be level once installed.
- Do not install the Docking Station in a position where the Blackbird main unit will be inserted upside down.
- To protect against vehicle noise, leave a space of 10 to 20 cm between the vehicle wiring and wiring for the Docking Station when installing.
- The Docking Station should be mounted in a convenient location using the mounting screws provided.

1. DISPLAY

Connects to the display connector of Alpine A/V Head Unit.

2. ANTENNA INPUT (OPTIONAL)

FM antenna input (RDS-TMC traffic tuner reception). Optional film antenna (KAX-350FM) available. See your dealer for details.

3. AUDIO OUTPUT


Connects to aux input of Alpine A/V Head Unit (using the provided adapter).

4. Power

Connects 10 pin power input.

5. GPS Antenna

External GPS antenna (included) Input



7 Dimmer In (Illumination) (White/Blue) 9 Parking Brake (Yellow/Blue) 10 Open

Operating Blackbird from the A/V Head Unit (using IVA-W200 as an example)

- **1.** Press and hold the power button for 2 seconds to power on Blackbird.
- 2. Place Blackbird into the Docking station.
- $\mathbf{3}$. Power on the A/V Head Unit and select Navigation as Source.
- To Listen to Music from Blackbird
- 4. Press SOURCE and select AUX as input.
- 5. Press V.SEL and select Navigation as video source.
- Using V. SEL, you can still use function of the A/V Head Unit while Blackbird is on the screen.
- Blackbird's music feature is also available from the Navi menu. See Blackbird Owner's Manual for more details.

Features

- Navigation map display output to A/V Head Unit
- Full Touch Control with compatible A/V Head Unit
- · Vehicle speed sensor input
- Voice guidance output
- Stereo MP3/WMA audio output

Confirming Proper Installation

The vehicle connections screen allows you to ensure proper installation of the PMD-DOK1.

- 1. Touch NAVI. The A/V Head Unit will display the Blackbird screen.
- 2. Touch MAIN MENU
- 3. Touch INFORMATION

Additional On-Screen Buttons


Wiring Diagram With IVA-W200

When Blackbird is docked, two additional on-screen buttons allow you to conveniently access system features.



Note; If left idle for more than 5 seconds, the system will automatically return to the Blackbird navigation screen.





Touching this button will display



Specifications

- External dimensions118 (W) x 118 (H) x 40 (D) mm
- Included in the box: PMD-DOK1 Docking Station1 Transparent Dock Cover1 10 pin Power cable (5 m/ 16.4 ft).....1 13 pin RGB Video cable (5 m/ 16.4 ft)1 External GPS antenna (5 m/ 16.4 ft)1 Mini jack to RCA (female) cable (31 cm/ 1 ft).....1 Mounting screws4 Cover lock screws2 Installation/Owner's Manual1 Registration card1
- Product specifications and appearance are subject to change without notice for the purpose of improvement.

4. Select VEHICLE CONNECTIONS. The connection status will appear on the screen.

Illumination - Toggle the parking lamp switch on and off to confirm this connection. This will allow the navigation display to change between night and dav mode.

VSS - When connected to the vehicle speed sensor wire, this number will change to reflect current speed.

Parking Brake - Toggle the parking brake on and off to confirm this connection. This will allow access to the Edit and Setup menu while the vehicle is parked.

Illumination : ON	-		
VSS : 25MPH	Battery	: 653	
	Illumination	: ON	
Parking Brake : OFF	VSS	: 25MPH	
	Parking Brake	e : OFF	

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com