


WARNING:

TOREDUCE THERISK OF FIRE OR ELECTRIC SHOCK, DONOT EXPOSE THIS PRODUCT TORAIN OR MOISTURE.

DO NOT INSERT ANY METALLIC OBJECT THROUGH VENTILATION GRILLS.

CAUTION:



Explanation of Graphical Symbols



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product'senclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

Precautions

Safety -----

Should any liquid or solid object fall into the cabinet, unplug the unit and have it checked by the qualified personnel before operating it any further.

Unplug the unit from the wall oulet if it is not going to be used for several days or more. To disconnect the cord, pull it out by the plug. Never pull the cord itself.

Allow adequate air circulation to prevent internal heat build-up. Do not place the unit on surfaces (rugs, blankets, etc.) or near materials(curtains, draperies) that may block the ventilation holes.

Height and vertical linearity controls located at the rear panel are for special adjustments by qualified personnel only.

Installation -----

Do not install the unit in an extremely hot or humid place or in a place subject to excessive dust, mechanical vibration.

Theunit is not designed to be waterproof. Exposure to rain or water may damage the unit.

Cleaning ----

Clean the unit with a slightly damp soft cloth. Use a mild household detergent. Never use strong solvents such as thinner or benzine as they might damage the finish of the unit.

Retain the original carton and packing materials for safe transport of this unit in the future.

- 2 -

IMPORTANT SAFEGUARDS

- 1. READ INSTRUCTIONS -- All the safety and operating instructionsshould be readbefore the appliance is operated
- 2. RETAIN INSTRUCTIONS -- The safety and operating instructionsshould be retained for future reference
- 3. CLEANING -- Unplug video monitor or equipment from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Useadampclothforcleaning.
- 4. ATTACHMENTS -- Do not use attachments not recommended by the video monitor or equipment manufacturer as they may result in the risk of fire, electric shockorinjury topersons.
- WATER AND MOISTURE -- Do not use video monitor or equipment near water -- for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimmingpool, orthelike.
- 6 ACCESSORIES -- Do not place video monitor or equipment on an unstable cart, stand or table. The video monitor or equipment may fall, causing serious injury to a child or adult, and seriousdamagetotheequipment. Wallorshelfmounting should follow the manufacturer's instructions, and should use a mounting kit approved by themanufacturer
- 6A. Videomonitororequipmentandcart combinationsshould bemoved with care. Quickstops, excessive force, and uneven surfaces may cause the equipment and cart combination to over turn



- 7. VENTILATION -- Slots and openings in the cabinet and the back or bottom are provided for ventilation, and to ensure reliable operation of the video monitor or equipment and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked blocked of covered. The openings should never be blocked by placing the video monitor or equipment on a bed, sofa, rug, or other similar surface. Video monitor or equipment should never be placed near or over a radiator or heat register. Video monitor or equipment receiver should not be placed in a built-in installation such as a bookcase unless proper ventilation isprovided.
- 8. POWER SOURCES -- Video monitor or equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your video monitor or equipment dealer or local power company. For video monitor orequipment designed to operate from battery power refer to the operating instructions.
- 9. GROUNDING OR POLARIZATION -- This video monitor may be equipped with a polarized alternating - current line plug (a plughaving one blade widerthanthe other). This plug will fit into the power outlet only one way. This is a safety feature. If youareunabletoinserttheplugfullyintotheoutlet, try reversing the plug. If the plug should still fail to fit, contact vour electriciantoreplace vour obsolete outlet. Donotdefeat the safetypurpose of the polarized plug.

Alternate Warnings - This video monitor is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purposeofthegrounding-typeplug.

- 10. POWER CORDS -- Do not allow anything to rest on the power cord. Do not locate video monitor or equipment where the cord willbeabusedbypersons walking on it.
- 11. HEED WARNINGS -- Follow all instructions marked on the videomonitororequipment.
- 12. LIGHTNING -- For added protection for video monitor or equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightningandpower-linesurges.
- 13. OVERLOADING -- Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.
- 14. OBJECT AND LIQUID ENTRY -- Never push objects of any kind into video monitor or equipment through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kindontheproduct
- 15. SERVICING -- Do not attempt to service video monitor or equipment yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing toqualifiedservicepersonnel.
- 16. DAMAGE REQUIRING SERVICE -- Unplug video monitor or equipment from the wall outlet and referservicing to qualified servicepersonnelunder thefollowingconditions

A. When the power-supply cord or the plug has been damaged

B. If liquid has spilled, or objects have fallen into the video product. C. If the videoproducthasbeenexposed torainor water

D. If the video product has been exposed to rainof water. D. If the video product does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the vide oproduct to its normal operation. E. If the video product has been dropped, or the cabinet

damaged. F. When the video product exhibits a distinct change in performance -- this indicates a needforservice.

- 17. REPLACEMENT PARTS -- When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
- 18. SAFETY CHECK -- Upon completion of any service or repairs to this video product, ask the service technician to erform safety checks to determine that the video product is in properoperatingcondition.
- 19. FIELD INSTALLATION -- This installation should be made by a qualified service person and should conform to all local codes

- 3 -

FCC COMPLIANCE STATEMENT

INFORMATION TO THE USER: THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

- REORIENT ORRELOCATE THE RECEIVING ANTENNA

- INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER

- CONNECT THE EQUIPMENT INTO ANOUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER ISCONNECTED

- CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP

CAUTION : CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURED COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THIS CLASS B DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE-CAUSING EQUIPMENT REGULATIONS.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B RESPECTE TOUTES LES EXIGENCES DU RÈGLEMENT SUR LEMATÉRIEL BROUILLERDUCANADA.

FEATURES

- Possible use as a closed circuit television monitor or a video preview / playback monitor.
- Loop through connection.
- Electronic circuits provide safeguards against interference, noise and changing signal strength to maintain a clear and stable picture.

SPECIFICATIONS

PICTURE TUBE(Useful screen size)	9" Diagonal, 90° Deflection Angle (8.7")
POWER SOURCE	12" Diagonal, 90° Deflection Angle (11.6") _ AC 90 – 132V 50Hz/60Hz _ AC 198 – 264V 50Hz/60Hz
→ CAUTION : Confirm the model number and the power source on the cover page before use.	
POWER CONSUMPTION SYSTEM RESOLUTION INPUT SIGNAL SCANNING FREQUENCY : HORIZONTAL : VERTICAL LINEARITY : HORIZONTAL : VERTICAL ACTIVE DISPLAY AREA	18 Watts EIA or CCIR standard more than 800 TV lines (center) 1.0Vp-p (75 ohm) 60Hz : 15.734KHz 50Hz : 15.625KHz $\begin{bmatrix} 59.94Hz \\ 50Hz \end{bmatrix}$ 10% MAX. 10% MAX.
: HORIZONTAL	10% overscanning
: <i>VERTICAL</i> INPUT CONNECTOR(CAMERA) CONTROL	13% overscanning BNC connector
: FRONT : BACK	H-HOLD, V-HOLD, BRIGHT, CONTRAST, POWER S/W V-LINEARITY , V-HEIGHT, EIA/CCIR SELECTOR S/W
OPERATING TEMPERATURE AMBIENT HUMIDITY DIMENSIONS(W x D x H) WEIGHT	0°C ~ 40C° (32°F ~ 104°F) 0% ~ 90% 9" : 220mm x 248mm x 234mm 12" : 305mm x 302mm x 287mm 9" : 4.3Kg 12" : 7.3Kg

- 5 -

OPERATING INSTRUCTION

FRONT 9" 12"

1. H-HOLD (horizontal hold) CONTROL

When the picture has slanting horizontal bars, rotate the H-HOLD control in either direction until a stationary picture is obtained.

5

4

3

2. V-HOLD (vertical hold) CONTROL

When the picture rolls up or down on the screen, adjust V-HOLD control until there is a single steady picture.

3. BRIGHT (brightness) CONTROL


Turn clockwise for more brightness and counterclockwise for less.


4. CONTRAST CONTROL

Turn clockwise to increase picture contrast and counterclockwise to decrease it.

5. POWER SWITCH

To turn the monitor power on, press once. To turn the power off, press once again.





BLACK & WHITE MONITOR

50300976A

Printed in KOREA

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com