

Police Beacon

YA-145 B/R/G/Y

Users Guide

Please read these instructions carefully before use

World-wide Headquarters:

3000 North 29th Ct., Hollywood, Florida, USA, FL 33020 Tel: +1-954-929-1115 Fax: +1-954-929-5560

www.ChauvetLighting.com



Introduction

Congratulations on the purchase of your new CHAUVET lighting effect. We are confident you will enjoy many trouble free hours with this unit. To assist with the care and use of the product we have prepared this short guide.

Operation

This lighting effect has been designed to function on a mains power supply of either 120V~60Hz or 230V~50Hz and has been fitted with a suitable power plug for use with your local voltage. Check the label on the unit and the power plug for the correct voltage.

When connected to the mains power supply the bulb should illuminate and the reflector dish should rotate.

The duty cycle for this effect should be no more than 15 minutes on then 15 minutes off.

Replacing Lamps

- 1. Disconnect from main power supply before attempting to replace lamp.
- 2. Ensure that the unit is sufficiently cool, before removing blown lamp.
- 3. Never touch new lamps with your fingers; use a tissue or a cloth.

In order to replace the lamp, disconnect from main power supply first, and unscrew the set screws to remove the lamp replacement cover, which is highlighted on the diagram (fig.1). Only use the appropriately rated lamps as use of any other lamp type may cause the unit to be non-operational.

Finally before switching on, check that the lamp is housed correctly in the lamp holder and that the lamp replacement cover has been screwed back into place.

If after replacement of the lamp, the unit is still not working then please contact CHAUVET for servicing.

Cleaning

The most important part of your lighting effect to keep clean is the colored dome and the reflector dish as they allow the light output to transmit. These should be cleaned with a soft damp cloth. The body of the unit may also be cleaned in the same way. We recommend internal cleaning be carried out by a fully qualified technician.

Maintenance & Servicing

Work on internal parts should be carried out by a qualified technician. Removal of any covers other than the lamp replacement access is considered a breach of warranty and will not be covered under any such agreement unless authorized first by CHAUVET.

Troubleshooting

- If the unit is not functional check main power supply is 'on'.
- If the unit is functional but lamp does not light lamp may require replacing. If after trying this solution you still have a problem contact CHAUVET.

Caution

No user serviceable parts inside, please refer to CHAUVET for service.

Power Connections

The unit is supplied with a power plug appropriate to its voltage and destination. Should any other connections be required they must be carried out with the following configuration.

Earth = Green/Yellow cable Neutral = Blue cable Live = Brown cable

In the USA & Europe, it is required that all plugs are 3-pin type i.e. with Earth/Ground connection

In the UK, it is required that all mains plugs are fitted with 5A fuses.

Technical Specifications

Power	120V~60Hz AC	230V~50Hz AC	
Lamps	1 x 120V 25W Part No S3909	1 x 230V 25W Part No S3909	
Dimensions	184 x 178mm / 7.25in x 7in		
Weight	1.14kg / 2.5lbs		

User Information	Please	complete t	for your records)
Date Purchased:	1	1	Serial No <u>:</u>
Dealer Stamp: BEACON			Model: YA-145 POLICE

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com