# Santos Tobal Solvers Fores

Kaffeemaschine Cafetière Kaffemaskine Cafetera Caffettiera Koffiezetapparaat Kaffebryggare Máquina de café Ekspres do kawy ΚΑΦΕΤΙΕΡΑ Kávovar Instruction for use ENGLISH Gebrauchsanweisung DEUTSCH Mode d'emploi FRANÇAIS Brugsanvisning DANSK Instrucciones de uso **ESPAÑOL** Istruzioni per l'uso ITALIANO Gebruiksaanwijzing **NEDERLANDS** Bruksanvisning SVENSKĂ Instruções de uso **PORTUGUÊS** Instrukcja obsługi Język polski Οδηγίες χρήσεως ΕΛΛΗΝΙΚΑ Návod k obsluze ČESKY



0.751/25 oz Coffee Maker

# Welcome to BODUM®

We congratulate you on your purchase of the SANTOS 3004 coffee maker. With this machine you will be able to make aromatic coffee.

#### OPERATING PRINCIPLE

The water is heated in the jug. The steam generated forces the water through the riser tube and into the funnel. The gentle heating of the ground coffee enhances the coffee's beneficial qualities. The coffee is brewed at the ideal temperature and develops its full aroma. Once the correct brewing time has elapsed, the heating element switches off and the coffee flows back into the jug - it is now ready to serve.

The Santos coffee maker 3004 allows you to prepare between 3 cups (0.375 I/12.5 oz) and 6 cups (0.75 I/25 oz) of coffee. The cycle time can vary according to the amount of water, the amount of coffee and the grind of coffee, for 6 cups (0.75 I/25 oz) it takes approximately 5 minutes.

After 15 minutes the machine switches off automatically.

Intended use. The "Santos" coffee maker is designed only for brewing coffee with ground coffee beans. Coarse or finely ground coffee may be used. BODUM® recommends using a grind suitable for filter coffee. Instant coffee is not suitable.

Warning! Never use the unit to boil water! Never heat up cold, brewed coffee.

The coffee maker is intended exclusively for household use and may therefore be operated only in the household.





- 1 Funnel cover
- 2 Filter
- 3 Funnel
- 4 Seal
- 5 Swing
- 6 Lid of jug
- **7** Jug
- 8 Level indicator with MIN and MAX filling marks
- **9** Power base
- 10 Cable storage
- 11 ON/OFF switch

## SAFETY INSTRUCTIONS

### WHAT TO DO:

Use the unit exclusively in the household and only for the intended purpose (see "Intended use").

Damaged units should be taken immediately to the nearest BODUM® HOME STORE or authorized BODUM® dealer for repairs.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid

Only operate the unit with the rated voltage indicated (see label on base of unit).

SAFETY INSTRUCTIONS |









Always place the unit on a dry, stable and horizontal surface.

Always allow the unit to cool down before cleaning.

Switch off the unit before removing the plug from the electrical outlet. Always pull only on the plug and never on the cable.







Download from Www.Somanuals.com. All Manuals Search And Download

# SAFETY INSTRUCTIONS WHAT YOU MUST NOT DO:

Do not allow children to operate the unit without supervision. Children do not recognize hazards.

The power base and parts of the jug become very hot during operation! Lift the jug only by the handle; do not touch hot surfaces!

Under no circumstances should you operate units in which parts are defective or missing.

Do not crush the cable or lead it around corners or sharp edges! Store excess cable in the base of the unit.

#### **COFFEE PREPARATION**

#### Before first use.

Every unit is tested and carefully packed before shipping. Nevertheless, please check before use that the unit is complete and is not damaged anywhere.

#### Before the first brewing.

Flush the unit without coffee. To do this, fill the jug with water, boil and pour out. Always make sure that the jug is filled with enough water for brewing coffee. The MIN mark on the level indicator must always be reached, i.e. always fill with at least enough water for 3 cups (0.375 I/12.5 oz).











1. Pull the cable out of the power base for at least 2/3 of its length.



2. Plug in the cable, leading it as directly as possible.



3. Fill the jug with the desired amount of cold water.

Operate the unit with BODUM® original parts only. BODUM® declines any liability or guarantee if the unit is fitted with any other parts.

Do not place the unit or parts near a stove or oven or in a microwave oven.

To protect against fire, electric shock or injuries, never immerse the cable, plug or power base in liquids or allow them to come into contact with

liquids.

Never open the power base or the bottom of the jug! Have repairs performed only by authorized experts.



4. The MIN mark on the level indicator must be reached!




5. Place the jug on the power base.



6. Turn the funnel around on its axis to fit it on the jug. Note: Wetting the seal facilitates fitting of the funnel.













7. Ensure that the funnel sits securely on the jug and that the seal is evenly compressed.



8. Place the filter in the funnel.



9. Ensure that the filter snaps audibly in position!





10. Place the desired amount of ground coffee in the funnel. We recommend one BODUM® scoop (7g/0.25 oz) per BODUM® coffee cup (1.25 dl/4 oz).



13. As soon as there is no water left in the funnel, the coffee is ready.



11. Place the cover on the



12. Press the switch marked "ON" at the side of the machine. The switch will light up to show that the machine is switched on. Caution: The unit will become hot and steam may escape from the



15. Turn the swing outwards from the power base.



openings in the cover.





Remove the swing from the power base. Rinse the swing with water.



Warning: Unplug the power base before cleaning and do not immerse in liquids or clean under running water.

Replace the cable in the storage area in the base.



The filter has to be changed as soon as the mesh has any defects, or at least once every three months. Filter plates are available at any BODUM® HOME STORE or authorized BODUM® dealer. Loosen the screw in the filter and replace the filter plate.



16. Hold the jug firmly by the handle and tip the funnel aside slightly. Warning: Hot parts! Lift the jug only by the handle.



14. A funnel holder is

integrated in the power

swing.

base. Press lightly on the

17. Place the funnel on the funnel holder on the power base, or else in the sink.



18. The coffee can now be enjoyed.





Remove the cover from the funnel and discard the coffee grounds.



Remove the filter from the funnel. Rinse and clean the funnel and filter with water. Both parts are dishwasher safe.



Clean the jug with warm water and washingup liquid.

Warning: Do not immerse the jug in liquids. Do not clean the jug under running water.

Warning! Allow all parts to cool before cleaning! The plasthe dishwasher or



#### LIME REMOVAL



Coffee has a slightly descaling effect. If lime deposits are only slight, it is sufficient to leave a little coffee in the jug after each brewing cycle over a period of 2-3 days.

To descale we recommend the use of ordinary commercial descalers. For the regular removal of scale and discolouring from the jug we recommend using BODUM® cleaner and descaler.



1. Dissolve contents of BODUM® cleaner and descaler package in 4 cups warm water.



2. Turn machine on and begin the brew cycle.



3. Rinse all components and repeat steps 1 and 2 twice with clean water.

#### **SERVICE & GUARANTEE CONDITIONS**

All BODUM® products are made of high-quality, durable materials. However, should parts require replacement, please contact one of the following:

your BODUM® dealer - the BODUM® HOME STORE - the BODUM® representative in your country, or our home page at www.bodum.com

Guarantee. BODUM® guarantees the "Santos" coffee maker for 2 years from date of purchase against material defects or malfunctions which can be traced back to defects in manufacturing or design.

Repair is free of charge provided all guarantee requirements are fulfilled.

Guarantee requirements. The guarantee certificate must be completely filled out by the seller at the time of purchase. Only agents authorized by BODUM® may perform guarantee services.

BODUM® makes no guarantee for damage which can be attributed to use for unintended purposes, incorrect handling, normal wear and tear, defective or incorrect maintenance or service work, incorrect operation or manipulation by unauthorized persons.

> **TECHNICAL DATA:** Mains voltage: 230V 50Hz or 120V 60Hz Rated power: 1200W Cable length extendible to 80cm Net contents: 0.375 - 0.75 litres 12.5 - 25 ounces

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com