



Illustrated Parts List

Model Series

12E300

TYPE NUMBERS
0018 through 0275.

TABLE OF CONTENTS

Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	5
Exhaust System	6
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valves	3
Lubrication	2
Piston Group	2
Rewind Starter	5



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.











1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.





1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL










1019 LABEL KIT




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5750-2 Assemblies include all parts shown in frames. 06/18/2008



5750-3 **Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.** Assemblies include all parts shown in frames. **06/18/2008**




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5750-4 Assemblies include all parts shown in frames. **06/18/2008**



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5750-5 Assemblies include all parts shown in frames. 06/18/2008

12E300



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5750-6 Assemblies include all parts shown in frames. **06/18/2008**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
1	699510	Cylinder Assembly	26	791969	Ring Set (Standard) (Used After Code Date 05060600).	65	699228	Screw (Rewind Starter)		
2	399269	Kit-Bushing/Seal (Magneto Side)				65A	699851	Screw (Rewind Starter)		
3	★299819S	Seal-Oil (Magneto Side)			----- Note -----	78	699205	Screw (Flywheel Guard)		
5	699486	Head-Cylinder			499631 Ring Set (Standard) (Used Before Code Date 05060700).	95	691636	Screw (Throttle Valve)		
7	★∅698210	Gasket-Cylinder Head			791324 Ring Set (.020" Oversize) (Used After Code Date 05060600).	97	690024	Shaft-Throttle		
11B	695745	Tube-Breather			692786 Ring Set (.020" Oversize) (Used Before Code Date 05060700).	98	398185	Kit-Idle Speed		
12	★699485	Gasket-Crankcase				104	●691242	Pin-Float Hinge		
13	699482	Screw (Cylinder Head)				108	695807	Valve-Choke		
15	691686	Plug-Oil Drain				109B	695729	Shaft-Choke		
15B	695757	Plug-Oil Drain				109C	791957	Shaft-Choke		
16	699445	Crankshaft ----- Note ----- 699454 Crankshaft Used on Type No(s). 0275.				117	690048	Jet-Main (Standard)		
18	699804	Cover-Crankcase	27	691866	Lock-Piston Pin	118	498977	Jet-Main (High Altitude)		
18B	699677	Cover-Crankcase	28	499423	Pin-Piston	121	792006	Kit-Carburetor Overhaul		
20	★692550	Seal-Oil (PTO Side)	29	690124	Rod-Connecting			122	●693749	Spacer-Carburetor
20A	★691952	Seal-Oil (PTO Side) (Auxiliary Drive)	30	791584	Dipper-Connecting Rod	125A	794587	Carburetor		
21	281658S	Cap-Oil Fill	32	691664	Screw (Connecting Rod)	127	●694468	Plug-Welch		
22	699478	Screw (Crankcase Cover/ Sump)	32A	695759	Screw (Connecting Rod)	127A	●691739	Plug-Welch		
23	699516	Flywheel	33	499642	Valve-Exhaust	130	691181	Valve-Throttle		
24	222698S	Key-Flywheel	34	499641	Valve-Intake	133	398187	Float-Carburetor		
25	791968	Piston Assembly (Standard) ----- Note ----- 791326 Piston Assembly (.020" Oversize)	35	691304	Spring-Valve (Intake)	134	●398188	Kit-Needle/Seat		
			36	691304	Spring-Valve (Exhaust)	137	●693981	Gasket-Float Bowl		
			37	699661	Guard-Flywheel	146	690979	Key-Timing		
			40	692194	Retainer-Valve	155	698214	Plate-Cylinder Head		
			45	690977	Tappet-Valve	186	692317	Connector-Hose		
			46	696813	Camshaft	187	791766	Line-Fuel (Cut to Required Length)		
			46A	695285	Camshaft	187A	791867	Line-Fuel (Molded)		
			51★♦∅692555	Gasket-Intake		187B	791874	Line-Fuel (Molded)		
			55A	696710	Housing-Rewind Starter	188	699479	Screw (Control Bracket)		
			58	693389	Rope-Starter (Cut To Required Length)	190	699220	Screw (Fuel Tank)		
			60B	699334	Grip-Starter Rope	192	694543	Ball-Rocker Arm		

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5750-7

Assemblies include all parts shown in frames.

06/18/2008

12E300

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
209	692571	Spring-Governor	304	699598	Housing-Blower	474	694457	Alternator
209A	691278	Spring-Governor	305	699480	Screw (Blower Housing)			----- Note -----
219	693578	Gear-Governor	306A	695710	Shield-Cylinder			793640 Alternator
220	691724	Washer (Governor Gear)	307	699483	Screw (Cylinder Shield)			Used on Type No(s). 0275.
222	699592	Bracket-Control (Used Before Code Date 06051500).	307A	699234	Screw (Cylinder Shield)	474A	698314	Alternator
222G	793109	Bracket-Control (Used After Code Date 06051400).	309A	696818	Motor-Starter ----- Note -----	485	695755	Knob-Control
227	692573	Lever-Governor Control			699786 Motor-Starter Used on Type No(s). 0275.	493A	695744	Bracket-Mounting
238	691300	Cap-Valve	318	690370	Screw (Mounting Bracket)	493B	691177	Bracket-Mounting
268	691025	Control Wire Casing (Cut to Required Length)	318A	790537	Screw (Mounting Bracket) (Used After Code Date 04110800).	493C	699048	Bracket-Mounting
269	691026	Control Wire (Cut to Required Length)			----- Note -----	501	698315	Regulator
270	691027	Nut (Control Wire Casing)			699773 Screw (Mounting Bracket) (Used Before Code Date 04110900).	503	699889	Strap-Starter
271	691028	Lever-Control	332A	792723	Nut (Flywheel)	504	694254	Washer Set-Friction
271A	698038	Lever-Control	333	695711	Armature-Magneto	505	691251	Nut (Governor Control Lever)
276	♦271716	Washer-Sealing	334	699477	Screw (Magneto Armature)	523	693618	Dipstick ----- Note -----
281A	793131	Panel-Control (Used After Code Date 06051400).	337	491055S	Spark-Plug			790546 Dipstick
		----- Note -----	356K	695731	Wire-Stop			Used on Type No(s). 0275.
		697550 Panel-Control (Used Before Code Date 06051500).	358	791797	Set-Engine Gasket	524	281370	Seal-Dipstick Tube
		793122 Panel-Control (Used After Code Date 06051400).	363	19203	Puller-Flywheel	526	793006	Screw (Regulator)
		Used on Type No(s). 0275.	365	699484	Screw (Carburetor)	528	793006	Hose-Primer
		696684 Panel-Control (Used Before Code Date 06051500).	383	19374S	Wrench-Spark Plug	552	692346	Bushing-Governor Crank
		Used on Type No(s). 0275.	427	694255	Nut (Control Bracket)	562	691119	Bolt (Governor Control Lever)
300	699512	Muffler ----- Note -----	441	694262	Bracket-Oil Fill	597	691696	Screw (Pawl Friction Plate)
		699511 Muffler Used on Type No(s). 0018, 0100, 0111, 0275.	449	699629	Screw (Oil Fill Bracket)	598	220624	Shim-End Play
			455	692591	Cup-Flywheel	601	791850	Clamp-Hose
			456	692299	Plate-Pawl Friction	604A	793134	Cover-Control (Used After Code Date 06051400).
			459	281505S	Pawl-Ratchet			----- Note -----
			472	696691	Knob-Choke Shaft			695749 Cover-Control (Used Before Code Date 06051500).
			472B	791958	Knob-Choke Shaft	608A	699335	Starter-Rewind
						613	697812	Screw (Muffler)
						613A	699480	Screw (Muffler)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊘ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5750-8

Assemblies include all parts shown in frames.

06/18/2008

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
615	692576	Retainer-Governor Shaft	842	691031	Seal-O Ring (Dipstick Tube)	1011	794544	Tube-Vent
616	692547	Crank-Governor	847	693617	Dipstick/Tube Assembly	1019	792211	Kit-Label
619	699480	Screw (Cylinder Head Plate)			----- Note -----	1022	★Ø691890	Gasket-Rocker Cover
621	692310	Switch-Stop			790545 Dipstick/Tube Assembly	1023	499924	Cover-Rocker Arm
632	692653	Spring/Link-Mechanical Governor			Used on Type No(s). 0275.	1026	790287	Rod-Push
633	◆693867	Seal-Choke/Throttle Shaft	851	493880S	Terminal-Spark Plug	1029	691230	Arm-Rocker
633A	◆691321	Seal-Choke/Throttle Shaft	863	699849	Bracket-Muffler	1034	691343	Guide-Push Rod
635A	692927	Boot-Sparkplug	864	699232	Adapter-Muffler	1036		Label-Emissions (Available From An Authorized Briggs & Stratton Sevice Dealer)
663	699854	Screw (Control Panel)	868	★Ø692044	Seal-Valve	1054	280275	Tie-Cable
668	694257	Spacer	883	★692237	Gasket-Exhaust	1058	277104	Operator's Manual
689	691855	Spring-Friction	883A	★691893	Gasket-Exhaust	1070	699201	Screw (Flywheel Fan)
692	690572	Spring-Detent (Choke)	892	695747	Switch-Key	1095	791798	Gasket Set-Valve
703	698320	Clip	914	699480	Screw (Rocker Cover) (Bottom)	1119	699772	Screw (Alternator)
718	690959	Pin-Locating	914A	692557	Screw (Rocker Cover) (Top)	1148	698418	Screw (Clip)
731	794590	Hood-Snow	914B	697551	Screw (Rocker Cover) (Center)	1196	696692	Screw (Snow Hood) (Carburetor)
741	695087	Gear-Timing			930 696709 Guard-Rewind	1196A	696685	Screw (Snow Hood) (Muffler)
742	692564	Retainer-E Ring			957 792647 Cap-Fuel Tank	1210	498144	Pulley/Spring Assembly (Pulley)
746	790278	Gear-Idler			958 698180 Valve-Fuel Shut Off	1211	498144	Pulley/Spring Assembly (Spring)
773	694258	Retainer			972 694260 Tank-Fuel	1224	696824	Nut (Carburetor Primer)
813	690635	Clamp			975 493640 Bowl-Float	1230	699847	Screw (Control Bracket)
819	699233	Screw (Muffler Bracket)			976 790221 Primer-Carburetor (Snap Fit)	1251	696699	Shield-Snow
823	699209	Screw (Muffler Adapter)			----- Note -----	1252	699234	Screw (Snow Shield)
824	696017	Gasket-Heat Shield			695750 Primer-Carburetor	1319	794467	Label-Warning
830	694544	Stud (Rocker Arm)			977 792007 Gasket Set-Carburetor	1330	272147	Repair Manual
832A	699892	Guard-Muffler			990 695756 Key-Set			
		----- Note -----			993 ★Ø694088 Gasket-Cylinder Head Plate			
		699313 Guard-Muffler			996 794687 Shield-Carburetor			
		Used on Type No(s). 0275.			998 696683 Pipe-Oil			
836B	699209	Screw (Muffler Guard)			1005 692592 Fan-Flywheel			
836C	699234	Screw (Muffler Guard)	1005A	794273	Fan-Flywheel			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5750-9

Assemblies include all parts shown in frames.

06/18/2008

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>