

The limited warranty set forth below is given by Canon U.S.A., Inc., (Canon U.S.A.) and Canon Canada Inc., (Canon Canada) with respect to Calculators purchased and used in the United States and Canada respectively.

PRINTED IN CHINA



E-IM-2480

## INSTRUCTIONS INSTRUCCIONES

### ENGLISH

#### POWER SUPPLY

This calculator comes with a dual power source, The duration of alkaline battery depends entirely on individual usage.

- Electromagnetic interference or electrostatic discharge may cause the display to malfunction or the contents of the memory to be lost or altered. Should this occur, press the **ON** key and re-start your calculation from the beginning.

#### AUTOMATIC POWER-OFF FUNCTION

When the power is turned "ON" and none of the keys are pressed for more than **7 minutes**, the calculator turns off automatically to save power. Press **ON** key to restart the calculator. "0" will appear on the display.

#### OVERFLOW FUNCTIONS

In the following cases, "E" will be shown on the display. The keyboard is electronically locked and further operation is impossible. Press **ON** key to clear the overflow. The overflow occurs when:

- The key input, result or the memory content exceeds 8 digits to the left of the decimal point.
- Dividing by "0".

#### SPECIFICATION

Power Source: Solar cell and alkaline battery (LR44 x 1)  
Usable Temperature : 0°C to 40°C (32°F to 104°F)  
Dimensions: 103mm (L) x 60mm (W) x 11.3mm (H) /  
4-1/16" (L) x 2-23/64" (W) x 3/64" (H)

Weight: 57g (1.93 oz)

*(Subject to change without notice)*

#### FUENTE DE ALIMENTACIÓN

Esta calculadora puede funcionar con dos fuentes de alimentación. Las pila alcalina pueden utilizarse durante bastante tiempo, dependiendo del uso que se les dé.

- La interferencia electromagnética o descarga electrostática puede hacer que el Display al mal funcionamiento o el contenido de la memoria para ser perdido o alterado. Si esto ocurre, pulse la tecla **ON** clave y volver a iniciar el cálculo desde el principio.

#### FUNCIÓN DE DESCONEXIÓN AUTOMÁTICA

Cuando la calculadora es conectada pero no se presiona ninguna tecla durante más de **7 minutos** aproximadamente, el indicador se apaga automáticamente. En este caso, presione la tecla para **ON** comenzar los cálculos.

#### FUNCIÓN DE REBOSE

Funciones de desbordamiento en el caso siguiente, "E" se mostrará en la Display. El teclado está bloqueado electrónicamente y posterior operación es imposible.

Pulse **ON** para borrar el desbordamiento. La función de rebose ocurre cuando:

- La aportación fundamental, resultado o el contenido de la memoria excede de 8 dígitos a la izquierda del punto decimal.
- Dividiendo por "0".

#### ESPECIFICACIONES

Fuente de alimentación: Célula solar o ilas alcalina (LR44 x 1)  
Temperatura de uso: 0°C a 40°C (32°F a 104°F)  
Dimensiones: 103mm (A) x 60mm (L) x 11.3mm (A) /  
4-1/16" (A) x 2-23/64" (L) x 3/64" (A)

Peso: 57g (1.93 oz)

*(Sujetas a cambios sin previo aviso)*

This limited warranty is only effective upon presentation of proof of purchase (bill of sale) to Canon U.S.A. or Canon Canada Factory Service Center, Canon Calculators, when delivered to you in a new condition in the original container, are warranted against defective materials or workmanship as follows: for a period of one (1) year from the date of original purchase, defective parts or Calculators returned to a Canon U.S.A. or Canon Canada Factory Service Center and proven to be defective upon inspection, will be exchanged at Canon U.S.A.'s or Canon Canada's sole option, for new or comparable rebuilt parts or calculators (of the same or similar model). Warranty for replacement shall not extend the original warranty period of the defective calculator.

When returning Calculators under this limited warranty, you must pre-pay the shipping charges, if any, and enclose a complete explanation of the problem. Calculators covered by this limited warranty will be repaired at Canon U.S.A.'s or Canon Canada's sole option, and returned to you without charge by any Canon U.S.A. or Canon Canada Service Center. This warranty does not cover rechargeable batteries that may be supplied with the Calculator, as with which batteries there shall be no warranty or replacement.

Information Technology Services and CANON CANADA INFORMATION/SERVICE CENTER will refer you to the nearest Factory Service Center. Repairs not under warranty will be at such cost as Canon U.S.A. or Canon Canada may from time to time generally establish.

This limited warranty covers all defects encountered in normal use of the calculators, and does not apply in the following cases:

- Loss or damage to the Calculators due to abuse, mishandling, alteration, accident, electrical current fluctuations, failure to follow operating instructions, maintenance and environmental instructions prescribed in Canon U.S.A.'s or Canon Canada's instruction manual or service performed by other than a Canon U.S.A. or Canon Canada Factory Service Center.
- Use of parts (other than those distributed by Canon U.S.A. or Canon Canada) which damage the Calculator or cause abnormally frequent service calls or service problems.
- If any Calculator has had its serial numbers or dating altered or removed.
- Loss or damage to the Calculator due to leaking batteries (other than rechargeable batteries supplied as original equipment with the Calculator by Canon U.S.A. or Canon Canada) or water damage.

**NO IMPLIED WARRANTY (OR CONDITION)\* INCLUDING ANY IMPLIED WARRANTY (OR CONDITION)\* OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, APPLIES TO THE PURCHASE OF REVENUE OR PROFITS. PERIOD OF EXPRESS WARRANTY STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTY, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THE CALCULATORS SHALL BIND CANON U.S.A. OR CANON CANADA. (SOME STATES OR PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS DO NOT APPLY TO YOU), NEITHER CANON U.S.A. NOR CANON CANADA SHALL BE LIABLE FOR LOSS OF REVENUE OR PROFITS. FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR FOR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE CALCULATOR, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF CANON U.S.A. OR CANON CANADA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, NOR SHALL RECOVERY OF ANY KIND AGAINST CANON U.S.A. OR CANON CANADA BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE CALCULATOR SOLD BY CANON U.S.A. OR CANON CANADA AND CAUSING THE ALLEGED DAMAGE, WITHOUT LIMITING THE FOREGOING, YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF USE, MISUSE OR INABILITY TO USE ANY CALCULATOR SOLD BY CANON U.S.A. OR CANON CANADA NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF CANON U.S.A. OR CANON CANADA. (SOME STATES OR PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU) THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF ANY CALCULATOR OR THE PERSON FOR WHOM IT WAS PURCHASED AS A GIFT AND STATES YOUR EXCLUSIVE REMEDY.**

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

Canon U.S.A., Inc. One Canon Plaza, Lake Success, New York 11042-1198  
Canon Canada Inc. 6390 Dixie Road, Mississauga, Ontario L5T 1P7 \*CANADA

Canon Information Technology Services in the United States

For all general inquiries, operational assistance, accessory orders or for the location of the nearest service facility for this product in the United States, please contact:

Canon U.S.A., Inc.  
One Canon Plaza, Lake Success, NY 11042,  
Customer Relations Division  
1-800-628-4040

Please keep a copy of your original bill of sale. In order to obtain warranty service, you will need to present a copy of your original bill of sale from your Consumer Calculator retailer at the time of service.

Also please keep all packing materials and the original packing box to protect your equipment, should you need to transport it for service.

Canon Information/Service Centers in Canada

Should service be necessary, please call 1 800-OK CANON for information regarding the nearest Authorized Service Facility:  

|   |  |   |
|---|--|---|
| Canon Canada Inc.<br>2828 16th Street, N.E. Calgary,<br>Alberta T2E 7K7 | Canon Canada Inc.<br>5990 ch Côte-de-la-Lesse,<br>Montréal, Québec H4T 1V7 | Canon Canada Inc.<br>6390 Dixie Road, Mississauga,<br>Ontario L5T 1P7 |
|---|--|---|

#### CANON ELECTRONIC BUSINESS MACHINES (H.K.) CO., LTD.

17/F, Ever Gain Plaza, Tower One, 82-100 Container Port Road,  
Kwai Chung, New Territories, Hong Kong

#### CANON U.S.A., INC.










One Canon Plaza, Lake Success, NY 11042, U.S.A.








#### CANON CANADA INC.

6390 Dixie Road, Mississauga, Ontario, L5T 1P7, Canada

#### CANON LATIN AMERICA, INC.


All Manuals Search and Downloads, U.S.A.

| CALCULATION<br>                            | OPERATION<br>  | DISPLAY<br>12345678  |
|--|--|--|
| <b>▼ Mixed / Mixta</b><br>140-35+22=127<br>2x2③=6<br>-7x9=-63<br>9÷5x3.2+7=12.76<br>(2+4)÷3x8.1=16.2                       | <br>140 <b>=</b> 35 <b>+</b> 22 <b>=</b><br>2 <b>x</b> 2 <b>=</b> 3 <b>=</b><br>7 <b>=</b> 9 <b>=</b><br>9 <b>÷</b> 5 <b>x</b> 3 <b>.</b> 2<br><b>+</b> 7 <b>=</b><br>2 <b>+</b> 4 <b>÷</b> 3 <b>x</b><br>8 <b>.</b> 1 <b>=</b>   | ( 0.)<br>( 127.)<br>( 6.)<br>(- MINUS 63.)<br>( 12.76)<br>( 16.2)  |
| <b>▼ Constant / Constante</b><br>2+3=5<br>4+3=7<br>1-2=-1<br>2-2=0<br>2x3=6<br>2x4=8<br>6÷3=2<br>9÷3=3                     | 2 <b>+</b> 3 <b>=</b><br>4 <b>=</b><br>1 <b>-</b> 2 <b>=</b><br>2 <b>=</b><br>2 <b>x</b> 3 <b>=</b><br>4 <b>=</b><br>6 <b>÷</b> 3 <b>=</b><br>9 <b>÷</b> 3 <b>=</b>  | ( 5.)<br>( 7.)<br>(- MINUS 1.)<br>( 0.)<br>( 6.)<br>( 8.)<br>( 2.)<br>( 3.)                                    |
| <b>▼ Power, Fraction / Power, Fracción</b><br>3 <sup>4</sup> =81<br>1/5=0.2<br>1/(2x3+4)=0.1                               | 3 <b>x</b> <b>=</b> <b>=</b> <b>=</b><br>5 <b>÷</b> <b>=</b><br>2 <b>x</b> 3 <b>+</b> 4 <b>÷</b> <b>=</b>  | ( 81.)<br>( 0.2)<br>( 0.1)   |
| <b>▼ Square Root / Raíz cuadrada</b><br>$\sqrt{3} = 1.7320508$   | 3 <b>√</b>   | ( 1.7320508)   |
| <b>▼ Reciprocal Calculation</b><br>1/7=0.1428571   | 7 <b>1/x</b> <b>=</b>  | ( 0.1428571)   |
| <b>▼ Memory / Memoria</b><br>3x4= 12<br>-) 6÷0.2= 30<br>-18<br>+) 200<br>182   |   <br>3 <b>x</b> 4 <b>M±</b><br>6 <b>÷</b> 2 <b>M±</b><br><br>200 <b>M±</b><br> (Recall Memory)<br> (Clear Memory) | ( 0.)<br>( MEMORY 12.)<br>( MEMORY 30.)<br>(- MINUS MEMORY 18.)<br>( MEMORY 200.)<br>( MEMORY 182.)<br>( 182.) |
| <b>▼ Mark-Up / Mark-up</b><br>Cost \$2,000<br>Profit=20% of Selling Price<br>Selling Price=? (\$2,500)<br>Profit=? (\$500) | 2000 <b>(MU)</b> 20 <b>%±</b><br><b>=</b>  | ( 2'500.)<br>( 500.)   |

| CALCULATION<br>                       | OPERATION<br>  | DISPLAY<br>12345678  |
|---|--|--|
| <b>▼ Mark-Down / Mark-down</b><br>Selling Price \$2,400<br>Profit=20% of Cost<br>Cost=? (\$2,000)<br>Profit=? (\$400) | 2400 <b>(MU)</b> 20 <b>%±</b><br><b>=</b>  | ( 2'000.)<br>(- MINUS 400.)  |
| <b>▼ Overflow / Overflow</b><br>1) 123456x7890<br>=9740740<br>(ERROR)   | 123456 <b>x</b> 7890 <b>=</b><br><br>123 <b>(M±)</b><br>  <br>6 <b>+</b> 0 <b>=</b><br> | ( 9.7406784) <small>ERROR</small><br>( 9.7406784)<br>( 99'999'999.) <small>MEMORY</small><br>( MEMORY ERROR) <small>MEMORY ERROR</small><br>( 0.) <small>MEMORY</small><br>( 0.) <small>MEMORY</small><br>( 99'999'999.)<br>( 0.) <small>ERROR</small><br>( 0.) <small>ERROR</small> |

## REPLACE BATTERY


**ENGLISH**

After replace the battery, press the  key to restart the calculator.


**CAUTION:** Risk of explosion if battery is replaced by an incorrect type dispose of used batteries according to the instruction.

## SUBSTITUIR LA PILA

**ESPAÑOL**

Después de substituir la pila, Pulse  para reiniciar la calculadora.

**PRECAUCIÓN:** Existe un riesgo de explosión si se utiliza un tipo de pila incorrecto. Sigla las instrucciones para desechar las pilas.



**(Hg)** COMPONENT(S) INSIDE THIS PRODUCT CONTAIN MERCURY AND MUST BE RECYCLED OR DISPOSED OF ACCORDING TO LOCAL, STATE OR FEDERAL LAWS.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>