

EXCALIBUR




Solitaire (370E)

USER MANUAL

SOLITAIRE

HOW TO PLAY

- A) To move the card(s) from one card stack to another card stack press the CARD STACKS button corresponding to the card(s) you want to move and the button corresponding to the location to which you want to move.
- B) To move an ace from the card stack to the suit stack, press the CARD STACKS button corresponding to the card you want to move and the SUIT button.
- C) To turn the sound on & off
 - To begin a new game
 - To select the games. Standard Deal 1, Standard Deal 3, Vegas Deal 1 or Vegas Deal 3
- E) To move an ace from the suit stack to the card stack, press the SUIT STACKS button and the CARD STACKS button corresponding to the location to which you want to move.
- F) To move an ace from the deck to the suit stack, Press the DECK button and the SUIT button.
- G) To uncover the face down cards in a card stack
 - To accumulate the scores in consecutive games of Vegas Deal 1 and 3
- H) To activate the timer after you select a new game
 - To cancel your last move
- I) To display the 1st, 2nd and 3rd card in Standard Deal 3 and Vegas Deal 3 game
- J) To turn off the unit
 - To resume the game in the last game mode
- K) The unit will turn off automatically if no button is pushed for approximately 2 minutes



SCORING SYSTEM:

1) STANDARD STYLE (DEAL 1 AND DEAL 3)

- Each game starts with 0 points.
- 10 points Move each card from deck or card stack to suit stack
- 5 points Move each card from deck to card stack
- 0 points Move each card from card stack to card stack
- 15 points Move each card from suit stack to a card stack
- 20 points Each pass through the deck (for Standard Deal 3 and Vegas Deal 3 game only)
- 100 points After 3 passes through the deck (for Standard Deal 1 and Vegas Deal 1 game only)

2) VEGAS STYLE DEAL (DEAL 1 AND DEAL 3):

Each game starts at 500 points. If you decide to accumulate your scores in consecutive games, press REVIEW button before game starts, and the word 'KEEP' will appear on the screen.

- 52 points Cost per game
- 5 points Move each card to suit stack

3) STANDARD STYLE WITH TIMER OPTION:

If you select the timer option, a special bonus will be awarded if you win the game within a specific time of about 4.5 minutes.

- 2 points - 2 points will be deducted automatically if you exceed 8 seconds after each move

Batteries: Requires 3 AA Batteries (Not Included)

*WARNING:

- 1) Do not use rechargeable batteries
- 2) Batteries are to be inserted with correct polarity.
- 3) Only batteries of the same or equivalent type as recommended are to be used, different types or new and used batteries are not to be mixed.
- 4) Exhausted batteries are to be removed from the unit.
- 5) Do not short circuit the supply terminals.
- 6) Non-rechargeable batteries are not to be recharged.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>