



A 1012 Dynalink 6 In 1 Universal Remote Control

Congratulations on purchasing this learning universal remote control. It contains one of the largest infrared code libraries obtainable for up to 6 different devices.

FEATURES

The 6 in 1 universal remote control is suitable for almost all common brands of TV's (labelled TV on the remote control), DVD players (labelled DVD), digital and analogue satellite receiver and cable boxes (SAT), video recorders (VCR), tuners (AUX), CD players (CD), cassette recorders (AUX), amplifiers and other audio device (AUX). It can operate all of the main functions of your device.

For preprogrammed codes, all you have to do is to choose the device for which you wish to control (for example TV) and choose one each of the 3-digit code numbers from the brand code list (for example 001 under Philips TV) until your TV buttons are programmed. After set up it will remember all the codes even when batteries are removed / changed.














Alternatively, the unit has an "Auto Search" to scan the code library in case you can't find a suitable code under the brand, or you can not find your device brand in the list.

The remote control also has a "learn" function to learn a new code from an original remote control if your the remote control does not have your remote pre-programmed.

Other features include a "Device shift" which allows you to change a device button(s) to work as another device. E.g. you can set up a TV code in the AUX and then you will have 2 TV device keys. "Volume lock" (for VOL+/VOL-) allows you to control only the volume from one device. This is very useful for controlling amplifier volume in a home theatre, ie you can control the volume without switching devices. "Write-protection of Device Codes" can protect the device codes from being inadvertently overwritten or deleted

Button Functions



SET	For set up of the remote control.
TV, VCR, SAT, CD, DVD, AUX	Selects the device you want to control.
	Turns the device on and off
-/--	To switch over to 1 or 2 digit number entry
0-9	The number keys operate the same as on your original remote control, and may also be used for entering device codes during set up.
AV	Operates like the TV/Video button on your original remote, and TV/SAT key on your original satellite remote.
MENU	Menu or on-screen display function
CHAN +/-	Channel up and down keys
VOL +/-	Volume up and down keys
Mute	To mute the sound output
	Rewind or fast reverse
	Play
	FF or fast forward
	Record
	Stop
	Pause
	Up, down, left, right keys
OK	OK/Enter key
EXIT	Exit key
Red/Grn/Ylw/Blue	TV teletext/programming buttons
	Television video
	TV and text mixed
	Teletext mode
	Page hold
	Displays info on the selected channel

Battery Installation

This remote control requires 2 AAA batteries to function. Fresh Alkaline batteries are recommended. To install the batteries:

1. Turn the remote back, and lift the battery cover off.
2. Insert the batteries, matching the batteries to the (+) and (-) marks inside the battery compartment.
3. Slide the battery cover back into place. All data that has been set up will be saved in memory even when the batteries are removed, however the clock may need setting again.

Operating Instructions

A. Set up by Brand Code:

1. In the rear of this manual find the brand name and code no of your device brand (e.g. Philips 001, 004, 016 ...). Note: Ensure you select the correct device type numbers from the list (eg TV for TV as labelled at the top of each section in the rear of this manual).
2. Hold down the SET key and the device key (e.g. TV) at the same time. The TV device key on your remote control will light up, showing that the remote is now in set-up mode.
3. Enter the 3-digit device code (e.g. 001 for Philips TV) within 10 seconds. If there is no button entry within 10 seconds, the set-up mode is automatically terminated.
4. The LED goes out if the code has been accepted by the remote control. If the LED flashes twice, that means the code may be wrong, and the remote control

remains in set-up mode. If this occurs you should enter the correct code from the list again within 10 seconds.

5. Once programmed, check the function of the keys on A 1012 remote control. If most keys on your new remote control do not function correctly, try another 3-digit device code (e.g. 004...) from the list under the same brand. Repeat steps 3 to 6 until all the basic functions operate correctly.
6. To leave set up mode, press the device key (e.g. TV). If you do not actuate any keys within 10 seconds it will automatically exit set up mode.

B. Set up by Automatic Search:

If setting up by brand name and codes is unsuccessful, or you can not find your brand name in the list, you can use the "Automatic Search" to find the correct code for your remote control.

1. Switch on the power for the device that you want to control.
2. Point the A 1012 remote control at your device. Press the SET and the device (e.g. TV) keys simultaneously and hold them down for 3 seconds. The device key will flash, showing the remote control is now in Automatic Search mode.
3. When the correct device has been found, the remote control will send an OFF signal to the device from the remote control (code scan). When the device (e.g. TV) switches off, immediately press any key (except SET key) to stop the Automatic Search.
4. Switch the device on again by pressing the "POWER" key to check the operation. Check the functions of other keys on the remote control. If most or all of the keys do not function correctly, repeat the automatic search again ensuring you press any key immediately when your device turns off. If most key's function properly then the set up is successful. Press the device key (e.g. TV) again to save the code and finish the set up.

Note 1 .To abort the "Automatic Search", press any key (except set key). The LED lamp will go out and the search is terminated.

Note 2 .The "Automatic Search" will be terminated automatically after it goes through all codes, and the LED will extinguish.

C. Setting up by Manual Search:

If setting up by brand name and codes is unsuccessful, you can also use the "Manual Search" to find the correct code for operating your device.

1. Switch on the device that you want to control.
2. Point the A 1012 remote control at your device. Press and hold the SET key and press the device key (e.g. TV) in a short time (less than 3 seconds, to prevent the unit going to Automatic Search), then release both pressed keys.
3. The device key will light up continuously and the remote control is now in set-up mode.
4. To search for your device press the POWER (ON/OFF) key about every 1.5 seconds. The POWER button will now flash, showing that the remote control is in Manual Search mode. When your device has been found the device will switch off. Alternatively, if the device being sought is a video recorder, DVD player, CD player, AUX etc., you can also press the PLAY instead of POWER and search for PLAY activation. Once the searched device starts PLAYing the A 1012 is programmed. Test the functions of other keys (don't press POWER button or PLAY button, as the remote will go to next code) on the remote control. If most of the buttons do not function properly, continue to press the POWER key about every 1.5 seconds again to search for the next activated code that turns the POWER OFF or starts PLAYing. If most of the keys on the remote control work well, you can save the code by pressing the device key (e.g. TV) to finish the Manual Search.


Note 1 .The Manual Search will be automatically terminated if no entry is made within 30 seconds.

Note 2 .The "Manual Search" will be terminated automatically after it goes through all codes and LED will light off. But you can start it again if necessary.

D. Set up by Learning

The LEARN function is used to either program codes from a remote control not in the pre-programmed codes list, or to supplement the preprogrammed codes. In learn mode, you need the original device remote control to learn the codes. Please use fresh batteries for both the learning remote control and the original.

To learn place the remote controls next to each other as shown below. In learning mode the remotes must not be more than 30 mm apart, with the remotes in a straight line. The receiver LED on the A 1012 for learning is next to the transmitter LED.



1. To learn, press and hold the Learn key and press the A 1012 device type button that you want to learn (e.g. DVD), then release both pressed keys. The DVD device button on your new remote control blinks and the A 1012 remote control is now in learning mode for DVD codes.
2. Press and release the A1012 remote button that you want to learn to (e.g.POWER). The device button now illuminates continuously.
3. Press and hold the source button on your original remote control (e.g.POWER) until the LED on your new remote control blinks 2 times and illuminates continuously for 2 seconds, then blinks again. (This means you have learnt the POWER signal from the original remote. You're A 1012 remote control is now ready to learn the next button
4. Repeat steps 2 to 4 to learn all required buttons.

If there is a learning problem, the light blinks 4 times and lights up for 2 seconds then blinks. Repeat learning steps again to learn the required button. When learning is finished, to exit the learning mode, press and release LEARN key.

Note 1. The remote will exit learning mode if no key press for 30 seconds .

Note 2. You can press SET and 4 together to delete all buttons you have learnt under a device button. Ensure you select the device button first. The device LED will flash 2 times to confirm.

Note 3. If the remote controls memory is full, the LED will blink 4 times then exit learning.

Note 4. The last learnt signal will overwrite the previous signal stored in that device and button. About 100 commands can be stored in this remote control and about 40 commands can be learnt for one device.

Other Functions

A. Display the Device Code:

The device code, which has been set up in your new remote control, can be called up as follows:

1. Press the SET key and hold it down. Now actuate number "1" key to display the 100th position of the 3-digit code. Count the number of times the LED flashes. If the LED doesn't flash, that means the digit is ZERO.
2. Similarly, press the SET key and hold it down, at the same time actuate the number "2" key to display the 10th position of the 3-digit code. Count the number of times the LED flashes.
3. Press the SET key and hold it down, at the same time actuate number key "3" to display the 1st position of 3-digit code. Again count the number of times the LED flashes.

For Example, for Code 028:

- a. Press SET and "1", LED flashes 0 times, no flashes.
- b. Press SET and "2", LED flashes 2 times.
- c. Press SET and "3", LED flashes 8 times.

B. Reset / Delete Function:

To delete the codes which have been set up in the remote control, press and hold down the SET key, then press the "0" key simultaneously for more than 3 seconds. Release both pressed keys. The LED will flash twice and all preprogrammed and learned commands in the remote control are deleted.

C. Device Shift

Device Shift allows one device's buttons to be programmed under another device. E.g. If you have 2 TV's you can set up a TV code under AUX, or you can set up a CD under DVD.etc.

To set up a device under another device name:

1. Press the [SET] key and hold it, and then press the device button you want to change. Release both pressed keys. e.g. To change AUX to another device type, press AUX. The LED under AUX will be illuminated.
2. Press the new device button that you want to use e.g.[TV]. The LED under TV button flashes.
3. Press SET and AUX (as a TV device now), then input the TV code from the "set up by device brand code" to finish the set up.

Note

1. All devices buttons can be set to be another device type except TV.
2. If you want to revert to previous device, press the [SET] key and hold it, then press the device eg [AUX] button. The LED will illuminate. Release both pressed keys, and then press AUX device button again. The LED will extinguish. Then AUX is now an AUX button.
3. A Shifted device can only be programmed via code set up (and not auto search). The code lock will function on a shifted device but all other functions such as "Volume lock" etc will not work.

D. Volume lock

This function makes it very convenient when you only require one device to adjust volume. For example, you may use your amplifier as your main volume control.

Any or all devices can be programmed so that for example the amplifier volume or Mute is adjusted when using the other device(s), without switching to the amplifier.

The Volume and Mute on the on remote control will still control the volume and mute of your amplifier.

To set the Volume Lock feature:

1. Press the device button which you want to lock. E.g. [AUX]
2. Press [SET] and [5] the current VOL and Mute will be locked. The LED will flash twice to confirm.

To unlock the Volume Lock feature, Press [SET] and [6] to unlock it.

E. Write-protection of Device Codes:

To protect the device codes from being inadvertently overwritten / deleted, you can carry out the following:

1. Press the device key (e.g. TV) that you would like to protect on your remote control.
2. Press and hold down the SET key and press the "7" key at the same time. Then release both pressed keys. The LED will flash twice and the code is then protected from being overwritten/deleted.

To cancel write protection, press the SET key and hold it down, and press the "8" key at the same time, and then release the both pressed keys. The LED flashes twice and the protection has been cancelled.

Device Brand Code List

TV	
Brand	TV
Accent	023
Acme	004,010,313
Acura	010,309
ADA	015
ADC	002,006
Admiral	001,002,003,020,050,054,109,187,196,197,234,308
Adyson	004,186,210,213,296
Agashi	185,187,212,214,296
Agazi	003,308
Agb	124
Agef	234
Aiko	004,005,010,023,296,309
Aim	023
Aiwa	088,213,318,339
Akai	007,009,010,011,012,023,052,062,069,070,071,134,142,170,185,221,296,309,314,317,340
AKI	185
Akiba	012,023,101,212
Akito	023,026
Akura	003,012,016,023,072,101,185,191,212,308
Alba	309,317,326
Albe	004,010,012,023,028,029,054,063,069,087,163,170,184,185,187,195,198,215,217,296
Albiral	038,185,207
Alcyon	209
Alkos	165
Allorgan	021,027,195,212,219
Allstar	023,052
Amplivision	004,198,207,214,228
Amstrad	003,010,012,014,023,031,069,070,072,075,109,124,226,308,309,317,341
Anam	010,066,110,309
Anglo	010,309
Anitech	003,010,016,023,044,110,183,184,209,224,231,308,309
Ansonic	010,015,023,198,275,309
Arcam	296
Arcam delta	004
Arc en ciel	046,127,140,204,207
Aristona	016,023,052,170,195
A.R.Systems	023
ArthurMartin	159
Art-tech	212
ASA	001,017,018,019,050,111,234
Asberg	023,044,052,182,187,195,209
Astra	010,309
Astro sound	207,212
Asuka	003,004,012,101,212,214,218,296,308
Atlantic	004,021,022,023,052,170,182,197,296
Atori	010,309
Audiosonic	004,010,012,021,023,052,140,170,198,309
Audioton	004,182,198,231,233
Ausind	044,209,212
Autovox	001,003,004,021,044,058,102,126,209,234,308
AWA	023,296

A 1012 Dynalink Learning Universal Remote Control

Baird	140,185,186,200,232
Bang&olufsen	001,234
Barcom	210
Basic line	010,012,023,052,101,184,186,212,309
Bastide	004
Baur	023,077,119,133,142,170
Bazin	183,185,201,217
Beijin	263
Beknteknik	228
Beko	008,023,035,084,198,214,228,311,342
Beon	023,052,170
Best	114,115,198
Bestar	023,052,116,198,228,321
Binatone	004
Black diamond	326
Black star	130
Blacktron	101,212
Blackway	101,212
Blaupunkt	009,113,120,136,179
Blausonic	207
Blue sky	012,023,101,212,228
Blue star	101,121
Bondstec	130
Boots	004,026
Boston	208,218
BPL	023,096,101,121
Brandt	037,046,047,127,128,140,204
Brinkmann	023
Brion vega	001,023,052,058,170,208,234,343
Bristol	208
Britannia	004,296
Bruns	001,008,040,227,234
BSR	027,132,197,210,212,215
BTC	012
Bush	010,012,020,023,025,026,028,029,033,052,063,069,101,116,121,132,133,140,168,170,172,309,317,320,321,326
California	195
Capsonic	003,214,308
Carad	023
Carena	023,212,214
Carrefour	028
Cascade	010,023,309
Casio	023,201
Cathay	023,052,170
CCE	023
Centrum	325,326
Centurion	023,052,170
Century	001,191,234
CGE	044,054,130,132,187,198,204,209
CGM	226,233
Changhong	241,242,245,246,247,248,264,278,279,288
CIE	196,212,226
Cihan	214
Cimline	010,029,212,213,309
City	010,309
Clarivox	038,040,170
Clatronic	003,004,010,012,023,031,044,052,084,130,185,198,209,212,214,308,309
Cofadel	204

A 1012 Dynalink Learning Universal Remote Control

Colombia	228
Colombus	182
Concorde	010,309
Condor	004,022,023,052,084,101,182,184,187,198,211,296
Conrowa	265
Contec	004,010,028,030,031,211,212,217,296,309
Cont.ediso	204
Continentaledison	037,046,047,112,127,140
Cosmel	010,309
Crezar	182,226
Crosley	001,044,130,132,209,234
Crown	010,023,044,052,054,084,096,115,122,170,198,209,228,309,371
Cs electronics	004,012,130,296
CTC	130
CTC clatronic	015,187,198,207,210,212,226
Cybercom	308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Cybermaxx	308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Cybertron	012
Cytron	308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Daewoo	004,010,023,052,059,095,116,196,296,309,321,345
Dainichi	012,212,296
Dansai	003,023,052,170,212,296,308
Dantax	035,149,162,198,213,326
Datronic	196,211
Datsura	096,122
Dawa	023,195
Dayton	010,309
Daytron	023,196
Deawoo	023
Decca	004,011,023,026,031,052,124,170
Decca(uk)	229
De graaf	007,020,034
Deitron	023
Denko	185,214
Denver	211,212
Desmet	023,052,170,182
Diamant	023
Digiline	023,213
Digital	212
Dixi	010,023,040,052,170,309
Domland	219
Domoh	182
Drean	023
DTS	010,309
Dual	004,023,090,126,127,132,140,161,185,195,197,207,211,219,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,332,333,334,335,338
Dual-Tec	004,010,132,197,309
Dumont	001,004,015,018,019,234
Dux	023,170,195
Dynatron	023,052,170
Elbe	023,038,109,158,180,198,275
Elcit	001,234
Electa	121

A 1012 Dynalink Learning Universal Remote Control

Electro Tech	010,309
Elekta	101
Elektroniska	207
ELG	023
Elin	004,017,019,023,052,170,181,186,197,233,296
Elite	012,022,023,052,179,184,197
Elman	015,132,207,213
Elsay	184,229
Elta	010,296,309
Emerson	001,023,101,128,142,234
Emperor	101
Engel	207,227
Erres	016,023,052,170
ESC	023
Estel	207
Etron	010,023,309
Eurocom	207,212
Euro-Feel	003,308
Euroline	089,170
Euroman	023,185,196,198,212,214,296
Euromann	003,004,052,115,308
Europa	023,228
Europhon	004,015,023,026,052,073,124,132,207,226
Eurotronic	228
Expert	021,186,188,197
Exquisit	023
Fenner	010,116,184,191,195,212,309,321
Ferguson	036,037,038,051,053,082,112,128,164,170,232
Fidelis	182,211
Fidelity	004,020,023,069,097,296,317
Filsai	217
Finlandia	007,020,111,129,181,186,200
Finlux	001,004,011,015,017,018,019,023,044,052,064,111,124,132,158,168,170,181,209,225,234,314,315
First Line	004,010,023,027,052,063,130,183,296,309
Fisher	001,004,007,019,028,030,040,041,084,132,195,198,200,211,227,234
Flint	023,052,149,183,184,187,196,214
Formenti	001,002,004,022,044,126,132,134,170,182,209,234,296
Fortress	001,002,234
Fraba	023,198
France Concept	184
Friac	023
Frontech	003,010,020,050,069,119,130,183,184,191,213,308,309,317
Fujitsu	011,021,197,207,212
Funai	003,027,211,212,308,346
Galaxi	023,054,084
Galaxis	023,198
Galeria	196
Galway	184
GBC	010,028,132,226,233,309
GCM	195,212
GEC	004,011,023,042,050,052,124,133,142,170
GEC(UK)	186,224,229,231
Geloso	010,020,132,231,309
General Technic	010,309
Genexxa	012,023,050,052,212

A 1012 Dynalink Learning Universal Remote Control

Germanvox	226
Goldhand	231,296
Goldstar	004,010,013,020,023,052,085,094,130,132,170,172,198,206,210,223,296,309,326,344
Goodmans	003,010,011,023,028,029,052,069,094,112,116,128,154,170,206,230,308,309,317,321,326
Gorenje	084,115,198
GPM	012,210,212
Gradiente	023
Graetz	050,142,143,188
Granada	004,007,011,020,023,028,032,041,044,052,055,065,124,128,129,134,135,139,170,209
Grandin	010,012,023,101,121,170,184,309
Gronic	180,191,212
Grundig	009,018,023,044,092,102,117,118,136,137,185,209,347
GTT	187,211
H-150a	276
Haaz	338
Halifax	003,004,296,308
Hampton	004,183,226,296
Hanseatic	004,008,010,022,023,027,028,052,074,096,101,119,132,142,170,198,234,275,309
Hantarex	010,023,124,309
Hantor	023
Harwood	023,186,326
Hauppauge	023
HCM	003,004,010,023,075,101,121,200,211,226,308,309
Hemmermann	183,201
Hifivox	140,204
Higashi	185
Highline	023
Hinari	007,010,012,023,028,044,052,138,170,200,212,213,227,230,309,326
Hisawa	012,101,121,149,212
Hit	234
Hitachi	004,011,017,020,023,024,028,034,042,045,046,047,048,049,050,086,119,124,132,133,139,140,141,142,143,145,186,224,257,258,280,313,348
Hitsu	185,212
Horizont	306,307
Hornophon	023,052
Hoshai	012,212,233
Huanyu	004,116,296,321
Hygashi	004,296
Hyper	004,010,130,132,226,233,296,309
Hypson	003,004,023,052,101,121,170,212,214,308
Iberia	023
Ibervisao	188,207
Ibico	196
ICE	003,004,010,012,023,052,069,187,210,212,296,308,309,317
ICES	296
Imperial	023,044,050,052,054,084,130,132,187,198,209
Indesit	025,102
Indiana	023,052,170
Ingelen	050,188
Ingersol	010,309
Inno Hit	004,010,011,012,023,052,094,124,170,206,209,211,222,309
Innovation	003,010,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,314,316,317,318,319,320,321,322,324,325,326,327,328,329
Interbuy	010,110,130,309

A 1012 Dynalink Learning Universal Remote Control

Interfunk	001,016,023,050,052,130,140,142,170,198,234
Internal	023
Intersound	182
Intervision	003,004,015,023,101,110,198,308
Irradio	010,012,023,052,069,170,206,209,212,309,317
Iskra	183,231
Isukai	012,023,101,212
ITC	004,132,184,204,233
ITE	207
ITL	196
ITS	012,023,052,069,101,121,212,296,317
ITT	010,050,062,133,134,135,142,143,144,188,220,309,314,349
ITV	023,309,326
JEC	165
Jet Point	199
JVC	028,052,069,082,189,317,350
Kaisui	004,010,012,023,121,212,296,309
Kamosonic	004
Kamp	004,296
Kapsch	021,050,188,197,200
Karcher	004,010,017,023,038,101,170,198,309
Kasai	212
Kendo	015,020,023,029,109,180,183,186,196,197,198,207,213
Kennedy	021,132,182,197,231
Kennex	182,226,233
Kerion	182,212
Kingsley	004,296
Kitt	212
Kneissel	023,175,180,182,196,198,212,275
Kolster	023,052,191,210,214
Konka	012,023,185,238,242,243,244,248,249,254,255,260,261,285,287,289,303,313,373
Kontakt	204
Korpel	023,052,170
Korting	001,022,198,234
Kosmos	023
Kotron	226
Koyoda	010,309
Kronne	180
KTV	004,210
Kuba	186,195
Kuro	096,122,200
Kyoto	038,217
Lavis	211
Lenco	010,023,226,233,309
Lenoir	004,010,196,199,208,211,309
Lesla	130,191
Leyco	003,011,023,027,052,170,214,308
LG	004,010,013,020,023,052,085,089,094,130,132,150,170,172,198,206,210,223,296,309,326
Liesenk	170
Liesenkotter	023,179,195
Life	003,010,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,314,316,317,318,319,320,321,322,324,325,326,327,328,329
Lifetec	003,010,023,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,211,214,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Loewe	023,098,099,198,234,275,351

A 1012 Dynalink Learning Universal Remote Control

Loewe Opta	001,052,170,190
Logik	031
Luma	020,021,023,052,142,170,186,197
Lumatron	020,021,023,052,142,170,308
Lux May	023,052
Luxor	004,020,048,078,094,102,133,139,142,147,206,313
Madison	023,182,212
Magnadyne	001,015,124,130,132,170,191,234
Magnafon	004,015,044,073,124,181,182,183,195,207,209,296
Magnavox	023
Magnum	003,010,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,314,316,317,318,319,320,321,322,324,325,326,327,328,329,378,379,380,382
Mandor	003,308
Manesth	003,004,022,023,029,052,170,182,184,188,213,308
Manhattan	023
Marantz	023,052,170,187,195
Marech	182
Marelli	001,234
Mark	023,052,170,296
Marshall	212
Matsui	004,005,010,011,014,020,023,026,027,028,029,031,052,063,069,092,124,148,149,165,170,174,213,215,309,317
Matsushita	066
Mcmichael	042
Mediascreen	214
Mediator	016,023,052,170,195
Medion	003,010,023,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,211,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
M-Electronic	004,010,017,019,037,050,052,069,110,111,116,140,170,309,317,321
Melectronic	023,296
Memorex	010,309
Memphis	010,011,114,309
Mercury	023
Metz	001,076,081,136,152,153,218,234
Micromaxx	003,010,023,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Microstar	003,010,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Minerva	018,102,136,185,209
Minoka	023,052
Mitsubishi	001,023,028,031,052,055,056,061,099,102,136,171,192,234,276,278,279,280,326,352
Mivar	004,044,074,094,124,193,198,206,209,275,290,291,292,293,294,295,374,375
Morgans	023
Motion	044,209
MTC	133,198
Multi System	170
Multitec	023
Multitech	004,010,015,020,023,028,044,046,130,132,170,198,207,212,233,296,309
Murphy	004,019,134,296
NAD	142
Nagoya	207
Naiko	023
Nakimura	023

A 1012 Dynalink Learning Universal Remote Control

Naonis	020,109
National	065,102,194,284
NEC	023,028,057,331
Neckermann	001,004,009,020,023,052,084,119,133,170,198
NEI	023,052,069,114,170,183,199,212,317
Nesco	130
Neufunk	023
Newmar	182,183,207
Newtech	010,023,052,309
New World	012
Nicamagic	004,296
Nikkai	003,004,011,012,023,052,114,165,170,186,205,211,212,296,308
Nikkei	226,233
Noblex	023,184,199,200
Nobliko	004,015,018,044,209,296
Nogamatic	140,204
Nokia	050,062,064,133,134,135,142,143,144,188,220,314,315,353
Nordic	212,213
Nordmende	023,025,037,046,047,050,052,058,112,127,128,140,204,354
Nordvision	170
Nordway	217
Nortek	233
Novatronic	023,183,187,212,226
Oceanic	050,142,143
Oceanic(F)	188,220
Octan	195
Okano	023,084,187,198,233
Onceas	004,196,211
Onwa	070,196,212
Opera	023
Orbit	023,052
Orion	010,014,022,023,027,029,031,052,063,076,100,124,143,148,160,170,172,213,309,326,355
Orline	023
Ormond	172,326
Orsowe	207
Osaki	003,004,005,011,012,023,075,166,308
Osio	023
OSO	012
Osume	011,030
Otto Versand	002,004,009,022,023,028,052,077,112,119,121,122,132,133,140,142,170
Pael	004,181,185,296
Palladium	004,013,023,084,198
Palsonic	023
Panama	003,004,010,023,166,296,308,309
Panasonic	023,050,065,066,067,068,102,125,142,143,152,153,194,266,286,316,356
Panavision	023
Panda	267
Pathe Cinema	004,022,038,074,132,182,207,211,228,275,296
Pathe Marconi	038,046,047,127,140,204
Pausa	010,309
PCM	211
Perdio	005,011,022,023,182,207,213
Perfekt	023
Philharmonic	185
Philco	001,023,044,054,130,132,187,198,209,234
Philharmonic	004,166

A 1012 Dynalink Learning Universal Remote Control

Philips	001,004,016,023,039,042,044,052,089,090,112,116,132,142,156,170,195,219,234,321,323,357
Phoenix	001,023,052,170,182,195,198,234,296
Phonola	001,016,023,052,170,195,219,234,296
Pioneer	037,050,052,140,146,170,198,216,358
Pionier	198
Plantron	003,023,052,308
Polar	305
Poppy	010,211,309
Prandoni-Prince	020,124,142,182,197,207,209,212
Precision	004,166
Prima	010,050,309
Prinz	048,186,195,217,230,313
PRO2	308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338
Profex	010,044,142,309
Profilo	172,326
Profi-Tronic	023,052
Proline	011,016,023,052,063,184,213,214
Prosonic	023,043,108,162,170,172,198,296,311,320,326
Protech	003,004,010,015,023,052,114,130,132,133,166,170,308,309
Provision	023,170,326
Pye	016,023,052,069,170,195,234,317
Pygmy	208
Pymi	010,309
Quasar	130
Quelle	003,004,017,018,019,023,027,031,052,077,130,132,136,142,151,170,206,308,326
Questa	028
Radialva	023
Radiola	016,023,039,052,170,195
Radiomarelli	001,023,124,130,191
Radionette	017,019,181,188
Radio Shack	023
Radioton	185,211
Radiotone	008,023,052,198
Raduga	307
Rank	018,028
RBM	018
Rc	259
RCA	032
Recor	023
Record	307
Rectiligne	023
Rediffusion	142
Redstar	023
Reflex	023
Revox	023,052,170,190,198
REX	003,020,021,050,109,158,197,308
RFT	001,008,040,198,227,234,275
R-Line	023,052,170
Rm-d	268
Roadstar	003,010,012,023,226,233,308,309,359
Robotron	001,227,234
Royal Lux	198
RTF	001
Rubin	304,306,307

A 1012 Dynalink Learning Universal Remote Control

Saba	001,037,046,047,050,059,112,124,127,128,140,142,143,204,360
Saccs	038
Sadec	212
Sadko	307
Sagem	101,184
Saisho	003,004,010,014,029,031,124,183,213,215,308,309
Saito	207
Salora	020,048,050,094,096,108,109,119,122,129,132,133,135,139,142,186,206,313,314,320,361
Sambers	015,044,073,124,181,207,209,211
Samsung	003,004,010,011,023,031,052,084,091,094,105,106,161,166,170,173,198,199,206,296,308,309,362
Sandra	004,296
Sandra Color	195,231
Sansui	023,052,183,196,212
Sanwa	188
Sanyo	004,007,011,017,019,023,028,030,031,032,040,041,044,074,096,128,132,135,161,198,200,244,252,275,278,296,363
Save	023
SBR	016,023,042,170
Schaub Lorenz	050,142,143,188,220
Schneider	004,012,023,039,052,069,072,126,130,132,140,161,170,317,329,372
Schneider France	195,212,219
Scott	182
SEG	003,004,015,023,028,040,044,089,130,132,170,296,308,326
SEI	023,201,234
SEI-synudyne	001,014,015,027,050,076,124
Seleco	020,021,028,050,109,132,158,197,364
Sencora	010,309
Senday	182
Sentra	165,205,212
Serino	184,212
Sharp	002,006,028,030,060,202,243,365
Shivaki	195,196
Shiwan	212
Shorai	027,212
Siam	023
Siarem	001,015,124,132,180,191,234
Sicatel	038,207
Siemens	009,023,030,136,179,366
Siera	023
Sierra	016,052
Siesta	161,198
Silva	023,211,212,224,296
Silver	028
Singer	001,015,023,130,132,180,188,191,204,211,234,338
Sinudyne	001,014,015,023,027,029,076,132,170,201
Skantic	050,139,147
Skyworth	239,271,272,273,301,338
Sogera	022
Sokol	306,307
Solavox	050,093,188
song	251,269,283
Soniko	214,217,233
Sonitron	007,135,198
Sonneclair	023
Sonoko	003,004,010,023,052,101,170,211,212,214,308,309

A 1012 Dynalink Learning Universal Remote Control

Sonor	007,050,188
Sontec	023,052,161,170,196,198,210,220
Sony	010,011,028,030,031,077,107,128,131,166,203,237,302,309,367
Soundcolor	211,212,214,215
Soundmaster	226
Sound& Vision	012,015
Soundwave	023,052,170
Standard	004,010,012,022,023,052,166,182,183,191,196,309
Starlight	170
Starline	228
Starlite	023,212
Starlux	196,226
Stenway	101,121,185,212
Stern	020,021,050,197
STM	221
Strato	023
Sunic Line	182
Sunkai	010,023,027,063,183,211,212,213,309
Sunstar	023
Sunwood	010,023,052,309
Superla	004,296
Supertech	023,119,212,226,233,296
Supertone	185,207
Supra	010,184,214,309
Susumu	012
Sutron	010,309
Sydney	004,166,296
Sysline	170
Sytong	212,296
Taisho	207,213
Tamashi	212
Tandberg	081,158
Tandy	002,004,011,012,049,050,166
Tashiko	004,020,028,042,057,129,166,296
Tatung	004,011,023,026,052,124,166,170,229
TCL	196,240,241,250,253,274,277,297,298,299,300
TCM	003,010,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338,381,383
Teac	023
Teak	190
TEC	004,010,049,130,132,166,309
Tech Line	023
Technema	182
Technics	066,194
Technisat	040
Tecnema	022
Teinelsa	182,207
Teknant	211
Teleavia	037,046,112,127,140,204
Telecor	023
Telefunken	023,036,037,051,052,053,079,080,102,103,112,127,128,140,164,204,368
Telefusion	023
Telegazi	023
Telemeister	022,023
Teleopta	226
Telesonic	023
Telestar	023

A 1012 Dynalink Learning Universal Remote Control

Teletech	010,023,089,114,130,170,309
Teleton	004,021,081,119,133,166,197
Televideo	022,182,296
Tempest	023
Tennessee	233
Tensai	010,012,019,022,023,027,052,184,185,207,211,213,217,325
Tenson	182
Tesla	180,207
Tesmet	052
Tetran	182,197
Tevion	003,010,023,062,068,069,088,104,108,112,116,155,157,169,172,176,177,178,308,309,310,311,312,313,314,315,316,317,318,319,320,321,322,323,324,325,326,327,328,329,330,331,332,333,334,335,336,337,338,378
Texet	004,166
Thomson	004,023,037,046,047,051,052,053,059,102,103,112,127,128,140,164,167,204,331,369
Thorn	011,019,023,036,038,055,082,112,128,142,165,170,232
Tokai	011,023,052,183,184,210,212,226
Tokyo	004,296
Tomashi	101,121,212
Top Vision	210
Toshiba	018,028,083,165,205,245,270,279,281,370
Towada	050,132
Trans Continens	023
Transonic	023
Transtec	296
Trevi	199,226,233
Trident	166
Triumph	014,023,083,124,181,211,226
Tsoshi	212
Uher	021,022,023,044,050,052,181,184,190,195,197,198,209
Ultravox	001,004,015,023,130,132,134,182,183,186,191,201,234,296
Unic Line	023,182,183,212
Unic Radio	180,188,228
Uniden	212
United	023,089,170,326
UnitedSatellite	228
Universum	003,017,019,023,052,084,103,111,115,123,130,132,170,198,206,209,308,314
Univox	023,038,188,191,195,207,234
Uranya	182,191,211
Utax	211
Vanguard	186,212
Venus	262
Vestel	023,050,052,170,183,199,319,325,326
Vexa	010,023,170,212,231,309
Victor	028,052,066
Video Logic	185
Videologique	004,012,296
Videosat	130
Video System	023,052
Videotechnic	296
Videoton	184,217
Vidion	196
Visiola	004,180,296
Vision	022,023,052,182
Visorex	097
Vistar	049,188

A 1012 Dynalink Learning Universal Remote Control

Vityaz	306,307
Vortec	023,052,170
Voxson	001,020,023,044,050,052,109,189,197,208,209,234
Walkie	197
Waltham	004,023,038,049,139,166,217
Watson	022,023,052,170
Watt Radio	004,015,038,132,187,201,210,231,296
Wega	001,023,028,234
Wellfund	233
Weltblick	023,052,170,182
Weston	132
Wharfedale	023
White	182
White Westinghouse	004,015,022,023,044,170,182,296
Windstar	101
Xoceco	235,236,242,260
Xrypton	023,182
Yamishi	023,101,184,212
Yokan	023
Yoko	003,004,010,012,023,052,166,170,183,198,212,224,296,308,309
Yorx	012,185,196
Zanussi	020,021,109,197
Zoppas	197
7el	256
Others	282

VCR

Brand	VCR
Adelsound	098
Adyson	099
Aiwa	001,002,003,004,017,100,101,102,103,104,105,106,165,166
Akai	003,005,006,007,008,009,019,063,102,105,113,121,145,146
Akiba	041,099
Akitan	107
Akura	003,013,041,099,102
Alba	004,014,015,016,017,019,041,099,101,103,104,105,107,108,109,110,111,113,165,166
Allorgan	073,145,169
Allstar	114,115
Ambassador	019
Amstrad	002,022,023,099,101,108,116,117
Anitech	041,099,114
Anitsch	091
Ansonic	098
Aristona	115
ASA	025,026,086,106,115
Asuka	002,025,026,041,099,101,106,115,118
Audiosonic	108
Audioton	019
AWA	106,108,119,120
Baird	002,003,005,014,027,028,045,101,102,107,108,121,122,123
Basic line	004,014,019,041,099,103,108,165
Baur	026,032
Bestar	014,019,108
Black Panther	108
Black panther line	014

A 1012 Dynalink Learning Universal Remote Control

Blaupunkt	026,029,030,031,032,039,071,115,125,126,127,128,129,130,167
Blue sky	099,103,104,105,106
Bondstec	019,099
Brandt	066,067,102,131,132,133,134
Brinkmann	103,104
Brion vega	033,135
Broksonic	042
Bush	004,014,015,016,017,041,052,099,101,103,104,105,107,108,109,110,113,136,165,166
Canon	137
Carena	103,115
Carrefour	138
Casio	101
Cathay	108
Catron	019
CGE	002,003,101,102
CGM	089
Cimline	004,041,099,103,165
Clatronic	019,099
Combitech	017,105,166
Condor	014,019,107,108
Crown	014,019,041,099,108,114
Cybercom	165,166,167,168,169,170
Cybermaxx	165,166,167,168,169,170
Cytron	165,166,167,168,169,170
Daewoo	014,019,034,040,079,103,105,108,138,170
Dansai	041,099,107,108
Dantax	165
Daytron	014,108
Decca	002,003,026,101,102,104,115,142,143
De graaf	026,035,115,122,139,140,141,147
Deitron	108
Denko	099
Diamant	106
Domland	103
Dual	003,026,101,102,108,115,165,166,167,169,170
Dumont	002,026,035,045,101,115,122,144
Elbe	062,108,118
Elcatech	099
Elin	021,145
Elsay	099
Elta	041,099,107,108
Emerson	053,099,138
ESC	014,019,108,145
Etzuko	041,099
Europhon	019
Fenner	019
Ferguson	003,028,039,043,046,057,067,101,102,108,123,133,134,146
Fidelity	002,099,101,116,145
Finlandia	026,035,045,101,115,122,139,140,147
Finlux	002,003,005,026,035,045,050,061,101,115,122,144,147
First Line	004,025,034,035,041,061,099,103,104,106,108,120,136,138,147,148,165
Fisher	019,044,045,118,122,141,149,150
Flint	004,103,165
Formenti-Pheonix	026
Frontech	019,114
Fujitsu	002,101

A 1012 Dynalink Learning Universal Remote Control

Funai	002,101
Galaxi	101
Galaxy	002
GBC	019,041
GEC	026,115
Geloso	041
General	019
General Technic	004,017,038,073,104,165,166,167,169
Genexxa	122
Goldhand	041,099
Goldstar	002,025,101,106
Goodmans	002,014,019,021,025,028,041,047,048,099,101,103,104,106,108,115,129,136, 145,151,152
Gradiente	142
Graetz	003,033,045,102,122,135,145
Granada	010,026,029,035,039,045,049,101,106,115,122,127,140,141,145,147
Grandin	002,014,019,025,041,099,101,103,106,108
Grundig	026,029,032,039,041,050,051,052,054,084,104,115,127,128,129,133,153,154, 155
Haaz	165
Hanimex	105,107
Hanseatic	025,026,103,106,108,115
Harwood	099
HCM	041,052,099,114
Hinari	004,017,041,052,053,098,099,102,103,105,108,114,136,148,152,156,165,166
Hisawa	004,103,105,165
Hitachi	002,003,026,035,037,098,101,102,115,129,139,144,145,147
Hornophon	115
Hypson	004,041,099,103,105,108,165
Impego	019
Imperial	002,101,145
Ingersoll	098,103,145
Inno Hit	014,019,021,026,041,099,108,114,145
Innovation	004,017,038,073,165,166,167,169
Interbuy	025,106
Interfunk	026,045,099,115,122
Internal	108
International	108
Intervision	002,101,103,104,106,107,108
Irradio	025,041,099,106,115
ITT	003,005,033,045,055,056,102,121,122,135,141,145,157
ITT/Nokia	082,084,085,088,089,090,092,140
ITV	014,019,025,106,108
JVC	003,056,057,058,059,060,102,132,142,143,157
Kaisui	041,099
Karcher	026,108
Kendo	004,005,006,014,019,034,063,099,103,104,106,113,121,146,165
Kenwood	003,102,118
Kimari	149
Kneissel	103,104,105,106
Korpel	041,099
Kuba	149
Kuwa	029
Kyoto	099
Lenco	014
Leyco	041,099,148
LG	002,025,101,106,108

A 1012 Dynalink Learning Universal Remote Control

Lifetec	004,017,038,073,103,104,165,166,167,168,169,170
Loewe	031,036,098,106,115,126,127,144,158,159,167
Loewe Opta	025,026,039
Logik	021,041,098,099,103,121,145
Luma	093
Lumatron	014,108
Luxor	005,045,047,061,099,120,121,122,141,149,151
Magnasonic	045
Magnavox	115,129
Magnum	172
Manesth	034,041,099,103,115,138
Marantz	026,039,047,062,103,107,115,118,127,151,160
Mark	019,108
Marquant	114
Matsui	004,017,025,053,064,098,101,103,104,105,106,107,111,117,145,148,156,165,166
Mediator	026,115
Medion	004,017,038,073,103,104,105,165,166,167,168,169,170
Melectronic	002,101,106,118
Memorex	002,010,025,044,045,101,106,122,140,141,149
Memphis	041,099
Metz	029,030,031,032,039,084,115,125,126,127,128,153,158,159,161,167
Micormay	104
Micromaxx	004,017,038,073,103,165,166,167,168,169,170
Microstar	004,017,038,073,165,166,167,168,169,170
Migros	002,101
Minerva	032,039,128
Mitsubishi	002,026,057,061,115,119,120,143,162
Multitech	002,019,026,041,099,101,114,122
Murphy	002,101
NAD	096,122
National	029,031,126,167
NEC	003,057,062,102,106,118,122,143
Neckermann	003,026,033,053,102,115,127,135,156
NEI	026
Nesco	041,099,101,105
Neufunk	103
Nikkai	019,065,099,108
Nobliko	083,097
Nokia	003,005,010,021,033,045,055,102,108,113,115,121,122,135,140,141,145,147
Nordmende	003,056,057,066,067,102,131,133,134,143,148,157
Oceanic	002,003,010,101,102,115,121,122,140,141
Okano	004,063,099,103,104,108,113,114,165
Orion	004,015,017,048,053,064,098,103,104,105,107,109,110,148,152,156,165,166
Orson	002,101
Osaki	002,025,041,099,101,106
Osume	136
Otake	109,110
Otto Versand	026,032,115
Palladium	003,025,039,041,063,098,099,102,103,106,113,127,145
Palsonic	099,101
Panasonic	029,030,031,038,076,125,158,159,161,167
Pathe Cinema	064,098,120
Pathe Marconi	003,102
Penney	062
Pentax	035
Perdio	002,101,103
Philco	062

A 1012 Dynalink Learning Universal Remote Control

Philips	012,026,039,054,056,077,115,127,129,160
Phonola	026,115
Pioneer	026,057,115,143,147
Portland	014,019,107,108
Prinz	002,101,148
PRO2	165,166,167,168,169,170
Profex	041,114
Profi-Tronic	115,145
Proline	002,052,101,133,134,136
Prosc0	108
Prosonic	101,103,107,108,165
Protech	115
Provision	108
Pye	026,115
Quartz	045
Quelle	002,026,027,032,033,039,045,053,115,127,135,156
Radialva	099,106,115,140
Radiola	026,115
Rank	102
RCA	094
REX	003,056,102,157
RFT	019,026,099,129
Roadstar	014,021,025,041,099,106,108,145
Royal	099,114
Saba	003,046,056,066,067,081,102,108,131,132,133,134,151,157
Saisho	004,017,041,053,064,098,103,104,111,148,156,165,166
Salora	005,045,055,061,120,121,122,141
Samsung	021,073,074,145,163,169
Samurai	019
Sansui	003,013,057,099,102,104,114,121,143
Sanwa	098
Sanyo	027,044,045,122,140,141,143,149
Saville	017,105,107,108,145,166
SBR	026,115
Scan Sonic	145
Schaub Lorenz	002,003,005,033,045,101,102,113,121,122,135
Schneider	002,004,014,019,025,026,034,041,099,101,106,108,115,145,165
Seaway	108
SEG	021,041,099,108,114,119,145
SEI sinudyne	026,098,115
Seleco	003,019,102,106,142,157
Semivox	103,138
Sentra	019,099,136
Setron	041
Setron	099
Sharp	010,011,047,106,140,151
Shintom	041,045,099,122
Shivaki	025,106
Shorai	098,148
Siemens	025,032,039,045,050,106,115,122,127,128,150,155,160
Siera	115
Silva	025,106
Silver	108
Sinudyne	026,098,115
Solavox	019
Sonitron	149
Sonneclair	099

A 1012 Dynalink Learning Universal Remote Control

Sonoko	014,108
Sonolor	010,140
Sontec	025,106
Sony	018,020,024,070,071,072,075,078,112,121,124,130,161,164
Soundwave	103,106
Ssangyong	099
Standard	014,108
Starlite	106,122
Stern	108
Strong	013
Sunkai	004,103,104,108,165
Sunstar	002,101
Suntronic	002,101
Sunwood	041,099
Supra	106,145
Symphonic	099,101
Taisho	004,098,103,148,165
Tandberg	032,053,108
Tashiko	002,010,101,106,115,140,145
Tatung	002,003,026,101,102,103,104,115,120,140,146
TCM	004,017,038,073,165,166,167,168,169,170,171
Teac	100,101,102,106,108,115
TEC	019,099,107,108
Technics	029,031,167
Technisat	103,104
Teleavia	003,102,131
Telefunken	003,056,057,058,066,067,068,069,080,081,102,108,131,133,134,157
Telemeister	095
Teletech	099,101,108,114
Tempest	019
Tenosal	041,099
Tensai	002,025,041,098,099,101,106,114
Tevton	004,017,038,073,103,104,165,166,167,168,169,170
Thomson	003,012,056,057,058,067,080,081,102,132,133,134,157
Thorn	003,045,064,102,106,122
Tivo Hdd	012,078
TMK	087
Tokai	025,041,099,102,106,122
Tokiwa	099
Tonsai	041
Topline	104
Toshiba	003,026,034,056,061,102,115,120,129,138,157,170
Towada	041,099,114
Towika	041
Trakton	019
Triumph	053,156
TVA	019
Uher	025,033,106,135,145
Ultravox	033,107,108,135
Unitech	021,145
United Quick Star	014,107,108
Universum	002,005,009,022,025,026,032,039,054,101,103,104,106,114,115,116,121,127,128,129,145
Vector	062
Victor	057,058,142,143
Video	062
Videon	004,017,038,073,165,166,167,169

A 1012 Dynalink Learning Universal Remote Control

Watson	105,115
Weltblick	025,106
White	085,086
White Westinghouse	033,085,086,135
Xenon	093
Yamishi	041,099,107,108
Yokan	041
Yoko	019,021,025,041,106,145
ZX	103

SAT

Brand	CBL/SAT
AGS	249
Akai	003,125,242
Akena	249
Alba	003,004,005,006,007,008,009,102,133,328
Aldes	007,010,011
Allantide	015
Allsat	012,014,055,125,242
Allsonic	010,029,309
Alpha	242,249
Ampere	024
Amstrad	017,018,019,021,023,154
Andover cablevision	258
Ankaro	010,029,243,244,309
Anttron	004,009,014,247
Apollo	004
Arcon	017,024,025,027,056,243,325
Armstrong	021,242
Asat	125,242
AST	036
Astacom	249,250
Aston	164
Astra	003,021,030,031,032,033,034,093,284
Astro	009,011,029,040,041,042,241,247,309
Astrx	288
Athena	249
Audioton	009,055,247
Aura	034
Axiel	249
Axis	017,029,033,050,309
Barcom	025,243,325
Best	025,029,309,325
Blaupunkt	040,241
Boca	021,093,246
Brain wave	044
Brandt	136,137,138,145,316
Broadcast	043
Brunor	126
BT	249,250
BT cable	260
BT satellite	003,022,145
Bush	005,006,012,045,102,133,328
Cabletime	261,262,263,264
Cambridge	003,046
Camundosat	047

A 1012 Dynalink Learning Universal Remote Control

Canal+	140,174,222
Canal Satellite	245
Century	279
Channel master	007
Chaparral	098
Chess	318
Citycom	005,052,253
Clark	247
Clatronic	044
Clemens kamphus	015,083
Clyde cablevision	265
CNT	011
Colombia	249
Columbus	069
Commander	244
Commlink	010
Comtech	050,051
Condor	029,309
Connexions	039,047,048
Conrad	246,
Contec	050,052,246
Cosat	055
Crown	021
Cryptovision	266
Cybercom	306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Cybermaxx	306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Cytron	306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Daeryung	039
Dansat	012,014
DDC	007
Decca	053
Delega	007
DEW	050
Diamond	054
Discovery	249
Diseqc	250
Disk Express	243
Diskxpress	025,048,325
Distrisat	242
Ditristrad	055
DNT	039,125,242
Dong Woo	092
Drake	056,128
Dual	306,307,308,309,311,312,313,316,317,318,319,320,321
Dynasat	031
Echostar	026,039,057,058,060,073,149,150,151,156,249,318
EEC	015
Einhell	004,010,015,019,021
Elekta	011
Elta	004,008,029,055,125,242,309
Emanon	004
Emme Esse	029,031,045,083,309
Ep Sat	005
Eurodec	062,063,337
Europa	022,242,244,246

A 1012 Dynalink Learning Universal Remote Control

Eurosat	021
Eurosky	021,029,031,309
Eurospace	061
Eurostar	008,021,080
Exator	003,004,009,247
Fenner	249
Ferguson	005,012,014,045,062,064,065,066,337
Fidelity	017,019
Filmnet	267
Cablecrypt	
Filmnet Comcrypt	267
Finlandia	005
Finlux	003,005,030,067,072,079,335
Finnsat	050,062,337
Force	148
Fortec Star	285,286
Foxtel	324
Fracarro	133,249
France Satellite/Tv	069
Freecom	004,068
FTE	022,024,051,087,246
Fuba	004,025,029,032,039,040,069,072,122,125,241,243,309,325
Galaxi	025,243
Galaxis	010,029,033,050,055,070,076,152,153,309,317
Galaxy	325
Gardiner	253
GEC	265
GMI	021
Goldbox	245,322
Goldbox-D+	222,233
Goldstar	068
Gooding	075
Goodmans	005,074,328
Granada	030
Grothusen	004,068
Grundig	005,009,040,045,075,077,086,124,154,235,241,251,252,324
G-Sat	014,015
Hanseatic	095,312
Hantor	004,019,044,092
Hanuri	011
Harting Und Helling	015
HEDY	277
Heliocom	024
High Performance	082
Hinari	007,008,014
Hirschmann	015,039,040,078,079,080,083,122,129,178,179,180,181,241,250,335
Hisawa	044
Hitachi	005,045,115
Houston	055,244,249
Humax	152,192,193,234,281
Huth	010,013,021,043,044,050,055,083,244,246
Hyundal	326
Imperial	102,133
Innovation	029,085,095,153,156,157,309,311,312,313,317,318,319,320,321

A 1012 Dynalink Learning Universal Remote Control

Intertronic	021
Intervision	055
Italtel-Stream	223,224
ITT/Nokia	005,030,045,048,079,115,122,335
Jerrold	257,270
Johansson	044
Jok	250
Jsr	055
JVC	003,075,236
Kathrein	015,040,042,052,087,088,089,090,098,125,177,241,242,247,249,253,254
Kosmos	068,083,087,088
KR	009,247
Kreiselmeier	040,241
Kyostar	004,247
Labgear	327
Lasat	011,029,091,092,093,136,137,138,309,316
Lenco	004,022,068,094,244
Leng	044
Lennox	055
Lenson	336
Lexus	242
Leyco	003
LG	068
Lidcom	328
Life	137,153,317
Lifesat	029,085,095,137,153,156,157,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Lifetec	029,085,095,137,153,156,157,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Lion	015,061
Lorenzen	244
Lorraine	068
Lupus	029,309
Luxor	019,030,115,122
Lyonnaise	337
Macab	062,337
Manata	249,250
Manhattan	005,011,045,055,249,250
Marantz	125,242
Mascom	011,088
Maspro	005,045,064,075,098,129,235,241,251
Matsui	003,075,145,235,241,250
Mb	095,312
Mediabox	245
Mediamarkt	021
Mediasat	033,245
Medion	029,085,095,137,153,156,157,214,215,216,217,218,219,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Mega	125,242
Melectronic	253
Metronic	004,009,010,171,247,253,325
Metz	040,241
Micro	247
Micromaxx	029,085,095,137,153,156,157,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Microstar	029,085,095,137,153,156,157,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321

A 1012 Dynalink Learning Universal Remote Control

Micro Technology	015,034,061
Mimtech	096
Minerva	040,075,235
Mitsubishi	005,040,145
Mitsumi	093
Morgans	021,093,097,125,242,246
Morgan sydney	338
Movie Time	269
Multichoice	172,324
Multistar	087,092
Multitec	318,319
Muratto	038,068
Navex	044
NEC	100,101
Network	014
Neuhaus	033,055,071,244,246,336
Nextwave	016,155
Nikko	021
Nimbus	096
Nokia	005,030,045,048,079,110,111,122,134,135,194,195,196,197,198,199,200,201,202,203,204,222,223,227,230,236,280,292,335
Nomex	339
Nordmende	004,005,007,011,062,065,123,337
Novis	044
OAK	271
Oceanic	015,054,061
Octagon	004,008,009,050,244,247
Okano	021,083,087,236,237,238,239
Ondigital	186,229,230
Optex	052,055
Orbit	015,036
Orbitech	004,103,246
Origo	105
Osat	009
Otto Versand	040
Oxford	003,249
Pace	005,012,014,040,045,064,074,099,107,112,130,154,186,189,191,195,204,205,206,207,208,209,210,211,212,213
Pacific	054
Packsat	250
Palcom	007,032,069,071,336
Palladium	021,075,077,235
Paltec	032
Panasonic	005,045,154,183
Panda	005,012,241
Pansat	329
Patriot	249,
Patriot Worldsat	003,249,250
Philips	005,014,028,035,037,045,049,059,075,086,099,104,121,124,125,132,169,170,222,224,225,235,237,238,241,242,243,244,245,246,247,248,249,250,251,252,253,254,311
Phoenix	014,050,074
Phonotrend	010,055,083
Pioneer	245,272,273,275
Pk Sat	015

A 1012 Dynalink Learning Universal Remote Control

Polsat	173,337
Polytron	052
Predki	044
Preisner	246
Premiere	055,140,245
Priesner	021
PRO2	306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Profi	094
Profile	249
Promax	005
Prosat	006,007,010,102,133
Protek	015,054
Proton	015
Provision	011
Ptt Telecom	047
Pye	235,
Quadral	007,010,029,246,249,250,309
Quelle	019,040
Quiero	173,337
Radiola	125,242
Radix	039
Rainbow	009,247
RE	096
Rebox	330
Rediffusion	101
Redpoint	033
Redstar	029,309
Remoshack	296
Revox	096
RFT	010,103,125,242,244
Ruefach	094
Saba	006,011,014,045,061,064,065,120,127,133,136,142,143,144,146,250
Sabre	005
Sagem	062,337
Sakura	050,074
Salora	030,100,101,107,274
Samsung	004,027,078,272
Sat	007,017,036,038
Satbox	276
Satcom	043,095,106,312
Satec	014,045
Satford	043
Satmaster	043
Satpartner	004,009,011,044,068,083,247
Schäcke	247
Schneider	049,248,250,252,254,309,313,317,318,319,320
Schwaiger	013,014,052,054,089,095,137,144,146,147,152,155,157,168,246,306,312,316,317,319
Scientific Atlanta Sts	255,256,268
Seemann	003,021,033,039
SEG	004,008,029,034,044,095,119,309,312
Seleco	055
Siemens	040,241
Silva	068
Skardin	033
Sky	154,182,190,191,220,221,278,282,283,323
Sky Digital	154

A 1012 Dynalink Learning Universal Remote Control

Skymaster	010,095,148,156,158,159,160,161,162,293,294,295,297,298,299,300,301,302,303,304,305,312,315,318,319
Skymax	015,125,242
Skyvision	055
Sony	020,154
SR	021,065,093
Starion	034
Starland	156,318
Starring	044
Star Trak	004
Stella	047
Strong	004,009,029,048,051,081,133,222,228,247,289,309
Sumida	021
Sun/Moon/Star	184
Sunstar	021,093,107
Tandberg	062,337
Tandy	009
Tantec	005,045,064,069,071,336
Tatung	053,105
TCM	029,085,095,137,153,156,157,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Techniland	043
Technisat	039,071,103,108,109,126,242,336
Teco	021,093
Telanor	007
Telasat	095,312
Tele+1	222,228,267
Teleciel	247
Telecom	047
Telefunken	004,045,131,136,137,138,145,250,316
Teleka	009,021,027,039,088,247,251
Telemaster	011
Telex	091
Telesat	095,312
Telestar	071,336
Televés	005,185,187,188,338,340
Telewire	055
Tevion	029,085,095,137,153,156,157,218,219,306,307,308,309,310,311,312,313,314,315,316,317,318,319,320,321
Thomson	005,065,084,131,139,145,173,245,249,250,337
Thorens	054
Thorn	005,012,014,045,064,066
Tioko	052
Tokai	242
Tonna	005,043,055,249
Topfield	331,332,333
Toshiba	239
TPS	141,175
Triad	015,036,038,068,113
Triasat	072
Triax	040,071,136,242,336
Tristar	051
Tudi	259
Twinner	338,340
Uniden	114,287
Unisat	021,050,242
Unitor	025,044,243
Universum	040,067,075,079,235,241,335

A 1012 Dynalink Learning Universal Remote Control

Variosat	241
Variostat	040
Vector	015,061
Ventana	125,242
Via Digital	135,139,231,232
Visiopass	335
Visiosat	044,055,156,163,164,165,166,167,318
Viva	244
Vivanco	334,341
Vortec	004,027,078
VTech	253
V-Tech	036,038,104,115
Way	291
Wela	246
Westminster Cable	260
Wevasat	005,015
Wewa	005
Winer	290
Winersat	044
Wisi	005,036,038,039,040,113,116,117,118,241,246
Wittenberg	017
Wolsey	082
Woorisat	011
Xsat	176,249
Zehnder	011,029,038,087,089,119,243,253,309,325
Zeta Technology	242
Zodiac	009,247

CD

Brand	CD
Adcom	006
Aiwa	007,008,009,098
Akai	010,011,012,013
Alba	014
Arcam	083
Asuka	015
Audiosonic	015
Bestar	016
BSR	017
Bush	018
California audio lab	019
Carrera	020
Classic	119
Condor	017
Crown	021
Cybercom	103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Cybermaxx	103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Cytron	103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Denon	022,023
Dual	015,024,103,104,105,107,108,109,110,111,112,113,114,115,116,117,118
Elta	105,108,113
Emerson	006,016,025
Fisher	026,027
Genexxa	016,025,028,029,030,031,032,033,034,107
Goldstar	020

A 1012 Dynalink Learning Universal Remote Control

Goodmans	025,035,036
Grundig	037,083
Harmon Kardon	010,038,039,040
Hitachi	006,024,041,042,043
Innovation	081,089,090,091,092,093,094,109,110,111,112,113,114,115
Intersound	015
JVC	044
Kenwood	026,029,045,046,047,100
Kodak	005
LG	020
Lifetec	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113, 114,115,116,117,118,119,120
Linn	083
Luxman	048,049
Magnum	081,089,090,091,092,093,094,109,110,111,112,113,114,115
Marantz	051,052,083
Matsui	051,053,083
Mcintosh	054,055
Medion	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113, 114,115,116,117,118,119,120
M-Electronic	050
Memorex	006,016,025,031,034
Meridian	083
Micromaxx	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113, 114,115,116,117,118,119,120
Micromega	083
Microstar	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113, 114,115,116,117,118,119,120
Mission	083
NAD	028,049,084,085,086,087
Naim	083
Nakamichi	056,057
Onkyo	002,058,059,060,061
Panasonic	018,019,062
Philips	003,063,064,082,083
Philips Cd-I	064
Philips Cd-V	002
Pioneer	030,034,099
PRO2	103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Proton	083
Quad	083
Realistic	006,016,031,032,107
Roadstar	050,063,065
Rotel	083
Saba	024
SAE	083
Samsung	102
Sansui	003,025,066,067,068,083
Schneider	001,017,083
Scott	016,025
Sharp	029,069,070,071
Sherwood	124
Siemens	072
Signature	010
Singer	118
Skymaster	121
Sony	028,073,074,075,088,095,096,097

A 1012 Dynalink Learning Universal Remote Control

Sunwood	015
Tandberg	083
TCM	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Teac	122
Technics	019,062,077,101
Telefunken	024
Tevion	081,089,090,091,092,093,094,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120
Theorie\$anwendung	123
Thomson	004,024
Toshiba	049,078,079
Universum	083
Vector Research	020
Victor	044
Welltech	107,108,112
Yamaha	069,076,080
Yorx	065

DVD

Brand	DVD	DVR
Accoustic solutions	128	
Aiwa	129	
Akai	010,034,064	
Alba	130,131,132	
Ames	128	
Amstrad	130	
AMW	091	
Apex	132,133,134,135	
Arena	120	120
A-trend	136	
BBK	075,076,077,078,079,080,081,082,083,084,085	
Black diamond	130	
Brandt	118	
Broksonic	137	
Bush	097,130,131,132,147	
Centrum	138,139,140,141	
Cinevision	142	
Classic	128	
CMI	120	120
Crown	118	
Cybercom	102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
CyberHome	042,068,136	
Cybermaxx	102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Cytron	102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Daewoo	070,091	
Daytron	143	
Denon	005,036,058	
Denver	131	
DIK	114	
Dmtech	144	
Dual	102,103,104,105,107,108,109,110,111,112,113,114,115,116,117,118,119,120,128,130,167	120

A 1012 Dynalink Learning Universal Remote Control

DVD 1024	145	
ECG	095	
Elta	146,147,168	
Emerson	142	
Ferguson	118	
Finlux	142	
Fisher	148	
GE	132	
Golden Sphere	108	
Goldstar	142	
Goodmans	118,147	
Go-Video	105	
Gradiente	118	
Grundig	011,158	
GVG	096	
Haaz	108,109	
Harman/Kardon	050,150	
H&B	110	
Himage	094	
Hitachi	009,025,030,043,063,127,163	127
HTY	086	
Initial	132	
Innovation	012,013,014,114,116,117,118	
JBL	150	
JVC	002,032,066	
Kendo	114,120	120
Kenwood	005,028,058	
KLH	132	
Koss	118	
Labwave	023,048	
Lasonic	067,108	
Lecson	151	
Lenoxx	152	
LG	016,142,153	
Life	012,013,014,116,117,118	
Lifetec	012,013,014,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Limit	108	
Linn	035	
Loewe	011,039,158	
Magnavox	056,089,125,126,157	
Magnum	170,171	174
Marantz	003,038,142,157,158,159	
Matsui	118	
Maxim	091	
MBO	154	
Medion	012,013,014,041,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Metz	009,024,163	
Mico	087,088	
Micromaxx	012,013,014,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Microsoft	155	
Microstar	012,013,014,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Mintek	132	
Mitsubishi	007,130	

A 1012 Dynalink Learning Universal Remote Control

Mustek	069,071,072,128	
NAD	027,142,162	
Nakamichi	156	
Noname	045	
Norcent	093	
Nortek	091	
Onkyo	015,029,065,149	
Optimus	059	
Orion	137	
Oritron	118	
Pacific	114	
Panasonic	005,006,017,022,036,051,054,055,058	
Panda	090	
Philco	053	
Philips	003,011,039,040,047,052,125,126,157,158,159	125,126
Philips magnavox	157,158,159	
Pioneer	009,024,026,059,062,163	
Prism	104	
PRO2	102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124	120
Proline	118	
Proscan	155	
Prosonic	160,161	
RCA	057,073,132,155	
Reoc	108	
REX	138	
RTL	120	120
Saba	118	
Salora	142	
Sampo	108	
Samsung	008,030,063,105	
Sanyo	092,148	
Schneider	014,113,114,118,130,144,161	
SEG	108,130	
Sharp	012,013,116,162	
Sherwood	044	
Shinco	132	
Shinsonic	132	
Siltex	076	
Skymaster	098,099,100,101,128,147	
Sm electronic	128,147	
Sony	004,031,046,060	
Strong	091	
Sunsui	137	
Supervision	147	
SVA	074	
Sylvania	106	
TCM	012,013,014,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124,169	120,173
Teac	108,132,163	
Technics	005,036,037,058,155	
Techwood	162	
Tevion	012,013,014,102,103,104,105,106,107,108,109,110,111,112,113,114,115,116,117,118,119,120,121,122,123,124,172	120
Theta digital	163	
Thomson	001,033,155	
Toshiba	003,049,137,157	

A 1012 Dynalink Learning Universal Remote Control

United	164,165	
Universum	130	
Wharfedale	151	
Xenius	115,118	
Yamaha	005,036,058,061,125,126	125,126
Yamakawa	166	
Zenith	142	
Others	018,019,020,021	

AUX □ AMP, TUNER, TAPE, LD, Other □

Brand	AMP	TUNER	TAPE	LD/OTHER
ADT				161
Aiwa	028,128,129	203,204,245	319,320,321,437,438	181,182
Akai	018,112,121	223,274,286	326,390,400,410,411,421	
Amplifier	158			
Amstrad	014,034,077,086,145	278,290,294,295	393	
Arion				162
ASH	027	250		
Aswo	043	253	328	
Audio Comb1				040,190
Braun	104		347	
Bush	032,116	239	314	
CD Photo				039
CDR				041,191
CD Video				038
Centrum		301		
Cybercom	169,170,171	302,303,304		173,174,175,176,177,178
Cybermaxx	169,170,171	302,303,304		173,174,175,176,177,178
Cytron	169,170,171	302,303,304		173,174,175,176,177,178
Daewoo	022	284	384	
DBS				179
Denon	020,080,098,131,139	198,199,228,249,271,297	313,317,318,356,369,443	001(LD)
Diora	081	287	376,377	
Disco Vision				003(LD)
DMT				161
Dual	062,124,169,170	208,222,302,303	327,412,413	173,174,175,176,183
Elta		305,306		176,184
Fischer	021,085,134	260	370,371,382,440	
Goldstar	029	201	439	
Gold Vision				166,167
Goodmanns	015,018,032	274	312	
Goodmans		239	344	
Grundig	043,142,148	253,255,307	328,332,337,445	005(LD),043,044,046
Harman Kardon	091	281	368,403	
HDT				159
Hitachi	098	228,279	356,392	003(LD)
Home automation				192
ITT	073	227	395,396	

A 1012 Dynalink Learning Universal Remote Control

JBL	068,118			
JVC	067,146,150	241,270,273	322,339,340,434,435	
Kenwood	023,062,156	222,263,265,268,272	325,394,409,412,413,427,432,433	062
Lifetec	169,170,171	302,303,304		173,174,175,176,177,178
Linn	043,148	298	365	043
Luxman	099,100,149,152	264,300	353,354,361,408	
Magnavox			445	046
Magnum	194			
Marantz	043,148,153	253,307	328,364,399,445	043,044,046,
Medion	034,169,170,171	302,303,304		173,174,175,176,177,178
Meridian	148			043
Micromaxx	169,170,171	302,303,304		173,174,175,176,177,178
Microstar	169,170,171	302,303,304		173,174,175,176,177,178
Minowa	013	236		
Mission	155	215		
Mitsubishi				005(LD)
NAD	048	285	380,381	005(LD),047,048,049,050
Naim				043
Nakamichi	069	246	404	
Niam	148			
Nokia	072	237	397	
Noname	032	239		
Okano	016,017	276,289	424,425	
Onkyo	024,125	252,266	323,324,333,378,379	
Palladium	033,090,133	277	420	
Palladium/Okano	143			
Panasonic	136,138,141	198,258	359,405,406	
Philips	043,101,140,148,153,154	253,307	328,337,398,445	004(LD),006(LD),043,044,045,046
Pioneer	011,119,148	207,210,211,262	330,331,389,415,417,418,419	003(LD),005(LD),043,055,185
PRO2	169,170,171	302,303,304		173,174,175,176,177,178
Quad	148			043
Radiola				006(LD)
Radiotone	087			
Radix				160
Radmor	140,153,154	254	364	
Revox	089,120	213	338	
Revox/Studer	101,153,154	253	328	
Rotel	126,127	205		
Saba	151			
Samsung	010,074,083,092	206,238,275,291,299	360,362,363,373,374	065,186
Sansui		307	445	044,046
Sany			382	
Sanyo	134,157	219,259	383,407,414	

A 1012 Dynalink Learning Universal Remote Control

Schneider	012,013,016, 019,026,029, 032,033,034, 035,043,073, 075,086,088, 096,105,106, 107,108,109, 110,111,113, 114,115,143, 144,145,147	201,215,217, 218,220,221, 225,226,227, 229,230,231, 234,235,236, 239,267,269, 277,286,289, 290,295	328,343,344,345, 346,349,350,351, 355,395,396,423, 439	
Sharp	132,156	200,272	316,341,427	187
Sherwood	071,078,079	240,282,283	367,385,386,387, 388	
Siemens	016,018,019, 022,026,029, 031,034,043, 075,093,094, 095,142	201,215,233, 234,244,253, 274,284,289, 292,296	326,328,357,358, 422,423,426,428, 429,430,431,439	
Sinotec	035	221		
Sinotec(Pepsi-Dose)	035	221		
Sony	036,117,133	216,243,247,2 48	342,402,416, 441,442,444	002(LD),007(LD) ,008(LD),051,052 ,053,056,057,058,0 59,060,061,168, 188,193
Supertech	032	239		
Switch Box				180
T+A	025,103	232,251	348,436	
T+A Elektroakustik	025	251	436	
TCM	169,170,171, 172,195,196	302,303,304, 308		173,174,175,176, 177,178
Teac		309,310		
Techmate				163
Technics	082,097,135, 138	214,256,257, 288	315,366,375,405	063
Tehsan				164,165
Telefunken				005(LD)
Tensai	102			
Tevion	169,170,171, 197	302,303,304		173,174,175,176, 177,178
Theorie&anw ending		311		
Thomson	123	209	329	064
Thorn				009(LD)
Uher	130	202		
Universum	010,016,018, 084,107	230,274,289, 293,299	345,352,363,372, 423,426	
Video CD				037,189
Welltech				173,178
Yamaha	030,070,076, 122	212,224,242, 261,280	334,335,336,391, 401	042,054,066
Others	137			

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>