IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER - Any hair dryer is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock

- 1. Always "unplug it" immediately after using 2. Do not use while bathing or in a shower. 3. Do not place or store appliance where it
- can fall or be nulled into a tub or sink. 4. Do not place in, or drop into, water or
- other liquid 5. If an appliance falls into water, "unplug it" immediately. Do not reach into the water.

WARNING - To reduce the risk of burns. electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.

- 2. Close supervision is necessary when this appliance is used by on or near children or by individuals with certain disabilities.
- 3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer

4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped, damaged, or dropped into water, Return the annliance to a Conair service center for examination and repair.

5. Keep the cord away from heated surfaces. Do not pull, twist, or wrap line cord around dryer, even during storage.

6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint hair and the like

7. Never use while sleeping 8. Never drop or insert any object into any opening or hose

9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- 10. Do not use an extension cord to operate dryer
- 11. Do not direct hot air toward eyes or other heat-sensitive areas
- 12. Attachments may be hot during use. Allow them to cool before handling
- 13. Do not place appliance on any surface while it is operating
- 14. While using the appliance, keep your hair out of it. Keen your hair away from the air inlets

15. Do not use with voltage converter.

SAVE THESE INSTRUCTIONS

OPERATING

This appliance is intended for household use only. Use on Alternating Current (60 hertz) only. Standard Dryers are designed to operate at 110 to 125 volts A.C.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature. this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit. contact a qualified electrician. Do not attempt to defeat this safety feature.


IMPORTANT 1875 WATT OPERATING GUIDE

Use of this dryer on the same circuit or fuse with other electrical products or appliances may trip a 15 amp circuit breaker or blow a 15 amp fuse. NEVER replace the fuse with one rated higher than the capacity of the circuit. Doing so could result in an electrical fire.

CHECK ALCI SAFETY FEATURE EVERY TIME

VOILUSE APPLIANCE This appliance is equipped with an Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly, perform the following test. The purnose of this test is to allow you to make sure the water sensing system (ALCI) is working.

- 1. Plug in the appliance and press test button on plug (See appropriate diagram below)
- 2. The appliance will stop working. There will be an audible click and reset button will pop out. 3 To reset ALCI with a reset button unit should be unplugged. Then push reset button
- in, and reinsert plug into outlet.



- 5. It is important that if immersion occurs. this unit be brought to a service center. Do not try to reset.
- 6. Be sure to repeat test every time you use the unit to confirm ALCI is operational.

Should the appliance go off and the reset button pop up during use, this could indicate a malfunction in the unit. Remove plug from outlet and allow the appliance to cool. Reinsert plug into outlet

The appliance should then function normally If not return to an authorized Conair Service Center for evaluation and renain

SUPER STYLING GUIDE

Your best looks begin with a good haircut that's well maintained. Always treat hair right with superior quality shampoos, conditioners, and finishing products.

DRYING BASICS

1. Shampoo and condition hair with products of your choice. Rinse thoroughly. Towel blot hair to remove excess moisture Section hair Push the ion on switch to turn on the ion generator; clouds of negatively charged ions will help to reduce static electricity, control frizzy flyaways and contributeto your hair's shine. Using the dryer along with your styling brush, start at a lower setting and direct hot air through a section of hair at a time. Move driver steadily across each section so that the hot air passes through hair Direct air flow at hair not scaln

- 2. Keep dryer's air intake vents unobstructed and free from hair while drying.
- 3. To avoid over drying, do not concentrate heat on any one section for any length of time. Keep dryer moving as you style.
- 4. For quick touch ups, between shampoos. dampen hair with a mist of water before styling with the dryer.
- When using your dryer to create curls and waves. dry hair almost completely on a warmer temperature setting, then finish styling with Cool Shot feature to close hair shaft and lock in style.

GETTING TO KNOW YOUR DRYER The professional Conair® ION SHINE dryer is very effective, even at lower temperatures. and helps to give healthier-looking, shiny more manageable hair with maximum styling control. Its powerful professional motor lasts up to 3 times as long as an average motor and gives you a genuine cold shot that 'freezes' a style into place.

RODY & VOLUME To create extra volume, turn head upside down while drying Position the air flow toward the roots for maximum lift. When hair is dry. toss head back and



ends slightly

at the roots

under as you dry.

hrush hair into place







6' Line Cord



Download from Www.Somanuals.com. All Manuals Search And Download.



This message about...

AULT

can save a life!

NTERRUPTERS

IF YOU MUST USE YOUR HAIR DRYER IN

THE RATHROOM INSTALL A GECL*NOW! Your local electrician can help you decide which type is best for you-a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCI's in the bathrooms, garages, and outdoor outlets of all new homes

WHY DO YOU NEED A GEC12 Electricity and water don't mix. If your hair dryer falls in water while it's plugged in, the electric shock



can kill you...even if the switch is "off." A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

A GFCI can save your life! Compared to that, the price is small! Don't wait...instal one now!

*GFCI is a sensitive device which reacts immediately to a small electric current leak by stopping the electricity flow.

USER MAINTENANCE

Your dryer is virtually maintenance free. No lubrication is needed. For proper operating performance, the dryer must be kept clean When cleaning is needed, unplug the cord and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a cloth only

Blocked or clogged air intake vents will cause the dryer to overheat. If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat turns off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

If the cord or dryer is damaged or does not operate properly, return it for repair to an authorized Conair service representative only. No repairs should be attempted by the consumer

STORAGE - Important

When not in use, your dryer should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer. Allow the cord to hang or lie loose and straight at the point of entry into the dryer.

LIMITED THREE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 36 months from the date of purchase if the appliance is defec-tive in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below that is nearest you, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 36 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS. OR LIABILITIES. INCLUDING BUT NOT LIM-ITED TO THE IMPLIED WARRANTY OF MER-CHANTABILITY AND FITNESS FOR A PARTIC ULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 36 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSE QUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED. WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.



SERVICE CENTERS:

©2003 CONAIR CORPORATION

CONAIR CORPORATION CONAIR CORPORATION Service Department 150 Milford Road 7475 N. Glen Harbor Blvd Fast Windsor N.I 08520 Glendale AZ 85307

03NP422

CONAIR

PROFESSIONAL STYLER

THE POWER OF SALON STYLING

Longer life AC Motor runs quieter &

provides powerful airflow to dry hair fast.

Instruction & Styling Guid

151Z Model

+



IB-4942



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com