

TRAVEL SMART® by CONAIR®

Instruction Guide Instrucciones Directives

½" (13mm) ceramic straightener
plancha cerámica 13 mm
fer à défriser céramique 13 mm

Model/ Modelo/
Modèle TS20S

GETTING TO KNOW YOUR STRAIGHTENER



Heat resistant storage pouch with mat allows hot iron to be stored immediately after use. Mat protects counters from damage while styling.

1. Always unplug the straightener before using it.
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into soft surface, such as a couch or bed.
6. Never use while sleeping.
7. Never drop or insert any object into any opening.

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING FROM WATER DANGER

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

1. This appliance should never be left unattended when plugged in. Do not let heated surfaces touch eyes or bare skin.
2. This straightener is hot when in use. Do not touch hot surfaces of the appliance. Use the handles or knobs. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
3. Use this appliance only for its intended use as described in this booklet. Do not use attachments not recommended by the manufacturer. Do not use an extension cord to operate appliance.
4. Do not use with a voltage converter and repair.
5. Never operate this appliance if it has a damaged cord or plug, it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination.
6. Keep the cord away from heated surfaces.
7. Do not pull, twist, or wrap line cord around appliance, even during storage.
8. Never block the air openings of the appliance, keeping them free of any lint, etc. Never place the appliance on a soft surface, such as a couch or bed.
9. Never use while sleeping.
10. Never drop or insert any object into any opening.

WARNING

11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. This straightener is hot when in use. Do not let heated surfaces touch eyes or bare skin.
13. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.
14. Before plugging in, please read the dual voltage information in this booklet.
15. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
16. Do not touch hot surfaces of the appliance. Use the handles or knobs. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
17. Do not use with a voltage converter.

GUARDE ESTAS INSTRUCCIONES DE USO

Este aparato fue diseñado para uso doméstico. Úselo solamente con Corriente Alterna de 120/240V (50/60 hertz).

This straightening iron is intended for household use. This unit is designed to operate at 120-240VAC volts AC. Use on Alternating Current (50/60 hertz) only.

SAVE THESE OPERATING INSTRUCTIONS

Do not use with a voltage converter. Do not touch hot surfaces of the appliance. Use the handles or knobs. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.

11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
12. This straightener is hot when in use. Do not let heated surfaces touch eyes or bare skin.
13. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.
14. Before plugging in, please read the dual voltage information in this booklet.
15. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
16. Do not touch hot surfaces of the appliance. Use the handles or knobs. Do not attempt to touch the housing of your appliance near the straightening plates as it is hot when in use.
17. Do not use with a voltage converter.

MEDIDAS DE SEGURIDAD IMPORTANTES

Siempre que use aparatos eléctricos, especialmente en la presencia de niños, debe tomar precauciones básicas de seguridad, entre las cuales las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USARLO MANTENGA EL APARATO ALEJADO DEL AGUA PELIGRO

Cualquier electrodoméstico permanece bajo tensión, aunque el interruptor esté apagado. Para reducir el riesgo de muerte o herida por descarga:

1. Siempre desconecte el aparato inmediatamente después de usarlo.
2. No lo use en el baño o la ducha.
3. No coloque ni guarde el aparato donde pueda caer o ser empujado a una bañera o un lavabo.
4. No coloque el aparato ni lo deje caer al agua u otro líquido.
5. Si el aparato cayera al agua, desconéctelo inmediatamente. No toque el agua.

ESPAÑOL

FAMILIARÍCESE CON SUS TENACILLAS

Placas de 13 mm cubiertas de cerámica



Estuche/tapete a prueba de calor que permite guardar el aparato inmediatamente después de usarlo y que protege las encimeras.

USER MAINTENANCE

STYLING WITH CERAMIC TECHNOLOGY STRAIGHTENING IRONS

The plates of your new straightening iron have an easy-glide ceramic surface, the latest in technological advances. Ceramic even heat distribution produces the ultimate in healthy, shiny, silky looking hair. You'll find that hair glides easily over the surface of the plates as you're straightening, and that it is easier to clean styling products residue, etc. off the plates after each use. The ceramic surface also helps smooth down flyways and frizzes. As you smooth your hair, heat is evenly distributed so that the style you create has a salon-perfect, silky finish. Hair glides right through the plates after it's straightened.

The new ceramic technology is a pleasure to work with, makes styling your hair easier and provides professional results. After using the iron several times, you'll learn the ideal way to straighten and prior to use in outlet.

Some experience is necessary when adjusting to the proper voltage. Use an adapter plug with correct configuration prior to use in outlet.


1. This straightening iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow it to cool, and wipe exterior with a cloth. If any abnormal condition occurs, unplug it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION- NEVER allow the power supply cord to be pulled, twisted, or severed bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE- When not in use, your appliance is easy to store. Allow it to cool, then store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections.

ALWAYS UNPLUG SMALL APPLIANCES

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.



KEEP AWAY FROM WATER

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

LIMITED TWO-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below that is nearest you, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>