

# RT-M1000+T/V

## CBL+TV Remote Control



### Programming And Operating Instructions

To have a clearer idea of the features and capabilities of your remote control, take a moment to read these instructions. Save for future reference.

### RT-M1000 + T/V CBL + TV Remote Control

#### 1. Introduction

Your remote control is simple to program, easy to use, and can operate two (2) electronic devices, which include :

- CABLE** Motorola DCT Cable set-top terminals
- TV** Televisions

Before you can use your remote control, it must be programmed (set-up) to operate your TV.

#### 2. Before Getting Started

Some of the special features on your remote control are as follows :

#### Point and Press® Programming

Lets you program your TV without codes. For more information, see Section 5.

#### Time Out

Shuts remote off if any button is pressed and held for 45-seconds. This extends battery life in the event the remote becomes lodged under or between heavy objects.

#### 3. Installing / Replacing Batteries

Install two (2) new "AAA" batteries as indicated by the diagram in the battery compartment.

When the batteries become low and need to be replaced, the LED will not illuminate normally or at all during use.

When this happens, replace the existing batteries with two (2) new "AAA" batteries to restore normal operation to the remote control.

#### 4. Programming Your TV

If you have a TV that's operated by remote control,

### RT-M1000 + T/V CBL + TV Remote Control

it is recommended that you plug it directly into a wall outlet instead of the cable set-top terminal.

#### Code-Entry Programming...

1. Turn on TV.
2. Press [OK], then [MUTE] together until the LED illuminates.
3. Locate the 3-digit code for your brand in the TV Setup Code list and enter it on the keypad of the remote control. Entry of the correct code will cause your TV to turn off.

If multiple codes are listed for your brand, you may have to enter several different codes until your TV turns off.

4. As soon as you have entered a 3-digit code that turns your TV off, press [MUTE].

a. If the TV turns back on, press [OK] to lock in the code. The LED will blink and go out.

Or

b. If the TV does not turn back on, enter a different 3-digit setup code until your TV turns back on. Then press [OK] to lock in the code. The LED will blink and go out.

#### Point and Press® Programming...

1. Turn on TV.
2. Press [OK], then [MUTE] together until the LED illuminates.
3. Press and hold the [CH ▲] button until one device turns off. While you are pressing the [CH ▲] button, the LED will blink. As soon as one device turns off, release the [CH ▲] button.

4. Press [MUTE]. If the device that turned off...

### RT-M1000 + T/V CBL + TV Remote Control

- a. Turns back on, press [OK] to lock in this code. The LED will blink and go out.

Or

- b. Does not turn back on, press [CH ▼] one step at a time until that device turns back on. Each time you press the [CH ▼] button, the LED will blink.

Once you have found a code that turns the device on / off, press [OK] to lock in this code. The LED will blink and go out.

#### 5. Programming Volume Control

To program volume control to Cable set-top terminal...

1. Press [CBL], then [OK] together until the LED illuminates.

2. Press [VOL ▲], then [CBL] for Cable volume.

3. The LED will blink and go out.

To program volume control to TV...

1. Press [CBL], then [OK] together until the LED illuminates.

2. Press [VOL ▲], then [TV] for TV volume.

3. The LED will blink and go out.

#### 6. Resetting Your Remote Control

To reset your remote to its factory default setting, follow these steps:

1. Press [CBL], then [OK] together until the LED illuminates.

2. Press [MENU], then [MENU] again. The LED will blink and go out.

#### TV Set-up Codes

BRAND	CODE				
Admiral	026	054	211		
Advent	072	094	547	561	
	577				
Adventura	047				
Aiwa	214	585			
Akai	053	576	587		
Amark	023	215			
Amstrad	157				
Anam	217	218	219	220	221
	222	223			
AOC	053				
APEX	030	038	549		
Audiovox	220	579			
Belcor	073				
Bell & Howell	211				
Broksonic	165	167			
Brokwood	073				
Candle	068	091			
Centurion	095	107	108		
Citizen	068	091	211	233	
Concerto	073	095			
Contec	147				
Coronado	023				
Craig	223				
Crown	023				
Curtis Mathes	016	054	107	108	211
	213				
Daewoo	051	068	073	095	158
	159	189	191	194	196
	197	198	200	202	204
	205	206	207	209	
Daytron	073	095	107	108	
Dumont	073				
DELL	562				
Electro Home	073	095			
Elektra	353				
Emerson	016	023	053	064	103
	139	158	159	164	165
	166	167	168	169	392
	400	401	402	408	415
Envision	073	095			
ESA	568	570			
Fisher	355	356			
Fujitsu	574	583			
Funai	047				

### RT-M1000 + T/V CBL + TV Remote Control

Gateway	548				
GE	015	018	042	044	049
	054	055	068	073	090
	095	101	102	103	389
	390	396	403	406	407
Gibraltar	023	048	053	068	073
	090	095	107	108	233
	360				
Goldstar (LG)	023	053	068	073	090
	107	108	233	360	361
GO-Video	558				
Grundig	233				
Hall Mark	073	095			
Hitachi	023	068	095	096	097
	098	099	100		
Hyundai	567				
Inkel	364				
Insigna	564	570	575		
JC Penney	039	053	068	073	092
	095	102	355		
JVC	104	105	106	396	397
	410				
Kawasho	073	095			
KMC	023				
KONKA	559				
KTV	023	053	233	366	
Kurazai	211	213			
LG (Goldstar)	023	053	068	073	090
	107	108	233	360	361
Lodgenet	211	213			
Logik	211	213			
Luxman	068	073	095		
LXI	024	026	157		
Magnavox (Philips)	023	068	071	073	089
	090	091	093	134	385
	387	397	404	577	586
Majestic	211	213			
Marantz	053	107	108	109	
Megatron	215				
Memorex	090	211	213	355	388
	405				
MGA / Mitsubishi	053	068	073	090	095
	107	109	110	216	384
	394	395	398	399	417
Mintek	584				
Montgomery Ward	022	023	026	053	071
	072	108	211	213	
NEC	028	068	090	108	200
	578				

### RT-M1000 + T/V CBL + TV Remote Control

Norcent	569	586			
Orion	019	159	160	161	162
	163	382			
Panasonic	042	043	044	045	046
	551				
Philco	023	053	068	071	072
	091	577			
Philips (Magnavox)	023	068	071	073	072
	089	090	091	093	134
	385	387	397	404	577
Pilot	073	094	233		
Pioneer	111	144	383		
Planar	588				
Portland	023	068			
ProScan	055	070			
Proton	090	371	372		
Protron	571	581			
Proview	573				
Pulsar	073				
Quasar	044				
Radio Shack	073				
Realistic	022	166	168		
RCA	042	052	053	054	055
	069	070	416		
Sampo	090	108			
Samsung	015	016	017	023	031
	090	107	108	134	147
	151	153	386	411	
Sansui	423	546			
Sanyo	353	355	356	376	377
Sceptre	582				
Scott	090	108	168		
Sears	023	031	038	039	068
	353	355	356		
Sharp	016	022	023	024	025
	026	027	028	029	393
	395	409			
Signature 2000	023	026	108	211213	
Sony	014	020	021		
Soundesign	091				
Squareview	157				
Supre-Macy	380				
Sylvania	068	071	072	090	091
	093	107	108	157	158
	419	580			
Symphonic	047	157			
Tatung	044	560			
Techwood	068				
Teknika	023	068	072	091	168

### RT-M1000 + T/V CBL + TV Remote Control

	213	577			
Telarent	023	213			
Tera	381				
Tevion	065	414			
TMK	068	090			
Toshiba	030	031	038	039	
Totevision	233				
Universal	068	102			
Vidtech	068				
ViewSonic	550				
Vizio	568				
Wards	068	090			
White Westinghouse	211	408	563	572	
XR-1000	213				
Yamaha	068				
York	090	108			
Zenith	047	048	049	050	051
	391	405	406	555	

#### 7. Additional Programming / Troubleshooting Information

1. If the same button is pressed and held for 45-seconds, your remote control will turn itself off automatically.

This extends the battery life should the remote become lodged under or between heavy objects, for example sofa cushions.

2. If you have a TV that's operated by remote control, it is recommended that you plug it directly into a wall outlet instead of the cable set-top terminal.

3. If you have any questions concerning the brand, model or operation of your cable set-top terminal, contact your cable operator.

Rev. 05/07

© 2007, Contec Holdings, LLC

Point and Press® is a registered trademark of Contec Holdings, LLC

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>