


You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI MAGNIFICA COFFEE MAKER EAM3200S. You'll find the answers to all your questions on the DELONGHI MAGNIFICA COFFEE MAKER EAM3200S in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DELONGHI MAGNIFICA COFFEE MAKER EAM3200S
User guide DELONGHI MAGNIFICA COFFEE MAKER EAM3200S
Operating instructions DELONGHI MAGNIFICA COFFEE MAKER EAM3200S
Instructions for use DELONGHI MAGNIFICA COFFEE MAKER EAM3200S
Instruction manual DELONGHI MAGNIFICA COFFEE MAKER EAM3200S





## Manual abstract:

S. 1362 should be fitted. This appliance conforms to the Norms EN 55014 regarding the suppression of radio interference. Warning - this appliance must be earthed 3 Bean container lid Centre lid for the ground coffee Container for the coffee beans Compartment for the measure (for pre-ground coffee) Grinding coarseness adjustment knob Cup warmer tray Container for pre-ground coffee Control panel Steam knob Infuser Mobile drawer Milk frother nozzle (removable) Coffee spout, adjustable in height Removable container for the coffee grounds Milk frother Water tank (removable) Power cable Steam spout Milk frother (removable) Cup support tray Measure for pre-ground coffee Drip tray (removable) Service door 4 1 2 3 4 Description of the control panel .5 Safety warning .6 Installation 6 Preparing the coffee maker .7 4.1 Filling the water tank .7 7 .7 8 4.

2 Filling the container with coffee beans 4.3 Using the coffee maker for the first time 5 6 7 8 9 Preparing the coffee (using coffee beans) Adjusting the coffee grinder 9 Preparing espresso coffee with ground coffee (instead of beans) .10 Hot water delivery .15 Preparing cappuccinos (using steam) .16 10 Cleaning and maintenance 14.

14 10.1 Cleaning the coffee maker 10.2 Cleaning the infuser 10.3 Descaling .15 16.

17.18 19 10.4 Setting the water hardness 11 Meaning of the normal operation indicator lights 12 Meaning of the alarm indicator lights and what to do when they are on 13 Problems that can be resolved before calling the service centre .20 OPERATING INSTRUCTIONS 5 1. DESCRIPTION OF THE CONTROL PANEL 1) On/off button 2) 1 cup and coffee temperature OK light 3) One cup button 4) 2 cup and coffee temperature OK light 5) Two cup button 6) Steam and steam temperature OK light 7) Steam function selector button 8) Coffee quantity selector knob (short, normal or long) 9) Grinding quantity selector knob (for weak, normal or strong coffee) 10)Rinse and descaling button 11)Ground coffee button (disables the coffee grinder) 12)Ground coffee light (coffee grinder disabled) 13)Scale alarm light 14)Generic alarm indicator light 15)Grounds container full or absent indicator light 16)No water or water tank absent indicator light OPERATING INSTRUCTIONS 6 2 SAFETY WARNINGS CAREFULLY READ AND KEEP THESE INSTRUCTIONS! This machine is designed to "make espresso coffee" and to "heat drinks": be careful to avoid scalding from the water and steam jets or by using the machine incorrectly. This appliance is for household use only. All other use is considered improper and consequently dangerous. The manufacturer is not liable for damage caused by improper, incorrect or unreasonable use of the appliance. During operation, do not touch the hot surfaces of the appliance. Use the knobs or handles.

Do not touch the appliance with damp hands or feet. Do not allow children or unfit persons to use the appliance unsupervised. Do not allow children to play with the appliance. In the event of breakdown or faulty operation, turn the appliance off and do not tamper with it. For repairs, contact a technical service centre authorised by the manufacturer only. Request that only original spare parts be used. Failure to respect the above may compromise the safety of the appliance. · · 3 INSTALLATION · After unpacking, make sure the appliance is complete and undamaged. If in doubt, do not use it. Contact professionally qualified personnel.

Packing elements (plastic bags, polystyrene etc) must not be left within reach of children as they may represent a hazard. Place the appliance on a work surface far away from water taps, basins and sources of heat. After having positioned the appliance on the work bench, make sure that there is a free space of around 5 cm between the surfaces of the appliance and the side and rear walls and a free space of at least 20 cm above the coffee maker. Never install the machine in environments where the temperature may reach 0°C or lower (the appliance may be damaged if the water freezes). Check that the voltage of the mains power supply corresponds to the value indicated on the appliance's rating plate.

Only connect the appliance to a power outlet with a minimum rating of 10A that is properly earthed. The manufacturer declines all liability for any accidents caused if the system is not correctly earthed..



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com