

#### **Heart Rate Monitor**

### 1. Functions

#### **Heart Rate Functions:**

Current Heart Rate

ECG Accurate

#### Watch Functions:

Time of Day

#### Other:

Large Dual Display
Easy to Start
Water Resistant
Comfortable Ultra-Slim Ergonomic Chest
Belt Transmitter w/ user Changeable Batteries
Interfaces with Heart Rate Interactive Exercise
Equipment at home and in the gym

# 2. Putting on your Ekho Heart Rate Monitor



### Receiver:

Mount the Receiver on either your left or right wrist. The watch receives and translates the electrical signals generated by your heart via the transmitter.

#### **Transmitter Belt:**

Attach the transmitter to the elastic strap.

Wrap the transmitter around your chest and adjust the length of the strap so it fits snug.

The strap should be comfortable and secure.

(If the strap is not secure, the electrodes may lose contact or the transmitter may slide down during exercise.)

The transmitter should be positioned just below the breasts/pectoral muscles, with the transmitter centered on the chest.

Wet the electrodes (rubber pads), the

electrodes must be wet for accurate heart rate.

The transmitter will automatically turn on when the above actions are done.

The optimal distance from the receiver (watch) to the transmitter is 1 meter (3.28 feet).

**Note:** All telemetry pulse watches are subject to interference from strong electromagnetic fields generated from motors, TV sets, computers, high voltage power cables which can disrupt the reception and cause incorrect hear rate measurements.

### 3. Setting Time

Press "Select" and hold for 3 seconds. 12/24 hour will flash. When 12/24 hour begins to flash, press "Select" to select mode.

When finished wait 7 seconds and hours will begin to flash. Press "Select" until hour desired is flashing. Wait 7 seconds. Repeat this process with Minutes and Seconds. Once complete wait 7 seconds and clock will begin.

### 4. Now It's Time to Begin

Press "Select", a zero will appear in the lower portion of the Display. Once a signal from the transmitter is detected, the heart symbol will begin to flash in conjunction with your heartbeat. Your heart rate will display in a few seconds.

If the heart symbol does not flash, the signal is not being received. Check the position of the transmitter. Verify the electrodes are moistened.

### 5. Now It's Time to Begin

Press "Mode", until a zero will appear in the lower portion of the Display. Once a signal from the transmitter is detected, the heart symbol will begin to flash in conjunction with your heartbeat. Your heart rate will display in a few seconds.

If the heart symbol does not flash, the signal is not being received. Check the position of the transmitter. Verify the electrodes are moistened.

# 6. Your done exercising.

Wash Transmitter belt with soapy water then rinse.

Dry Transmitter with soft cloth.

Store Transmitter a place that is clean and dry. Dirt and moisture may cause transmitter to continue reading, reducing the life of the battery.

### 7. Haven't exercised in a while?

Ekho Heart Rate Monitors is to be used to display heart rate during exercise only and cannot predict the intensity level that is safe for you. It is not intended for medical diagnostic purposes or for prevention of heart related health problems. Before you begin any exercise program, please consult your physician:

- a. If you have been inactive for a period of time
- b. Have a history of cardiac illness
- c. Smoke
- d. Have high blood pressure
- e. Are over-weight.

If you use a pacemaker, do not use a heart monitor until you consult your doctor.

# 8. Ekho Specifications

Receiver:

Heart Rate Range 30 to 240 BPM Heart Rate Accuracy +/- 1 BPM

Operating Temperature 0 C-50 C (32 F - xx F)Storage Temperature -20 C - 80 C (xxF-xxF)Battery 3 volt Lithium 2032 cell

Weight 30.6 grams

Transmitter & Belt:

Emitted Frequency 5KHz +/- 10%

Battery 3 volt lithium 2032 cell

Weight 4 oz.

# 9. Limited Warranty

Download from Www.Somanuals.com. All Manuals Search And Download.

Warranty, Terms and Conditions
If the product becomes defective during the 2-year Limited
Warranty period Ekho will repair or
replace any defective component part at no charge to the

replace any defective component part at no charge to the original owner, subject to the limitations and requirements listed.

THE FOLLOWING IS REQUIRED BY EKHO when requesting warranty services:

Check your resellers return policy. All purchased products must be returned to original place of

purchase within their return policy time period.

The product must be packed in the original shipping carton or

The product must be packed in the original shipping carton of in a suitable packing offering

similar degree of protection. To avoid scratches or other damages to the product during shipping

separate items, such as HRM, transmitter belt, transmitter, should be individually wrapped and

placed in the same package. This will reduce any extra cost of return freight/postage. Please

include a copy of Proof of Purchase and/or copy of registration form.

Limitations: The limited warranty provided by Ekho does not cover: A: Batteries. B: Damages

due to misuse. C: Abuse or accidents. D: Cracked or broken cases. E: Negligence of Precautions. F: Improper maintenance or commercial use. D: Repairs made by a non-Authorized technician. The warranties contained herein are expressly in lieu of any other warranties including implied warranty of merchantability and/or fitness for purpose. In no event

Shall Ekho be liable for arising out of or related to the use of this manual or the products

Described herein

## 10. Disclaimer

The material in this manual is for informational purposes only. The products it describes are subject to change without prior notice, due to the manufacturer's continuous development program.

Ekho makes no representations or warranties with respect to this manual or with respect to the products described herein. Ekho shall not be liable for any damages, direct or incidental, consequential or special, arising out of, or related to the use of this material or the products described herein.

EKHO Brand Americas, LLC 1624 Harmon Place Suite 207 Minneapolis, Minnesota 55403 001-612-922-3766 001-612-922-3767

www.ekho.us

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com