

GIGABYTE™

Quick Installation Guide

快速安裝說明 快速入門指南

- English VI.0
- 繁體中文
- 簡體中文



Welcome!

歡迎使用W566U/N筆記型電腦!


欢迎使用W566U/N笔记本电脑!

Congratulations on your purchase of the W566U/N Notebook computer. This Quick Start Guide offers information to guide you through a successful Notebook Setup.


感謝您選擇W566U/N筆記型電腦。為協助您順利使用W566U/N筆記型電腦，我們特地設計這份「快速安裝說明」來協助您開始設定您的W566U/N筆記型電腦。

感谢您选择W566U/N笔记本电脑。为协助您顺利使用W566U/N笔记本电脑，我们特地设计这份「快速入门指南」来协助您开始设定您的W566U/N笔记本电脑。


1 Know Your W566U/N Notebook Computer • 認識您的W566U/N筆記型電腦 • 认识您的W566U/N笔记本电脑




- | | |
|---------------------------------------|---------------------------------------|
| 1. Web Cam/網路攝影機 網路攝影機 | 5. Power Button / 電源鍵/电源键 |
| 2. LCD Display Screen/LCD顯示螢幕/LCD顯示螢幕 | 6. Touchpad/觸控板/触摸板 |
| 3. Launch Keys/快速鍵/快速键 | 7. Keyboard/鍵盤/键盘 |
| 4. Light Sensor/光亮感測功能/光亮感測功能 | 8. Dual Array Microphone/雙陣列麥克風/陣式麦克风 |




- | | |
|---------------------------------------|-------------------------|
| 1. Battery Bay/電池組槽/电池组槽 | 3. Fan Vent/風扇排出口/风扇排出口 |
| 2. Battery Release Latch/電池釋放卡/电池释放卡锁 | 4. Stereo / 立體聲喇叭/立体声喇叭 |



- | | |
|--|--|
| 1. LCD Latch/LCD 栓鎖/LCD栓鎖 | 5. Microphone Jack / 麥克風插孔 / 麦克风插孔 |
| 2. Status LED Indicator/LED 狀態指示燈/LED状态指示灯 | 6. IEEE 1394 Port / IEEE 1394 連接埠/ IEEE 1394 连接埠 |
| 3. Headphone Jack/耳機插孔/耳机插孔 | |
| 4. Line-in Jack/Line-in 插孔/Line-in 插孔 | |



- | | |
|--|--|
| 1. 4-in-1 Card Reader/4合1多媒體讀卡槽/4合1多媒体读卡器插槽 | 6. Optical Disc Eject Button/光碟機退片鍵/光驅退片键 |
| 2. PCI Express Card or New Card Slot/PCI Express卡或New Card插槽/PCI Express Card或New Card插槽 | 7. Emergency Eject Hole/緊急退片孔/紧急退片孔 |
| 3. USB Port/USB埠/USB埠 | 8. Modem Port / 數據機埠/调制解调器 |
| 4. Optical Disc Drive / 光碟機/光驱 | 9. USB Port / USB埠/USB埠 |
| 5. Optical Drive Indicator/光碟機狀態指示燈/光驅状态指示灯 | 10. Kensington Lock/Kensington 防盜鎖插槽 / Kensington防盜鎖插槽 |



- | | |
|--|--|
| 1. Power Port / 電源輸入插孔 / 电源输入插孔 | 4. External Display Port / 外部顯示器埠/外部顯示器埠(W566N DVI; W566U D-SUB) |
| 2. Port Replicator Connector/擴充底座連接埠/扩充底座连接埠 | 5. S-Video Port/S-Video埠/S-Video埠 |
| 3. LAN Port / LAN埠 / LAN埠 | 6. USB Ports/USB埠/USB埠 |

2 Setup • 開始使用 • 开始使用

- Slides in battery / 電池組安裝到電腦之中 / 电池组安装到电脑之中
- Connect to the AC power source / 連接AC電源 / 连接AC电源变压器
- Open the LCD panel to a comfortable viewing angle / 掀起螢幕並將螢幕調整至最適合觀看的角度 / 掀起屏幕并将屏幕调整至最适合观看的角度
- Press the power button to turn on the power / 按下電源鍵來啟動您的筆記型電腦 / 按下电源键来启动您的笔记本电脑

3 Status LED Indicator • LED狀態指示燈 • LED状态指示灯

Power / 電源指示燈 / 电源指示灯

It glows blue when the computer is on; It flahs blue when the computer is in the suspend mode. The light is off when the computer is in the Hibernation mode or shut down.
 電源指示燈亮起藍燈表示您的電腦系統已經啟動。如果閃爍藍燈表示筆記型電腦處於待機模式。如果電源指示燈熄滅則表示系統進入 Save-to-Disk 模式或已關閉電源。
 電源指示燈亮起藍燈表示您的計算機系統已經啟動。如果閃爍藍燈表示筆記型計算機位於待機模式。如果電源指示燈熄滅則表示系統進入 Save-to-Disk 模式或已關閉電源。

Battery Status Indicator / 電池狀態顯示燈 / 电池状态显示灯

Battery status indicator tells you whether the battery is charging or is already charged. If you are charging your battery, light remains on even if your notebook is shut off. If there's no battery activity, the power adapters are not connected, or the power switch is off, the battery indicator will also be off.

電池狀態顯示燈顯示電池正在充電或已充滿電。如果電池正在充電，電腦開機後指示燈仍會亮著。如果未使用電池、未接上電源變壓器，或電源已關，指示燈則會熄滅。
 電池狀態顯示燈顯示電池正在充電或已充滿電。如果電池正在充電，計算機開機後指示燈仍會亮著。如果未使用電池、未接上電源變壓器，或電源已關，指示燈則會熄滅。

Wireless LAN / 無線區域網路存取指示燈 / 无线局域网存取指示灯

This indicator tells you whether your computer is connected to a wireless network or not. 顯示電腦是否已連結至無線區域網路。
 顯示電腦是否已連結至無線區域網路。

Media Card Status Indicator / 讀卡狀態指示燈 / 读卡状态指示灯
 This light flickers when the computer is reading a multimedia or SD card. 電腦讀取多媒體卡或SD卡時此燈號將會閃爍。
 电脑读取多媒体卡或SD卡時此灯就会閃爍。

Caps Lock / 大寫鎖定 / 大写锁定
 This indicator tells you that the keyboard is set to type in all capital letters. 顯示鍵盤設定為全部大寫字母。
 显示键盘设定为全部大写字母。

Num LK / 數字鎖定 / 数字锁定
 Lights up when the numeric mode is turned on by pressing [Num LK]. Press [Num LK] again to turn off the embedded numeric keyboard. 指示燈亮起表示 [Num LK] 數字鎖已開啟。您可以再按下 [Num LK] 一次來解除鎖定。
 指示灯亮起表示 [Num LK] 数字锁已开启。您可以再按下 [Num LK] 一次来解除锁定。

Optical Drive and Hard Disk Drive (HDD) accessed/
 光碟機與硬碟存取指示/光驱读取与硬盘存取指示
 Lights up when the computer is reading information from the optical drive. This indicator tells you whether your internal hard drive is being accessed and, if so, how fast. 指示燈亮起表示正讀取光碟機資料。
 顯示硬碟是否正被讀取，以及存取的速度。
 指示灯亮起表示正读取光驱数据。
 显示硬盘是否正被读取，以及存取的速度。

This Quick Start Guide is intended for use only as a quick reference. For more detailed information and procedures, please consult the user manual included in your package or visit us at <http://www.gigabyte.com.tw>

「快速安裝說明」是協助您的簡易快速參考指南。如果您需要更多關於電腦功能和資訊請仔細查閱您的「使用手冊」。另外您也可以利用我們的官方網站 <http://www.gigabyte.tw> 查詢您需要的資料。

「快速安裝說明」是協助您的簡易快速參考指南。如果您需要更多關於電腦功能和資訊請仔細查閱您的「使用手冊」。另外您也可以利用我們的官方網站 <http://www.gigabyte.com.tw> 查詢您需要的資料。



HDTW7001010

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>