

#### **OPERATION INSTRUCTION**



EHD705 OUTDOOR / VANDAL DOME

ED705 INDOOR DOME

# HIGH PERFORMANCE TRUE WDR LOW PROFILE DOME

EHD705 ED705

#### **EVERFOCUS ELECTRONICS CORPORATION**

# **Operation Instruction**

#### 2013 EverFocus Electronics Corp

Please read this manual first for correct installation and operation. This manual should be retained for future reference. The information in this manual was current when published. The manufacturer reserves the right to revise and improve its products. All specifications are therefore subject to change without notice.

All rights reserved. No part of the contents of this manual may be reproduced or transmitted in any form or by any means without written permission of the EverFocus Electronics Corporation.

#### **Precautions**

- 1. Do not install the camera near electric or magnetic fields.
  - Install the camera away from TV/radio transmitters, magnets, electric motors, transformers and audio speakers since the electromagnetic fields generated from these devices may distort the video image or otherwise interfere with camera operation.
- 2. Never disassemble the camera beyond the recommendations in this manual nor introduce materials other than those recommended herein. Improper disassembly or introduction of corrosive materials may result in equipment failure or other damage.
- 3. Try to avoid facing the camera toward the sun.

In some circumstances, direct sunlight may cause permanent damage to the sensor and/or internal circuits, as well as creating unbalanced illumination beyond the capability of the camera to compensate.

- 4. Keep the power cord away from water and other liquids and never touch the power cord with wet hands. Touching a wet power cord with your hands or touching the power cord with wet hands may result in electric shock.
- Never install the camera in areas exposed to oil, gas or solvents.
   Oil, gas or solvents may result in equipment failure, electric shock or, in extreme cases, fire.
- 6. Cleaning

For cameras with interchangeable lenses, do not touch the surface of the sensor directly with the hands. Use lens tissue or a cotton tipped applicator and ethanol to clean the sensor and the camera lens. Use a damp soft cloth to remove any dirt from the camera body. Please do not use complex solvents, corrosive or abrasive agents for cleaning of any part of the camera.

7. Do not operate the camera beyond the specified temperature, humidity or power source ratings. This camera is suitable for indoor and outdoor operation. Use the camera at temperatures within -10°C~50°C (14°F~122°F) and in an IP66 compliant environment; this device is not rated as submersible. The input power source is 12VDC. The use of properly fused or Class 2 power limited type supplies are highly recommended.

#### 8. Mounting

Use care in selecting a solid mounting surface which will support the weight of the camera plus any wind, snow, ice or other loading, and securely attach the camera to the mounting surface using screws and anchors which will properly support the camera. If necessary (e.g. when mounting to drop ceilings) use a safety wire to provide additional support for the camera.



**ATTENTION!** This is a class A product which may cause radio interference in a domestic environment; in this case, the user may be urged to take adequate measures.



#### **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the users' authority to operate this equipment.

## **Table of Contents**

- 1. CAUTIONS
- 2. IMPORTANT SAFETY INSTRUCTION
- 3. EQUIPMENT AND ACCESSORIES
- 4. CAMERA COMPONENT DESCRIPTIONS
  - Indoor Dome / Outdoor-Vandal Dome Type
- 5. INSTALLATION
  - Indoor Dome / Outdoor-Vandal Dome Type
- 6. DIMENSIONS
  - Indoor Dome / Outdoor-Vandal Dome Type
- 7. SPECIFICATION
- 8. OSD MANUAL
  - Menu structure
  - Function Description

## Chapter

1

#### 1. Product Overview


Get incredible bright light and low light performance plus the resolution listed in the specs from the actual cameras you install. To take full advantage of the amazing images produced by this advanced imaging technology, the EverFocus Ultra Series ED705 uses a Sony Double Scan 960H WD sensor together with a megapixel lens to produce **True** Wide Dynamic Range (WDR) performance with 720 horizontal TV lines of resolution from this unique Ultra Series 720+ camera. Combine a native low light sensitivity of 0.05 lux with field programmable digital slow shutter and this camera truly provides color without compromise: over 720TVL resolution, plus your choice of full motion color or day/night images in ultra low light (no ghosting when using practical DSS setting of ~4X) and Double Scan True Wide Dynamic Range for clear color images in the most challenging of bright or unbalanced scene lighting conditions. The ED705 offers a unique low profile housing with 3 axis positioning for wall or ceiling surface mounting flexibility; 3.7mm megapixel lens that covers a 65° wide field of view; dual voltage operation and a full suite of OSD Menu and DSP functions controllable at the camera (3D-DNR to save DVR HDD space, digital image stabilization, privacy masking, mirroring, and much more). This is the camera that you have been waiting for to create analog CCTV systems that produce astounding image clarity in the widest range of indoor applications under almost any lighting conditions.

#### 1.1 Features

- True Wide Dynamic Range expansion from double scan sensor plus electronic ATR-EX to deliver properly exposed images despite bright or unbalanced lighting in the scene
- Ultra resolution of over 720 horizontal TV lines for astounding image quality
- Unique low profile housing design with 3-Axis positioning for convenient wall or ceiling mounting
- Fixed 3.7mm megapixel lens captures a 67° wide field of view
- Video test output point for convenient aim and focus during installation, and ease of service
- Exview HAD II sensor delivers amazing ultra high sensitivity of .05 lux low light sensitivity before DSS low light boost
- Adjustable low light enhancement for superlative performance without ghosting
- Color without compromise: your choice of full motion color or day/night images in low light without ghosting
- Easy to use OSD setup menu control includes a wide range of image control options
- Back light compensation (BLC) and Highlight Compensation (HLC)
- Adjustable 3D-Noise Reduction increases picture clarity while improving DVR disk storage utilization
- Privacy mask function for 15 configurable zones
- Dual voltage (12VDC/24VAC) with Anti Color Roll for stability even without line lock


# 3. EQUIPMENT AND ACCESSORIES

Indoor Dome Type	Mount Guide (Indoor Dome Type)
	<b>+</b>   <b>+</b>
Outdoor Vandal Dome Type	Mount Guide (Outdoor Vandal Dome Type)
	*



# 4. CAMERA COMPONENT DESCRIPTIONS


• Indoor Dome Type



NO	PART NAME		
1	Top Case		
2	Lens Cover		
3	Camera Module Bracket		
4	Camera Module Ass'y		
5	Cable		
6	Main PCB		
7	OSD Controller		
8	Base		

# 4. CAMERA COMPONENT DESCRIPTIONS

#### • Vandal Dome Type




NO	PART NAME
1	Top Case
2	Lens Cover
3	Case Rubber
4	Camera Module Bracket
5	Camera Module Ass'y
6	Main PCB
7	Safety Wire
8	OSD Controller
9	Base


## 5. INSTALLATION (Plastic Dome)


1. Attach the Low Profile Dome on the ceiling using the screws provided. Considering the camera angle required for the viewing angle.

2. Adjust the Lens Angle to the desired location.


TAPPING SCREW (4 x 20L) - 3EA








4. After adjusting the Lens, install the Top Cover.




## 5. INSTALLATION (Vandal Dome)


1. Attach the Low Profile Dome on the ceiling using the screws provided. Considering the camera angle required for the viewing angle

2. Adjust the Lens Angle to the desired location.




3. Connect the Service Video Output Cable and check the video image. Change the Settings accordingly using the OSD Controller.






4. After adjusting the Lens, install the Top Cover.



### 5. INSTALLATION

#### MONITOR CONNECTION

#### - DC12V/AC24V





When you install the camera, please glue up the end of cable to keep it stable in order to protect the camera from the humidity problems.


## 6. DIMENSIONS


• Indoor Dome Type


• Outdoor Vandal Dome Type














Unit(Inches)

## 7. SPECIFICATION

	NTSC	PAL		
Image Sensor	1/3" 960H SONY Double Scan Super HAD CCD II			
Scanning System	2 : 1 Interlace			
H Resolution.	700TV Lines			
Scanning Frequency	15.734KHz(H), 59.94Hz(V)	15.625KHz(H), 50Hz(V)		
Total Pixels No.	1028(H) X 508(V)	1028(H) X 596(V)		
Effective Pixels No.	976(H) X 494(V)	976(H) X 582(V)		
S/N Ratio	More than 50dB(AGC OFF, 3DNR ON)			
Min. Illumination	Color:0.1Lux, BW:0.1Lux (30IRE@F2.0	, AGC 36dB) 0.000001Lux (DSS x256)		
Sync System	Inte	rnal		
Gamma	r= 0	0.45		
Video Output	1.0 Vp-p Con	nposite(75Ω)		
Lens	Board	Lens		
Digital Zoom Ratio	3	x		
Electronic Shutter	1/60 ~1/100,000sec	1/50 ~1/100,000sec		
Digital Slow Shutter	OFF, 2 ~ .	256 Field		
Flickerless	ON / OFF			
Dynamic Range	52dB (WDR OFF) / 116.4dB (WDR ON)			
WDR	ON / OFF (Level adjustable)			
BLC	ON / OFF (Level adjustment, Area selection)			
HLC	ON / AUTO / OFF (Level adjustable)			
AGC	OFF, 6 ~ 36dB			
DNR(2D/3D)	ON / OFF (Level adjustable)			
Image Function	Image Flip, Freeze, Contrast, Sharpness			
Day & Night	COLOR / BW / AUTO(DIGITAL D/N)			
Motion Detection	4 Zones (Level adjustable, Area adjustment)			
Privacy Masking	15 Zones (Area adjustment)			
White Balance	ATW / PUSH / USER1 / USER2 / ANTI CR / MANUAL / PUSH-LOCK			
OSD	Built in (Joystick)			
Language	ENGLISH / JAPANESE / GERMAN / FRENCH / RUSSIAN / PORTUGUESE / SPANISH / CHINESE			
Operating Temperature	14°F~122°F(-10°C~+50°C)			
Storage Temperature	-4°F~140°F(-20°C~+60°C)			
Humidity	Less than 80%			
Power Consumotion	DC12V (±10%), Max. 190mA AC24V (±10%), Max. 2.5W			
Dimension (mm)	Indoor Dome Type: 119mm x 119mm x 42mm Outdoor Vandal Dome Type: 139mm x 134mm x 49mm			

Specifications and designs are subject to change for improving the functionality of this product without notice.

# 8. OSD MANUAL

#### • Menu structure

Main MENU	1st Sub MENU	2nd Sub MENU	3rd Sub MENU	4th Sub MENU	5th Sub MENU	
		HIGH LUMINANCE	FLICKERLESS	OFF / ON		
			BRIGHTNESS	0 ~ 255	0 ~ 255	
		LOW LUMINANCE	MODE	AGC, SLOW, AGC > AGC, OFF	AGC, SLOW, AGC > SLOW, SLOW > AGC, OFF	
	AUTO		AGC MAX	6, 12, 18, 24, 30, 36	5	
			DSS MAX	2, 4, 8, 16, 32, 64, 1	2, 4, 8, 16, 32, 64, 128, 256	
EVE 0 61 1 D E			BRIGHTNESS	x0.25, x0.5, x0.75,	x1.0	
EXPOSURE		RETURN				
		MODE	SHUT, SLOW			
	MANUAL	SHUT	MODE (SHUT) ONLY 1/50(PAL), 1/60(NTSC), 1/100(NTSC), 1/120(PAL), 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/10000 MODE (SLOW) ONLY 2, 4, 8, 16, 32, 64, 128, 256			
		AGC	6, 12, 18, 24, 30, 36, 42,	44.8		
		RETURN				
		SPEED	0 ~ 255			
		DELAY CNT	0 ~ 255			
	ATW	ATW FRAME	x0.5, x1.0, x1.5, x2.0			
		ENVIRONMENT	INDOOR, OUTDOOR			
		RETURN				
	PUSH					
	USER1	B-GAIN	0 ~ 255			
		R-GAIN	0 ~ 255			
WHITE		RETURN				
BALANCE		B-GAIN	0 ~ 255			
	USER2	R-GAIN	0 ~ 255			
		RETURN				
	ANTI CR					
		LEVEL UP	PUSH ENTER			
		LEVEL DOWN	PUSH ENTER			
	MANUAL	PRESET				
		RETURN				
	PUSH LOCK					
	COLOR					
DAY&NIGHT	AUTO	BURST	OFF, ON			
		DELAY CNT	0 ~ 255			
		DAY > NIGHT	0 ~ 255			
		NIGHT > DAY	0 ~ 255			
		RETURN				
	BW	BURST	OFF, ON			
		RETURN				

# 8. OSD MANUAL

Main MENU	1st Sub MENU	2nd Sub MENU	3rd Sub MENU	4th Sub MENU	5th Sub MENU
			LEVEL	0 ~ 15	
WDR/BLC		OFF, ON	CONTRAST1	0 ~ 7	
	WDR MODE		CONTRAST2	0 ~ 4	
			RETURN		
		OFF, ON	ZONE	CENTER, TOP, BOTTOM, LEFT, RIGHT	
	BLC MODE		LEVEL	0 ~ 15	
			RETURN		
			CLIP LEVEL	0 ~ 255	
	HLC MODE	OFF, ON, AUTO	SCALE	0 ~ 15	
			RETURN		
	2DNR MODE	OFF, ON			
	2DNR LEVEL	0 ~ 15			
DNR	3DNR MODE	OFF, ON			
	3DNR LEVEL	0 ~ 63			
	RETURN				
	HV-FLIP	OFF, ON			
	FREEZE	OFF, ON			
IMAGE	EZOOM	1.0x, 1.5x, 2.0x, 2.5x, 3.0x			
	CONTRAST	0 ~ 63			
	SHARPNESS	0 ~ 15			
	RETURN				
	CAMERA TITLE	OFF, ON	DISPLAY THE TITLE	EDITING MENU	-
			RETURN		
	LANGUAGE	ENGLISH / 中文 / Русский / ESPAÑOL / DEUTSCH / FRANCAIS / PORTUGUÊS / 日本語			
		AREA SEL	1/15 ~ 15/15		
		MODE	OFF, ON		
		POSITION	NEXT: PUSH ENTER		
	PRIVACY	COLOR	"WHITE, BLACK, RED, GREEN, BLUE, YELLOW, CYAN, MAGENTA"		
		TRANSP	0.00, 0.50, 0.75, 1.00		
SPECIAL		MOSAIC	OFF, ON		
		RETURN			
			DETECT SENSE	0 ~ 127	
	MOTION DET		BLOCK DISP	OFF, ON	
				AREA SEL	1/4 ~ 4/4
				MODE	OFF, ON
		OFF, ON		TOP	0 ~ 15
			MONITOR AREA	BOTTOM	0 ~ 15
				LEFT	0 ~ 23
				RIGHT	0 ~ 23
				RETURN	
FACTORY DEFAULT					
EXIT					
SAVE&EXIT					

## EverFocus Electronics Corp.

EverFocus Taiwan: 12F, No.79, Sec. 1, Shin-Tai Wu Road, Hsi-Chih, Taipei, Taiwan TEL: +886 2 2698 2334 FAX: +886 2 2698 2380 www.everfocus.com.tw marketing@everfocus.com.tw	EverFocus Europe - Germany: Albert-Einstein-Strasse 1, D-46446 Emmerich, Germany TEL: +49 2822 93940 FAX: +49 2822 939495 www.everfocus.de info@everfocus.de
EverFocus China - Beijing: Room 609, Technology Trade Building, Shangdi Information Industry Base, Haidian District, Beijing 100085, China TEL: +86 10 6297 3336~39 FAX: +86 10 6297 1423 www.everfocus.com.cn marketing@everfocus.com.cn	EverFocus China - Shenzhen: 4F, No. 2, D4 Building, Wan Yelong Industrial Park, Tangtou Road, Shiyan, Baoan, Shenzhen, Guangdong 518101, China TEL: +86 755 2765 1313 FAX: +86 755 2765 0337 www.everfocus.com.cn marketing@everfocus.com.cn
EverFocus USA - California: 1801 Highland Avenue, Unit A, Duarte, CA 91010, USA TEL: +1 626 844 8888 FAX: +1 626 844 8838 www.everfocus.com sales@everfocus.com	EverFocus USA - New York: 415 Oser Avenue, Unit S, Hauppauge, NY 11788, USA TEL: +1 631 436 5070 FAX: +1 631 436 5027 www.everfocus.com sales@everfocus.com
EverFocus Japan: 5F, Kinshicho City Building, 2-13-4 Koto-Bashi, Sumida-Ku, Tokyo, 130-0022, Japan TEL: +81 3 5625 8188 FAX: +81 3 5625 8189 www.everfocus.co.jp info@everfocus.co.jp	EverFocus Europe - UK: Unit 12, Spitfire Business Park, Hawker Road, Croydon Surrey, CR0 4WD, UK TEL: +44 (0) 20 8649 9757 / 0845 430 9999 FAX: +44 (0) 20 8649 9907 www.everfocus.com salesuk@everfocus.com
EverFocus India: Suite 803, Housefin Bhavan, C-21, Bandra Kurla Complex, Bandra (East), Mumbai 400051, India TEL: +91 22 6128 8700 FAX: +91 22 6128 8705 www.everfocus.in sales@everfocus.in	



Your EverFocus product is designed and manufactured with high quality materials and components which can be recycled and reused.
This symbol means that electrical and

electronic equipment, at their end-oflife, should be disposed of separately from your household waste. Please, dispose of this equipment at your local community waste collection/recycling centre. In the European Union there are separate collection systems for used electrical and electronic product.

Please, help us to conserve the

environment we live in!

Ihr EverFocus Produkt wurde entwickelt und hergestellt mit qualitativ hochwertigen Materialien und Komponenten, die recycelt und wieder verwendet werden können. Dieses Symbol bedeutet, dass elektrische und elektronische Geräte am Ende ihrer Nutzungsdauer vom Hausmüll getrennt entsorgt werden sollen. Bitte entsorgen Sie dieses Gerät bei

Bitte entsorgen Sie dieses Gerät bei Ihrer örtlichen kommunalen Sammelstelle oder im Recycling Centre. Helfen Sie uns bitte, die Umwelt zu erhalten, in der wir leben!



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com