



## iBlaster Silhouette



Model No. 188BK


Congratulations on your purchase of the iBlaster Silhouette from Excalibur Electronics, Inc. You and your friends will enjoy hours of great music with this innovative speaker set. It produces hi-fi quality sound and is compatible with iPod® Nano, iPod® video, MiniDISC players, MP3 players and portable media players. It even includes a handy remote control.









STANDBY: Press it to turn the speaker on, press again to turn it off.  
PLAY/PAUSE: Press to play, press to pause.  
MENU: Press to enter the MENU screen.  
DOWN: Press to scroll down.  
UP: Press to scroll up.  
ENTER: Press to select.  
PREV: Press to play the previous song.  
NEXT: Press to play the following song.  
VOL -: Press to decrease the volume.  
VOL+: Press to increase the volume.



STEP 1: Unpack the unit, wall adapter, iPod adapters and cable, then read this manual completely.




STEP 2: Choose the correct iPod adapter type and press the iPod adapter into the socket. If your iPod has a bottom connector, dock your iPod with the connector.




STEP 3: Plug the power adapter into the “12V DC In” jack and insert the AC adapter to a wall socket. Press the POWER button on the top of the unit and a blue light will turn on.





STEP 4: If you're using any other Audio products, connect the auxiliary cable from the headphone to the "Audio In" jack on the back of the unit.



STEP 5: If you're using a computer, connect the USB cable to the to the computer and the USB jack on the back of the unit.

EXCALIBUR ELECTRONICS, INC., warrants that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address shown to the right.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the product. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of implied

warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instance may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.  
13755 SW 119th Avenue  
Miami, FL 33186  
T: 305.477.8080  
F: 305.477.9516  
[www.ExcaliburElectronics.com](http://www.ExcaliburElectronics.com)

Ship the unit carefully packed, preferably in the original carton, and send it prepaid and adequately insured. Include a letter, detailing the complaint and include your daytime telephone number inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>