# Extron. Electronics



## User's Guide



## VersaTools™ MDA 5V, 5SV, 5A RCA

## **Mini Distribution Amplifiers**

68-614-01 **Rev. B** Printed in the USA 08 02

Download from Www.Somanuals.com. All Manuals Search And Download.

## Introduction

The Extron MDA 5 Series of Mini Distribution Amplifiers (MDAs) are a family of three video and audio distribution amplifiers. The MDA are members of the Extron VersaTools<sup>™</sup> line of basic distribution amplifiers, switchers, and associated video accessories.

The MDA 5V distributes buffered composite video, the MDA 5SV distributes buffered S-video (luminance (Y) and chrominance (C)), and the MDA 5A RCA distributes amplified stereo audio, on RCA outputs.


The MDAs ship with external, desktop 12V power supplies, which accept 100-240VAC input.

## Installation

The MDA 5V, 5SV, and 5A RCA can be mounted on a rack shelf, under a desk or tabletop, or on a projector bracket.

## **Rack mounting**

For optional rack mounting, mount the MDA on a VersaTools 19" 1U Rack Shelf (Extron part **#60-190-20**) (figure 1) or a standard Universal 1U Rack Shelf (Extron part **#60-190-01**) (figure 2). On the standard rack shelf, the MDA mounts in one of four locations to the rear of the rack or in one of four locations to the front of the rack.




## Figure 1 — Rack mounting the MDA 5V, 5SV, or 5A RCA on the VersaTools shelf

- 1. If feet were previously installed on the bottom of the MDA, remove them.
- 2. Mount the MDA on the rack shelf, using two 4-40 x 3/16 screws in opposite (diagonal) corners to secure the MDA to the shelf.

- 3. Install blank panel(s) or other unit(s) to the rack shelf.
- 4. Insert the shelf into the rack, aligning the holes in the shelf with those of the rack.
- 5. Secure the shelf to the rack using the supplied machine screws. This shelf can be mounted in the front or in the rear of the rack.



Only products in the VersaTools line can be mounted to a VersaTools shelf. Any 1U rack-mountable Extron product can be mounted on the standard shelf.






## Furniture or projector mounting

Furniture mount or projector mount the MDA using the optional mounting kit (Part **#70-212-01**, furniture, or **70-217-01**, projector) as follows:

1. Attach the mounting brackets to the MDA with the machine screws provided (figure 3).



#### 2 MDA 5V, 5SV, 5A RCA • Installation

## Installation

- **2**. If feet were previously installed on the bottom of the MDA, remove them.
- **3. For furniture mounting,** hold the MDA with the attached brackets against the underside of the table or other furniture. Mark the location of the screw holes of the bracket on the mounting surface.
- 4. For furniture mounting, drill 3/32" (2 mm) diameter pilot holes, 1/4" (6.3 mm) deep in the mounting surface at the marked screw locations.
- 5. For furniture mounting, insert #8 wood screws into the four pilot holes. Tighten each screw into the mounting surface until just less than 1/4" of the screw head protrudes.
- 6. For furniture mounting, align the mounting screws with the slots in the brackets and place the MDA against the surface, with the screws through the bracket slots.
- 7. **For furniture mounting,** slide the receiver slightly forward or back, then tighten all four screws to secure the MDA in place.
- 8. For projector mounting, secure the MDA to a projector mount or other surface by inserting the mounting bolt through the bracket's slotted hole.

## **Connections and Indicator**

Refer to figure 5.

- (1) **Video Input connector** (MDA 5V composite video and MDA 5SV S-video) Connect an input to this connector.
- (2) Video Outputs (1 through 5) connectors Connect up to five video devices to these connectors. (MDA 5V composite video and MDA 5SV S-video).
- (3) **Power connector** Plug the external 12V power supply into this 2-pole captive screw connector. The power supply is included with the unit. Figure 4 shows how to wire the connector.

### CAUTION

When connecting the power supply, voltage polarity is extremely important. Applying power with incorrect voltage polarity could damage the power supply and the MDA. Identify the power cord negative lead by the ridges on the side of the cord.



Captive Screw Connector





Figure 4 — Power connector wiring



Do not tin the stripped power supply leads before installing the captive screw connector. Tinned wires are not as secure in the captive screw connectors and could pull out.

#### WARNING

The two power cord wires must be kept separate while the power supply is plugged in. Remove power before continuing.

To verify the polarity before connection, plug in the power supply with no load and check the output with a voltmeter.




Figure 5 — MDA 5V front and rear panels

## **Specifications**

- **Power LED** Indicates power is applied. (4)
- 5 Loop connector — Provides passive loop-through for signal
- High Z / 75 Ohm switch Select 75-ohm termination on (6) or off.

**High Z** — Select this position (up) if you are connecting a terminated device to the Loop connector.

75 Ohm — This position (down) terminates the Input connector with 75 ohms of impedance. Select this position if you are not using the Loop connector, or if you are connecting an unterminated device to the Loop connector.

- (7) Audio input (left and right) connectors — Connect unbalanced stereo to this RCA connector
- (8) Audio output (1 through 5, left and right) connectors — Connect up to five audio (stereo) devices to these RCA connectors.

## **Specifications**

#### Video

| Gain                     | Unity               |
|--------------------------|---------------------|
| Bandwidth                |                     |
| MDA 5SV                  | 270 MHz (-3dB)      |
| MDA 5V                   | 435 MHz (-3dB)      |
| Differential phase error | 0.05°, 0 to 50 MHz  |
| Differential gain error  | <0.05%, 0 to 50 MHz |

### **Video input**

| •                        |  |
|--------------------------|--|
| Number/signal type       |  |
| MDA 5SV                  | 1 NTSC/PAL/SECAM S-video                 |
| MDA 5V                   | 1 NTSC/PAL/SECAM composite video         |
| Connectors               |  |
| MDA 5SV                  | 1 4-pin mini DIN female                  |
| MDA 5V                   | 1 BNC female                             |
| Nominal levels           | Composite video and Y of S-video: 1V p-p |
|                          | C of S-video: 0.3V p-p                   |
| Minimum/maximum level(s) |  |
| MDA 5SV                  | Y: 0.4V to 2.0V p-p with no offset       |
| MDA 5V                   | 0.4V to 2.0V p-p with no offset          |
| Impedance                | 75 ohms                                  |
| Return loss              | <-40dB @ 0 to 10 MHz for MDA 5V          |
|                          | <-25dB @ 0 to 10 MHz for MDA 5SV         |
| Maximum DC offset        | 1.0V                                     |
|                          |  |

### Video output

| Number/signal type       |  |
|--------------------------|--|
| MDA 5SV                  | 6 S-video: 5 buffered for distribution, 1 passive loop-through |
| MDA 5V                   | 6 composite video: 5 buffered for                              |
|                          | distribution, 1 passive loop-through                           |
| Connectors               |  |
| MDA 5SV                  | 6 4-pin mini-DIN   |
| MDA 5V                   | 6 BNC female   |
| Nominal levels           | Composite video and Y of S-video: 1V p-p                       |
|                          | C of S-video: 0.3V p-p   |
| Minimum/maximum level(s) | 0.4V to 2.0V p-p   |
| Impedance                | 75 ohms  |
| Return loss              | -30dB @ 5 MHz  |
| DC offset                | ±5mV maximum with input at 0 offset                            |
| _                        |  |

#### Sync

#### Standards ...... NTSC 3.58, NTSC 4.43, PAL, SECAM

#### Audio — MDA 5A RCA

| Gain                      | Unity (0dB)                           |
|---------------------------|---------------------------------------|
| Frequency response        | 20 Hz to 20 kHz, ±0.05dB              |
| THD + Noise               | 0.03% @ 1 kHz at nominal level        |
| S/N                       | >90 dB, at rated maximum output drive |
| Stereo channel separation | >80 dB @ 1 kHz; >60 dB @ 20 kHz       |
| CMRR                      | >75 dB @ 20 Hz to 20 kHz              |

### Audio input — MDA 5A RCA

| Number/signal type | 1 stereo unbalanced   |
|--------------------|---|
| Connectors         | 2 RCA connectors  |
| Impedance          | >10 kohms unbalanced, DC coupled  |
| Nominal levels     | Compatible with -10dBV (316mV), +4dBu<br>(1.23V), 0dBu (0.775V), -20dBV (100mV) |
| Maximum level      | +18 dBu unbalanced at 1%THD+N   |

### Audio output — MDA 5A RCA

| Number/signal type   | 5 stereo, unbalanced   |
|----------------------|--|
| Connectors           | 10 RCA connectors  |
| Impedance            | 50 ohms unbalanced   |
| Gain error           | ±0.1dB channel to channel  |
| Nominal levels       | Compatible with -10dBV (316mV), +4dBu (1.23V), 0dBu (0.775V), -20dBV (100mV) |
| Maximum level (Hi-Z) | >+18dBu, unbalanced at 1%THD+N   |

**NOTE**  $0dBu = 0.775 \ volts \ (RMS).$ 

6

### General

| Power                | 100VAC to 240VAC, 50/60 Hz, 5 watts,<br>external, auto-switchable; to 12VDC,<br>1 A (max.) power supply. Product requires<br>0.4 A (max).                  |
|----------------------|--|
| Temperature/humidity | Storage -40° to +158°F (-40° to +70°C) / 10%<br>to 90%, non-condensing<br>Operating +32° to +122°F (0° to +50°C) / 10%<br>to 90%, non-condensing           |
| Rack mount           | Yes, with optional 1U rack shelf, part #60-<br>190-01,<br>or the VersaTools rack shelf, part #60-190-20  |
| Enclosure type       | Metal  |
| Enclosure dimensions | <ul> <li>1.7" H x 4.3" W x 3.0" D (1U high, quarter rack width)</li> <li>4.2 cm H x 11.0 cm W x 7.6 cm D (Depth excludes connectors and knobs.)</li> </ul> |
| Product weight       | 0.7 lbs (0.3 kg)   |
| Shipping weight      | 3 lbs (1.4 kg)   |
| Vibration            | ISTA/NSTA 1A in carton (International Safe Transit Association)  |
| Listings             | UL, CUL  |
| Compliances          | CE, FCC Class A, VCCI, AS/NZS, ICES  |
| MTBF                 | 30,000 hours   |
| Warranty             | 3 years parts and labor  |

NOTE

Specifications are subject to change without notice.

## **FCC Class A Notice**

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Note: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to ensure compliance.



Extron Electronics, USA 1230 South Lewis Street Anaheim, CA 92805 USA 714.491.1500 Fax 714.491.1517 Extron Electronics, Europe Beeldschermweg 6C 3821 AH Amersfoort The Netherlands +31.33.453.4040 Fax +31.33.453.4050 Extron Electronics, Asia 135 Joo Seng Road, #04-01 PM Industrial Building Singapore 368363 +65.6383.4400 Fax +65.6383.4664 Extron Electronics, Japan Daisan DMJ Building 6F 3-9-1 Kudan Minami Chiyoda-ku, Tokyo 102-0074 Japan +81.3,3511.7655 Fax +81.3.3511.7656

© 2002 Extron Electronics. All rights reserved.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com