

Help Line

Australia	+ 1-800-33-11-77
Canada	+ 1-800-665-4339
México	+ 1-800-234-1185
United States	+ 1-800-955-0959

Fellowes

Australia	+ 61-3-8336-9700
Benelux	+ 31-(0)-76-523-2090
Canada	+ 1-905-475-6320
Deutschland	+ 49-(0)-5131-49770
France	+ 33-(0)-1-30-06-86-80
Italia	+ 39-071-730041
Japan	+ 81-(0)-3-5496-2401
Korea	+ 82-2-3462-2884
Malaysia	+ 60-(0)-35122-1231
Polska	+ 48-(0)-22-771-47-40
España	+ 34-91-748-05-01
Singapore	+ 65-6221-3811
United Kingdom	+ 44-(0)-1302-836836
United States	+ 1-630-893-1600

www.fellowes.com

Fellowes

1789 Norwood Avenue, Itasca, Illinois 60143-1095 • USA • 630-893-1600

<http://www.fellowes.com>

Australia
Benelux

Canada
China

Deutschland
España


France
Italia

Japan
Korea

Polska
Singapore

United Kingdom
United States

© 2007 Fellowes, Inc. Part No. 402663 REV E



DS-1

**Please read these instructions before use.
Veuillez lire ces instructions avant utilisation.
Lea estas instrucciones antes del uso.**

ENGLISH

Model DS-1

SafeSense® Technology (yellow)

Shredder head

See safety instructions below

Mesh basket

SafeSense® override switch



Step





Paper entry

Disconnect power switch

Overheated (red)

Standby (green)

Control switch



Lift and remove basket

Magnetic safety interlock

SAFE SENSE Breakthrough Safety Technology! SafeSense® stops shredding when hands are too close to the opening.


— To Test SafeSense® Technology

Shredder comes fully assembled. Remove basket packing material and plug in. Disconnect power switch must be in ON (I) position to operate shredder.


Press Auto-On (⏻)



Touch test area



Sensor lights up



CAPABILITIES

Will shred: Paper, small paper clips, credit cards and staples

Will not shred: Continuous forms, adhesive labels, transparencies, newspaper, cardboard, large paper clips, laminates or plastic other than noted above

Paper shred size:

Confetti-Cut 5/32" x 1-3/8" (3.9 x 35mm)

Maximum:

Sheets per pass (Confetti-Cut) 11*
 Cards per pass 1
 Paper width 9" / 229mm
 Continuous operation 4-5 minutes

*20 lb., 8.5"x11" paper at 120v, 60 Hz, 4.5Amps; heavier paper, humidity or other than rated voltage may reduce capacity.

Fellowes SafeSense® shredders are designed to be operated in home and office environments ranging between 50 – 80 degrees Fahrenheit (10 – 26 degrees Celsius) and 40 – 80% relative humidity.

IMPORTANT SAFETY INSTRUCTIONS — Read Before Using!

WARNING



- Keep away from children and pets. Keep hands away from paper entry. Always unplug when not in use.
- Keep foreign objects – gloves, jewelry, clothing, hair, etc. – away from shredder openings. If object enters top opening, press and hold Reverse (R) to back out object.



- Never use aerosol, petroleum-based or other flammable products on or near shredder. Do not use canned air on shredder.
- Do not use if damaged or defective. Do not open shredder head. Do not place near or over heat or water source.
- 11 sheets per pass to avoid jams.

CAUTION

- Avoid touching exposed blades under Confetti-Cut shredder head.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.

OPERATION




Continuous operation:
5 minute maximum

NOTE: Shredder runs briefly after each pass to clear entry. Continuous operation beyond 4-5 minutes will trigger 20-minute cool down period.



Set to Off



Set to Off

TROUBLESHOOTING

Paper jam: Set to Off and empty basket. Replace basket and follow any or all of the below procedures.



Press and hold Reverse (R)



Alternate slowly back and forth



Set to Off



Pull uncut paper from paper entry



Press and hold Reverse (R)

Shredder doesn't start:


- Yellow - SafeSense® active
- Yellow flashing - SafeSense® not active
- Make sure control switch is in Auto-On (power icon) position
- Clear paper particles covering magnetic safety interlock
- Wait 20 minutes for red light to turn off

ATTENTION: If the SafeSense® light remains on, you must engage the **Override Switch** in order to perform steps above. Once the jam is cleared, reset the SafeSense® feature. (See SafeSense® instructions below.)



SafeSense® paper jam: If the SafeSense® feature activates (SafeSense® light remains on) to cause the user to think the shredder has jammed when it has not, use the **Override Switch** to deactivate the SafeSense® feature and clear the paper. **Warning** – when switch is in override position, the SafeSense® light will flash and the SafeSense® feature will NOT function. Once the paper is cleared, reset the SafeSense® feature.

Sensor light illuminated—paper jammed



SafeSense® override switch



Active Not active

MAINTENANCE

Run regularly in reverse for one minute

Oil when bin is full, or immediately, if:


- Capacity decreases
- Motor sounds different, or Shredder stops running



Follow oiling procedure below and repeat twice.



Set to Off



*Apply oil across entry



Press Auto-On (power icon)



Shred one sheet



Press and hold Reverse (R) 2-3 seconds



CAUTION *Only use a non-aerosol vegetable oil in long nozzle container such as Fellowes 35250/3505006



WARRANTY

LIMITED WARRANTY Fellowes, Inc. ("Fellowes") warrants the cutting blades of the machine to be free from defects in material and workmanship for 5 years from the date of purchase by the original consumer. Fellowes warrants all other parts of the machine to be free of defects in material and workmanship for 1 year from the date of purchase by the original consumer. If any part is found to be defective during the warranty period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part. This warranty does not apply in cases of abuse, mishandling, or unauthorized repair. ANY IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE,

IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages attributable to this product.

This warranty gives you specific legal rights. The duration, terms, and conditions of this warranty are valid worldwide, except where different limitations, restrictions, or conditions may be required by local law.

For more details or to obtain service under this warranty, please contact us or your dealer.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>