

# POWERSHRED HS-660 THE WORLD'S TOUGHEST SHREDDERS



Please read these instructions before use. Do not discard: keep for future reference.

**Fellowes** 

Quality Office Products Since 1917



#### **KEY**

- A. Safety Flap
- B. Paper entry
- C. Disconnect switch (open door)
- D. Door
- E. Basket paper (inside)
- F. Casters
- G. See safety instructions
- H. Control Panel and LEDs

  - R 2. Reverse 3. Bin full
  - 4. Door open
  - 5. Safety Flap Open
  - 6. Low oil
  - 7. Auto oil complete

## **INDICATOR LIGHTS**







Stops automatically when bin is full. Empty bag when bag full indicator liahts up



Stops automatically if too much paper is inserted. Automatic reverse if paper iams



Stops automatically if safety flap is opened. Symbols flash alternately



Overload protection. Machine stops to cool down- approx. 10-15 minutes. Symbols flash alternately



Cutting shafts are automatically oiled



Oil bottle is empty

## **CAPABILITIES**

Will shred: Paper only

Will not shred: Adhesive labels, continuous form paper, transparencies. newspaper, junk mail, credit cards, CD/DVDs, staples, paper clips, cardboard, laminates, file folders, X-rays or plastic other than noted above Paper shred size:

High Security Micro-Cut.... (Din 6) 1/32 in. x 3/16 in. (0.8mm x 5.0mm)

#### Maximum:

Sheets per pass ..... 

\*8.5 in. x 11 in., 20lb., (75g) paper at 120V, 60 Hz, 8 Amps; heavier paper, humidity or other than rated voltage may reduce capacity. Recommended maximum daily usage rates: 3.000 sheets per day, 6 sheets per pass.

\* In order to perform at capacity, shredder must be plugged into a dedicated 15Amp, 120V outlet and auto oil system must be engaged.

## **ADVANCED PRODUCT FEATURES**



#### Auto Oil™

Lubricates the cutters automatically to enhance performance and extend shredder life



Energy saving feature shuts down the shredder after 1 hour of inactivity

## AWARNING: IMPORTANT SAFETY INSTRUCTIONS — Read Before Using!














Keep away from children and pets. Keep hands away from

paper entry. Always set to off or unplug when not in use.



canned air on shredder. Do not use if damaged or defective. Do not disassemble shredder. Do not place near or over heat source or water.


other flammable products on or near shredder. Do not use

- This shredder has a Disconnect Power Switch (C) in the door. The door must be closed to operate shredder. In case of emergency, open door. This action will stop shredder immediately.
- Avoid touching exposed cutting blades under shredder head.
- Shredder must be plugged into a properly grounded wall outlet or socket of the voltage and amperage designated on the label. The grounded outlet or socket must be installed near the equipment and easily accessible. Energy converters, transformers, or extension cords should not be used with this product.
- . Do not operate the machine without the safety flap closed (A).

#### **BASIC SET-UP**

## **BASIC SHREDDING OPERATION**

#### SHREDDER SET-UP



Open the door

Place cutter head into top of cabinet, use 2 people

Ensure access to a dedicated 15Amp, 120V outlet

Make sure safety flap is securely in place

#### PAPER



Plug in and make



Press (©) ON to sure door is closed activate



Feed paper When finished straight into paper entry and release shredding set to (c) OFF



Do nothing and shredder will go automatically to sleep mode after

1 hour

#### OILING SET-UP



Remove oil bottle holder from cabinet



Hook oil bottle holder into side of cabinet



Remove lid from oil bottle



Put oil tube into oil Place oil bottle bottle and screw into oil holder on stopper on side if cabinet



Close door, Plug into socket-outlet




Oil pump starts automatically on first use. To stop Oil Indicator ( $\Diamond$ ) from blinking red, press ON (©) after 15 seconds



After changing oil bottle, press Reverse (R) until Oil Indicator (a) no longer blinks red

## SHEET CAPACITY GAUGE

#### Eliminates frustrating jams by preventing overloads.



## **SLEEP MODE**

#### WHEN IN SLEEP MODE







To get out of sleep or press ON (🔿)



insert paper

## TROUBLESHOOTING and PREVENTIVE MAINTENANCE

- Empty wastebasket when bin full indicator lights up.
- Shredder won't run if the door is open, or bin needs to be emptied.
- Maintenance is an important part of protecting your investment. Don't forget to purchase our oil (3505801) and shredder bags (3604101).

Go to Support Section at www.fellowes.com or see back page of manual for useful telephone numbers.

#### PAPER JAM

#### Set to Off (4) and empty bin. Replace bin and follow the below procedures.



Stops automatically if too much paper is inserted. Automatic reverse if paper jams



paper from paper entry. Machine runs for a short time in reverse. Repeat if necessary



Shred One Sheet

## CLEANING AUTO-START INFARED SENSORS

Paper detection sensors are designed for maintenance free operation. However. on rare occasions the sensors may become blocked by paper dust causing the motor to run even if there is no paper present (Note: two paper detection sensors are located in the center of the paper entry).

#### TO CLEAN THE SENSORS







Locate Auto-start infared sensor



Use thin, long-handled brush to clean sensors. Make sure brush is clean and dry



Clean any contamination from the paper sensors



## POWERSHRED HS-660 THE WORLD'S TOUGHEST SHREDDERS™

## WARRANTY

Limited Warranty: Fellowes, Inc. ("Fellowes") warrants the parts of the machine to outside of the country where the shredder is initially sold. ANY IMPLIED WARRANTY, be free of defects in material and workmanship and provides service and support for INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS 1 year from the date of purchase by the original consumer. Fellowes warrants the cutting blades of the machine to be free from defects in material and workmanship ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages for I year from the date of purchase by the original consumer. If any part is found to attribute to this product. This warranty greve you specific legal rights. The duration, be defective during the warranty period, your sole and exclusive remedy will be repair terms, and conditions of this warranty are valid worldwide, except where different or replacement, at Fellowes' option and expense, of the defective part. This warranty in terms, and conditions, or this warranty are valid worldwide, except where different of the paper shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country where the shredder is initially sold. ANY IMPLIED WARRANTY, be a country or warranty period or any consequential or incidental damages that the country warranty are valid workmanty. The APROPRIATE WARRANTY PERIOD SET FORTH CUTTING THE APPROPRIATE WARRANTY PERIOD SET FORTH CUTTING THE APPR

#### **Questions or Concerns?**

www.fellowes.com Troubleshooting Registration Manuals	Customer Service & Support Troubleshooting Replacement parts General questions
Australia	+1-800-33-11-77
Canada	+1-800-665-4339
Europe	00-800-1810-1810
Mexico	+1-800-234-1185
United States	+1-800-955-0959



Fellowes 1789 Norwood Avenue, Itasca, Illinois 60143-1095 • USA • 630-893-1600

www.fellowes.com

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com