

P-8C



Please read these instructions before use. Do not discard: keep for future reference.

fellowes.com





# **KEY**

- A. Shredder head
- F. Disconnect power switch
- J. Control switch and LEDs

- B. Handle
- G. Paper/card entry
- I 1. Auto-On (green)

- C. Safety lock
- H. See safety instructions
- 2. OFF

- D. Window
- I. Sheet capacity guage
- R 3. Reverse
  4. Overheat (red)

- E. Bin
- C. Safety lock

  To set lock, push down and slide

# **CAPABILITIES**

Will shred: Paper, credit cards, paper clips and staples

Will not shred: Continuous forms, CD/DVDs, adhesive labels, transparencies, newspaper, cardboard, laminatess, X-rays or plastic other than noted above

#### Paper shred size:

Cross-Cut.......5/32 in. x 2 in. (3.9mm x 50mm)

#### Maximum:

Sheets per pass	8*
Cards per pass	
Paper entry width	


\*8.5 in. x11 in., 20 lb., (75g) paper at 120V/60 Hz, 3.0Amps; heavier paper, humidity or other than rated voltage may reduce capacity. Recommended daily usage rates: 10-20 paper passes; 10 cards. \$\hat{\textit{\textit{\textit{\textit{0}}}}\) 8 sheets per pass.

# **WARNING: IMPORTANT SAFETY INSTRUCTIONS** — Read Before Using!























- Do not use if damaged or defective. Do not disassemble shredder. Do not place near or over heat source or water.
- This shredder has a Disconnect Power Switch (F) that must be in the ON (I)
  position to operate shredder. In case of emergency, move switch to OFF (O)
  position. This action will stop shredder immediately.
- Avoid touching exposed cutting blades under shredder head.
- Do not put foreign objects in paper entry.
- The grounded socket-outlet shall be installed near the equipment and shall be easily accessible.

#### **BASIC SHREDDING OPERATION**


Insert waste bag (Fellowes #36052) for easy disposal.



**Continuous operation:** 

3-5 minute maximum

**NOTE:** Shredder runs briefly after each pass to clear entry. Continuous operation beyond 3-5 minutes will trigger a 15-minute cool down period.




## 8

Safety Lock prevents accidental operation. To set, wait for shredding to stop, push black button down and slide towards front of shredder.

To unlock push black button down and slide toward back of shredder. For greater safety, always unplug shredder after use.

#### **TROUBLESHOOTING**

Paper jam: Set to Off (0), remove shredder head and empty bin. Replace shredder head, and follow any or all of the below procedures.





Set to Off (0)

and unplug



paper from paper

entry. Plug in.



Set to Reverse (R)

#### Shredder doesn't start:

Make sure head is on basket correctly Wait 15 minutes for motor to cool down Remove and empty basket

Make sure safety lock is in unlock position

## **BASIC PRODUCT MAINTENANCE**

# OILING SHREDDER 🚄



All cross-cut shredders require oil for peak performance. If not oiled, a machine may experience diminished sheet capacity, intrusive noise when shredding and could ultimately stop running. To avoid these problems, we recommend you oil your shredder each time you empty your waste bin.

#### FOLLOW OILING PROCEDURE BELOW AND REPEAT TWICE



Set to Off (0)



\*Apply oil

across entry



Set to Auto-On (I)





Shred one sheet

Set to Reverse (R) for 2-3 seconds

ACAUTION \*Only use a non-aerosol vegetable oil in long nozzle container such as Fellowes 35250



## LIMITED PRODUCT WARRANTY

LIMITED WARRANTY Fellowes, Inc. ("Fellowes") warrants the cutting blades of the machine to be free from defects in material and workmanship for 3 years from the date of purchase by the original consumer. Fellowes warrants all other parts of the machine to be free of defects in material and workmanship for 1 year from the date of purchase by the original consumer. If any part is found to be defective during the warranty period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part. This warranty does not apply in cases of abuse, mishandling, or unauthorized repair. ANY IMPLIED WARRANTY, INCLUDING THAT

OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages attributable to this product. This warranty gives you specific legal rights. The duration, terms, and conditions of this warranty are valid worldwide, except where different limitations, restrictions, or conditions may be required by local law. For more details or to obtain service under this warranty, please contact us or your dealer.



# **Useful Phone Numbers**

Help Line	
Australia	+1-800-33-11-77
Canada	+1-800-665-4339
Fellowes	
Australia	+61-3-8336-9700
Benelux	+31-(0)-76-523-2090
Canada	+1-905-475-6320
Deutschland	+49-(0)-5131-49770
Espana	+34-90-233-55-69
France	+33-(0)-1-78-64-91-00
Italia	+39-071-730041

Europe	00-800-1810-1810			
Mexico	+1-800-234-1185			
United States	+1-800-955-0959			
Japan	+81-(0)-3-5496-2401			
Korea	+82-(0)-2-3462-2884			
Malaysia	+60-(0)-35122-1231			
Polska	+48 (22) 481-96-12			
Singapore	+65-6221-3811			
United Kingdom	+44-(0)-1302-836836			
United States	+1-630-893-1600			

Fello	owes.
-------	-------

1789 Norwood Avenue, Itasca, Illinois 60143-1095 • USA • 630-893-1600

www.fellowes.com

Australia	Benelux	Canada	China	France	Germany	Italy	Japan
Korea	Poland	Russia	Singapore	South Africa	Spain	United Kingdom	United States

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com