

# Fisher-Price®


## Twirlin' Whirlin' Garden™

### Supplemental Instructions

Product Number: 71923

### We've Made a Change!

Please disregard assembly step 3 in the enclosed instructions and follow these instructions instead!



- Insert and snap the tabs on the rainbow backboard into the slots in the base.
- Insert and snap the flowers into the the base.
- Fit one of the the pegs at the center of the block rocker into a hole in the base. Press to snap the other peg on the block rocker into the hole in the base.

**Assembly is now complete. Please continue to read the instructions for play and care for important information!**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>