





Smart Shopper™ Marketplace Scanner Installation Kit

Kit Parts


Installation Instructions Tool Required for installation: Phillips Screwdriver (not included).



Scanner




Label
(Apply Last)




Instruction Sheet

#8 x 1" Screw - 2




Shown Actual Size


Note: Tighten the screws with a Phillips screwdriver. Do not over-tighten.




- Place the scanner on the counter top and press down firmly. The scanner should push a hole through the label on your counter top revealing a screw hole. Remove the scanner from the counter top.




- Remove the two existing screws from your counter top. Discard these screws.



- Replace the scanner on the counter top. Insert the two enclosed screws into the holes in the scanner.



- Apply the label as shown in the illustration.



- Installation is now complete.**
- To activate the scanner sound effects, first press any key on the cash register, then place an item on the scanner and press lightly.

Questions? We'd like to hear from you!
Call Fisher-Price® Consumer Relations,
toll-free at **1-800-432-5437**.

Model Number: B1504

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>