

Fisher-Price®

www.fisher-price.com



H4828




H3370



Twin Time Dollhouse™

Download from www.Somanuals.com. All Manuals Search And Download.


Parts



Roof




3 Windows




Dollhouse



Valance



2 Awnings



Door Frame

PARTS NOT SHOWN:

Kitchen Island

2 Cradles

2 Baby Blankets

Sofa

Easy Chair

Chair

Cat Bed

Snack Tray


Train Toy

Rocking Horse


**2 Flower Boxes
with Flowers**

5 Figures

Assembly




- Grasp the latches and open the back of dollhouse **A**.
- Lower the sides **B**.
- Lower the "patio" **C**.




- **"Snap"** the roof to the top of the dollhouse.

Assembly





- **“Snap”** the door frame and three windows to the front of the dollhouse.
- **“Snap”** the awnings onto the front of the dollhouse at an angle, as shown.



- Press to fit the valance above the third floor window.

Fold Up Storage



- Place all accessories inside the dollhouse. Lift the patio **A**.
- Grasp the colored handles and lift both sides **B**.

- Fold both sides in **C**.


Consumer Information

Please keep this instruction sheet for future reference, as it contains important information.

Adult assembly is required.


No tools needed for assembly.

Wipe this toy with a clean cloth dampened with a mild soap and water solution.



CONSUMER ASSISTANCE

Call toll free: 1-800-432-5437 (US & Canada only)
M-F 9AM to 7PM / SAT 11AM to 5PM (EST)

 service.fisher-price.com

Write to us at: Fisher-Price® Consumer Relations,
636 Girard Avenue, East Aurora, New York 14052.

Hearing-impaired consumers using TTY/TDD equipment,
please call 1-800-382-7470.

For countries outside the United States:

Canada: Mattel Canada Inc., 6155 Freemont Blvd.,
Mississauga, Ontario L5R 3W2; www.service.mattel.com.

Great Britain: Mattel UK Ltd, Vanwall Business Park,
Maidenhead SL6 4UB. Helpline: 01628 500303.
www.service.mattel.com/uk

Australia: Mattel Australia Pty. Ltd., 658 Church Street,
Locked Bag #870, Richmond, Victoria 3121 Australia.
Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive,
Albany 1331, Auckland.

Asia: Mattel East Asia Ltd, Room 1106, South Tower,
World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2007 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

PRINTED IN MEXICO

H3370c-0920

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>