



Please keep this instruction sheet for future reference,  
as it contains important information.

Adult assembly is required.

Tool required for assembly: Phillips Screwdriver (not included).





[www.fisher-price.com](http://www.fisher-price.com)

## Noah's Ark


# Parts

## ⚠ CAUTION

This product contains small parts in its unassembled state. Adult assembly is required.




**Parts not shown:**  
Noah and His Wife  
8 Animal Figures  
Food Basket  
Tool Box



**M3 x 16 mm Screw - 4**  
**Shown Actual Size**


# Assembly

1



- Fit the cabin to the deck as shown.
- While holding the cabin in place, turn the deck over and insert an M3 x 16mm screw into each hole in the deck and tighten the screws with a Phillips screwdriver. Do not over-tighten.

2




- Fit the groove on the top of the door onto the peg at the top of the doorframe.
- Press the bottom of the door to fit it onto the peg at the bottom of the doorframe.

3

# Assembly

3



- Fit the flag into any hole on top of the cabin.
- Press the button under the front of the deck and lift to remove the deck.
- Press the button on top of the hull to open.

# Care

- Wipe the toy with a clean cloth dampened with a mild soap and water solution.
- Do not immerse the toy.

## Questions? We'd like to hear from you!

Call Fisher-Price® Consumer Relations, toll-free at **1-800-432-5437**, 8 AM- 6 PM EST Monday through Friday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Or, write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

### For countries outside the United States:

**CANADA: Questions? 1-800-567-7724.** Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

**GREAT BRITAIN:** Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB. Helpline: 01628 500302.

**AUSTRALIA:** Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

**NEW ZEALAND:** 16-18 William Pickering Drive, Albany 1331, Auckland.

**ASIA:** Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.

©2003 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

PRINTED IN CHINA

Download from [Www.Somanuals.com](http://Www.Somanuals.com). All Manuals Search And Download.

B1266a-0920

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>