JSS28WK/CK/BK GE[®] 30" Slide-In Electric Range

Dimensions and Installation Information

KW Rating	
240V	10.8
208V	8.1

Optional Kits

(Available at additional cost) JXS32 - Backguard JXS56 - Lower Trim Kit JXS86 - Vertical Side Trim Kit JXS77 - Body Sides

Note: To reduce possiblity of scorching of the side wall adjacent to the heating elements, it is recommended a minimum of 6" spacing from adjacent side walls be allowed for possible extended, high-heat, no-load operation of heating elements.

Receptacle Location: For all 30" Slide-In Ranges locally approved flexible service cord or conduit must be used because terminals are not accessible after range installation. See shaded area in drawing for location of electrical outlet box. Recommended outlet locations allow range to be installed directly against rear wall.

Note: Cabinets installed adjacent to slide-in ranges must have an adhesion spec of at least 194.°

Installation Information: Before installing, consult installation instructions packed with product for current dimensional data.


For answers to your Monogram,[®] GE Profile[™] or GE® appliance questions, visit our website at ge.com or call GE Answer Center[®] service, 800.626.2000.



30" Min Recommended 6" Min. Accessory From Walls Backguard Δ/R 30" Min 31-1/4 2-7/8" Acceptable Electrical 23-3/16 To Front 13" Max. Surface Of **Outlet Area** 00 18" Min. Countertop 36-1/4 35-7/8"-38" 20-5/8" Door from floor to Clearance From Front countertop 2-1/2 Surface of 7-1/2 Countertop 2-1/2 25-3/4** *JXS37 is 5-1/4" and JXS32 is 4 (excluding handle) **Total depth from wall to front of closed oven door including handle is 27-13/16. If you are NOT using the If you are using the optional

optional Filler or Backguard:

Filler or Backguard:



Dimension and installation information are shown in inches.




Listed by Underwriters Laboratories

```
Specification Revised 9/06
        320640
```

JSS28WK/CK/BK GE® 30" Slide-In Electric Range

Features and Benefits

- Electronic Oven Controls One-touch electronic pads are easy-to-use and allow for simple oven operation
- Coil Heating Elements Provide consistent and even heat on the cooktop with a plug-in element that is removable for easy cleaning
- Big ClearView™ Window An extra large clear window makes monitoring the progress of the food easy
- Frameless Glass Oven Door Offers an easy-to-clean and stylish design that blends seamlessly into existing cabinetry
- Dual Element Bake Alternates the upper broiling element and the lower baking element for even heating and optimal baking results
- Lift-up Porcelain Cooktop Makes spills and messes under the cooktop easily accessible and within reach
- Chrome Drip Bowls Contain minor spills and are removable for easy cleaning
- Two Oven Racks Feature a durable construction to help accommodate any size or type of cookware
- Audible Preheat Signal Features an audible signal that activates when the oven has reached the desired cooking temperature
- Interior Oven Light Supplies light to make viewing the progress of cooking easy and convenient
- Model JSS28WKWW White on white (white door and white cooktop)
- Model JSS28CKCC Bisque on bisque (bisque door and bisque cooktop)
- Model JSS28BKBB Black on black (black door and black cooktop)





Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com