

24H253 USB Module Kit

3A1333A ENG

To add a USB Module to a ProMix[®] 2KE Electronic Proportioner. For professional use only.



Important Safety Instructions Read all warnings and instructions in this

Read all warnings and instructions in this manual and in your separate ProMix 2KE manuals. Save these instructions.

Kit Parts

Ref.	Part	Description	Qty.
340	16F358	USB MODULE with TOKEN (T);	1
		see manual 3A1244 for token	
		instructions	
341	121417	SCREW	4
342	102063	WASHER	1
343	195875	SCREW	1
345	24H084	USB HARNESS	1
346	15R325	COVER, bulkhead	1
347▲	15X214	LABEL, warning	1

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

NOTE: You must order a CAN cable separately to complete the installation:

- For systems approved for Hazardous locations (IS, alternator powered), order Part No. 15V782 Cable.
- For systems approved for non-Hazardous locations, (non-IS) order Part No. 15V778 Cable.

PROVEN QUALITY. LEADING TECHNOLOGY.

Download from Www.Somanuals.com. All Manuals Search And Download.

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

	WARNING
	 FIRE AND EXPLOSION HAZARD Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion: Use equipment only in well ventilated area. Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). Keep work area free of debris, including solvent, rags and gasoline. Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
	 Ground all equipment in the work area. See Grounding instructions. Use only grounded hoses. Hold gun firmly to side of grounded pail when triggering into pail. If there is static sparking or you feel a shock, stop operation immediately. Do not use equipment until you identify and correct the problem. Keep a working fire extinguisher in the work area.
4	 ELECTRIC SHOCK HAZARD This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock. Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment. Connect only to grounded power source. All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.

Install the USB Module

<u> </u>

- 1. Disconnect main power. Open the control box.
- 2. Remove the five knockouts (K) on the top of the control box. See Fig. 1.
- 3. Install the USB module using four screws (341). The fifth screw (343) and star washer (342) must be installed in the center knockout to provide a ground-ing contact to the control box.
- 4. Install the USB cable (345) through the side of the control box and secure with the bulkhead nut (N, included). Connect the other end of the cable to the USB port on the module.
- 5. Install the bulkhead cover (346) over the USB cable port.
- 6. Place the warning label (347) above the USB cable port as shown in Fig. 1.




FIG. 1. Install USB Module

Install the Power CAN Cable

Non-IS Systems

- 1. Remove the user interface cable from J8 of the fluid control module and plug it into connector P3 of the USB module. See FIG. 2.
- 2. Connect Part No. 15V778 Cable (order separately) to J8 of the fluid control module and to connector P4 of the USB module.
- 3. Close the Control Box. Restore power.
- 4. See your ProMix 2KE Operation manual for instructions on using the USB module.

P4 P3

Fluid Control Module

USB Module

IS Systems

- 1. Connect Part No. 15V782 Cable (order separately) to J2 of the alternator module and to connector P3 of the USB module. See FIG. 3.
- 2. Close the Control Box. Restore power.
- 3. See your ProMix 2KE Operation manual for instructions on using the USB module.



To help prevent fire and explosion, do not connect, download, or remove the USB flash drive unless the unit is removed from the hazardous (explosive atmosphere) location. Never leave the USB flash drive in the USB port.

USB Module Alternator Module Intersection Intersection

FIG. 3. Install Part No. 15V782 Cable (IS Systems)




FIG. 2. Install Part No. 15V778 Cable (Non-IS Systems)

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor. Phone: 612-623-6921 or Toll Free: 1-800-328-0211 Fax: 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A1333

Graco Headquarters: Minneapolis International Offices: Belgium, China, Japan, Korea

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

Copyright 2010, Graco Inc. is registered to ISO 9001 www.graco.com Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com